

Horizon[®] 200/400 Powder Coating System

Customer Product Manual

Part 106913E03

Issued 4/09

**For parts and technical support, call the Industrial Coating
Systems Customer Support Center at (800) 433-9319 or
contact your local Nordson representative.**

This document is subject to change without notice.
Check <http://emanuals.nordson.com> for the latest version.



NORDSON CORPORATION • AMHERST, OHIO • USA

Contact Us

Nordson Corporation welcomes requests for information, comments, and inquiries about its products. General information about Nordson can be found on the Internet using the following address:
<http://www.nordson.com>.

Address all correspondence to:

Nordson Corporation
Attn: Customer Service
555 Jackson Street
Amherst, OH 44001

Notice

This is a Nordson Corporation publication which is protected by copyright. Original copyright date 1996. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Nordson Corporation. The information contained in this publication is subject to change without notice.

Trademarks

Horizon, Nordson, the Nordson logo, Sure Coat, Tribomatic, and Versa-Spray are registered trademarks of Nordson Corporation.

Table of Contents

Safety	1-1
Introduction	1-1
Qualified Personnel	1-1
Intended Use	1-1
Regulations and Approvals	1-2
Personal Safety	1-2
Fire Safety	1-2
Grounding	1-3
Action in the Event of a Malfunction	1-4
Disposal	1-4
 Description	 2-1
Introduction	2-1
System Configuration	2-1
System Operation	2-2
Powder Application	2-2
Powder Recovery and Reclaim	2-2
Non-Reclaim Systems	2-2
System Equipment	2-4
Recovery and Reclaim Equipment	2-4
System Controls	2-5
Application Equipment	2-5
Typical System Options	2-7
System Electrical and Pneumatic Controls	2-9
Motor Starter Panel	2-9
System Pneumatic Panel	2-11
Rotary Sieve Pneumatic Panel	2-12
 Operation	 3-1
New System Startup	3-1
Transfer Pump and Pulse Valve Timer Settings	3-1
Seal Checks	3-2
Air Pressure and Air Flow Settings	3-3
Rotary Sieve Settings	3-5
Final Startup Steps	3-5
Fan Damper Adjustment	3-6
Feed Hopper Level Sensor Calibration	3-6
Vent-Assist Air Pressure Adjustment	3-8
Daily Startup and Shutdown Procedures	3-8
Startup	3-8
Shutdown	3-9
Changing Colors	3-9
Color Change: Reclaim-to-Reclaim	3-9
Old Color Removal	3-9
New Color Installation	3-10
Color Change: Reclaim-to-Non-Reclaim	3-12
New Color Module/Feed Hopper Assembly	3-12
New Color Module with Portable Feed Hopper	3-14
Startup after Color Change	3-15

New Cartridge Filter Seasoning	4-1
Introduction	4-1
Seasoning with a Manual Operated Fan Damper	4-1
Seasoning with a Manual AMS System	4-2
Seasoning with an Automatic AMS System	4-2
Seasoning Without a Fan Damper or AMS System	4-3
 Maintenance	 5-1
Daily Maintenance	5-1
Cleaning	5-1
Daily Equipment Maintenance	5-2
Weekly Maintenance	5-4
Periodic Maintenance	5-5
Maintenance Check List	5-6
 Troubleshooting	 6-1
Introduction	6-1
Troubleshooting Procedures	6-2
Reversing Motor Direction	6-8
Exhaust Fan Motor	6-8
Sieve Motor	6-8
Schematics	6-9
Pneumatic Schematic	6-9
Electrical Schematic	6-10
 Repair	 7-1
Introduction	7-1
Final Filter Replacement	7-1
Cartridge Filter Replacement	7-3
Cartridge Filter Removal	7-3
Cartridge Filter Installation	7-3
Color Module Fluidizing Plate Replacement	7-6
Preparation	7-6
Fluidizing Plate Replacement	7-6
Feed Hopper Fluidizing Plate Replacement	7-8
Preparation	7-8
Fluidizing Plate Replacement	7-8
Vibratory Sieve Repair	7-10
Pulse Valve Replacement	7-10
Fan and Fan Drive Repair	7-12
V-Belt Replacement	7-14
Sheave Replacement	7-16
Sheave Removal	7-16
Sheave Installation	7-16
Motor Replacement	7-19
Motor Removal	7-19
Motor Installation	7-19
Fan Replacement	7-21
Fan Removal	7-21
Fan Installation	7-21
Fan Shaft and Bearing Replacement	7-23
Bearing Types	7-23
Fan Shaft and Bearing Removal	7-23
Fan Shaft and Bearing Installation	7-24
Old-Style Bearing and Fan Shaft Adjustment	7-25
New-Style Bearing and Fan Shaft Adjustment	7-26

Parts	8-1
Introduction	8-1
System Electrical Panel	8-2
Horizon 400 Parts	8-6
Base Parts	8-6
Pulse Valves and Air Manifold Parts	8-8
Pulse Valve Solenoids and Air Volume Control Parts	8-9
Fan and Fan Drive Parts	8-10
Belt/Bushing/Sheave/Motor/Mounting Plate Parts	8-12
Fan Damper Parts	8-12
Final Filters and Mounting Parts	8-14
Color Module Parts	8-15
Color Module Fluidizing Plates, Direct Vent, and Vent Stub Parts	8-17
Cartridge Filters	8-17
Vent Options	8-17
Horizon 200 Parts	8-19
Base Parts	8-19
Fan and Fan Drive	8-20
Color Module	8-21
Cart-Mounted Feed Hoppers and Sieves	8-22
Hopper with Vibratory Sieve	8-22
Hopper with 10-Port Cyclone	8-22
Hopper with Nordson 230/460 V Rotary Sieve	8-23
Feed Hopper with AZO Sieve	8-24
Feed Hopper with Nordson NRPS-100 Rotary Sieve	8-25
 Specifications	 9-1
Dimensions and Capacities	9-1
Operating Environment	9-1
Utilities	9-2
Normal Design Standards	9-2

Section 1

Safety

Introduction

Read and follow these safety instructions. Task- and equipment-specific warnings, cautions, and instructions are included in equipment documentation where appropriate.

Make sure all equipment documentation, including these instructions, is accessible to all persons operating or servicing equipment.

Qualified Personnel

Equipment owners are responsible for making sure that Nordson equipment is installed, operated, and serviced by qualified personnel. Qualified personnel are those employees or contractors who are trained to safely perform their assigned tasks. They are familiar with all relevant safety rules and regulations and are physically capable of performing their assigned tasks.

Intended Use

Use of Nordson equipment in ways other than those described in the documentation supplied with the equipment may result in injury to persons or damage to property.

Some examples of unintended use of equipment include

- using incompatible materials
- making unauthorized modifications
- removing or bypassing safety guards or interlocks
- using incompatible or damaged parts
- using unapproved auxiliary equipment
- operating equipment in excess of maximum ratings

Regulations and Approvals

Make sure all equipment is rated and approved for the environment in which it is used. Any approvals obtained for Nordson equipment will be voided if instructions for installation, operation, and service are not followed.

All phases of equipment installation must comply with all federal, state, and local codes.

Personal Safety

To prevent injury follow these instructions.

- Do not operate or service equipment unless you are qualified.
- Do not operate equipment unless safety guards, doors, or covers are intact and automatic interlocks are operating properly. Do not bypass or disarm any safety devices.
- Keep clear of moving equipment. Before adjusting or servicing any moving equipment, shut off the power supply and wait until the equipment comes to a complete stop. Lock out power and secure the equipment to prevent unexpected movement.
- Relieve (bleed off) hydraulic and pneumatic pressure before adjusting or servicing pressurized systems or components. Disconnect, lock out, and tag switches before servicing electrical equipment.
- Obtain and read Material Safety Data Sheets (MSDS) for all materials used. Follow the manufacturer's instructions for safe handling and use of materials, and use recommended personal protection devices.
- To prevent injury, be aware of less-obvious dangers in the workplace that often cannot be completely eliminated, such as hot surfaces, sharp edges, energized electrical circuits, and moving parts that cannot be enclosed or otherwise guarded for practical reasons.

Fire Safety

To avoid a fire or explosion, follow these instructions.

- Do not smoke, weld, grind, or use open flames where flammable materials are being used or stored.
- Provide adequate ventilation to prevent dangerous concentrations of volatile materials or vapors. Refer to local codes or your material MSDS for guidance.
- Do not disconnect live electrical circuits while working with flammable materials. Shut off power at a disconnect switch first to prevent sparking.

- Know where emergency stop buttons, shutoff valves, and fire extinguishers are located. If a fire starts in a spray booth, immediately shut off the spray system and exhaust fans.
- Clean, maintain, test, and repair equipment according to the instructions in your equipment documentation.
- Use only replacement parts that are designed for use with original equipment. Contact your Nordson representative for parts information and advice.

Grounding



WARNING: Operating faulty electrostatic equipment is hazardous and can cause electrocution, fire, or explosion. Make resistance checks part of your periodic maintenance program. If you receive even a slight electrical shock or notice static sparking or arcing, shut down all electrical or electrostatic equipment immediately. Do not restart the equipment until the problem has been identified and corrected.

All work conducted inside the spray booth or within 1 m (3 ft) of booth openings is considered within a Class 2, Division 1 or 2 Hazardous location and must comply with NFPA 33, NFPA 70 (NEC articles 500, 502, and 516), and NFPA 77, latest conditions.

- All electrically conductive objects in the spray areas shall be electrically connected to ground with a resistance of not more than 1 megohm as measured with an instrument that applies at least 500 volts to the circuit being evaluated.
- Equipment to be grounded includes, but is not limited to, the floor of the spray area, operator platforms, hoppers, photoeye supports, and blow-off nozzles. Personnel working in the spray area must be grounded.
- There is a possible ignition potential from the charged human body. Personnel standing on a painted surface, such as an operator platform, or wearing non-conductive shoes, are not grounded. Personnel must wear shoes with conductive soles or use a ground strap to maintain a connection to ground when working with or around electrostatic equipment.
- Operators must maintain skin-to-handle contact between their hand and the gun handle to prevent shocks while operating manual electrostatic spray guns. If gloves must be worn, cut away the palm or fingers, wear electrically conductive gloves, or wear a grounding strap connected to the gun handle or other true earth ground.
- Shut off electrostatic power supplies and ground gun electrodes before making adjustments or cleaning powder spray guns.
- Connect all disconnected equipment, ground cables, and wires after servicing equipment.

Action in the Event of a Malfunction

If a system or any equipment in a system malfunctions, shut off the system immediately and perform the following steps:

- Disconnect and lock out electrical power. Close pneumatic shutoff valves and relieve pressures.
- Identify the reason for the malfunction and correct it before restarting the equipment.

Disposal

Dispose of equipment and materials used in operation and servicing according to local codes.

Section 2

Description

Introduction

This manual covers Horizon 200 and 400 powder coating systems. It includes booth operation, maintenance, troubleshooting, repair procedures, and lists of serviceable parts. Other components of your system are covered in separate manuals.

System Configuration

This manual covers a basic, manually operated powder coating system. The illustrations show a Horizon 400 system. The Horizon 200 system is smaller, but has the same basic components. Additionally, your system may have optional equipment not described in this manual, such as the Smart-Coat system or other advanced control systems.

Systems are either permanently located under the conveyor, or mounted on casters and rails (roll-on/roll-off system). Roll-on/roll-off systems can be moved off-line for powder changes or maintenance.

Figure 2-1 illustrates the operation of the typical system. Figures 2-2 through 2-5 show the equipment and controls used in a typical system. You should also review the engineering drawings (plan views and schematics) furnished with your system.

System Operation

See Figure 2-1.

Powder Application

A porous fluidizing plate in the bottom of the feed hopper (8) diffuses low-pressure compressed air into the powder supply. The air fluidizes the powder, so it can be pumped to the spray guns. A vent duct connects the hopper to the color module (10).

The powder pumps (7) draw the powder out of the hopper, mix it with a high-velocity stream of air, and force it through the feed hoses (9) to the powder spray guns (2). The guns electrostatically charge the powder and spray it onto the workpieces (3) passing through the enclosure (1). The charged powder sticks to the grounded workpieces.

Powder Recovery and Reclaim

The exhaust fan (16) pulls spray-room air through the enclosure and into the color module through an opening in the base floor. A skirt seal prevents powder from escaping from the gap between the base floor and the color module. The air flows through the cartridge filters (13), into the fan compartment, through the final filters (17), and back into the spray room. The standard, manual fan damper (15) (Horizon 400 only) controls the volume of air flowing through the booth.

The oversprayed powder suspended in the air collects on the external surfaces of the cartridge filters. At timed intervals, the pulse valves (14) force large volumes of air through the center of the cartridge filters, blowing off the collected powder. The powder falls into the color module hoppers, where it is fluidized.

The transfer pumps (12) pump the fluidized powder in the color module hoppers through the transfer hoses (11) to the accumulator (5) on top of the sieve (6). The powder flows from the accumulator into the sieve screen. The screened powder falls into the feed hopper. The sieve discharges particles and clumps too large to pass through the screen into a scrap container. The vent hose (4) connecting the accumulator to the color module helps maintain a neutral air pressure in the accumulator and sieve.

Non-Reclaim Systems

You can convert your Horizon system from reclaim to non-reclaim by installing a color module for the new powder and connecting the transfer hoses to a scrap drum instead of an accumulator and sieve. You can then use a standard feed hopper attached to the color module, or a portable feed hopper, to supply the new powder to the spray guns.




Figure 2-1 System Operation

- | | | |
|----------------|--------------------|-----------------------|
| 1. Enclosure | 7. Powder pumps | 13. Cartridge filters |
| 2. Spray guns | 8. Feed hopper | 14. Pulse valves |
| 3. Workpiece | 9. Feed hoses | 15. Fan damper |
| 4. Vent hose | 10. Color module | 16. Exhaust fan |
| 5. Accumulator | 11. Transfer hoses | 17. Final filters |
| 6. Sieve | 12. Transfer pumps | |

System Equipment

A typical system includes the equipment described below. Your system may have different equipment, or the equipment may be installed in locations different from those shown in the illustrations.

Recovery and Reclaim Equipment

Item numbers in Table 2-1 correspond to callouts in Figure 2-2.

Table 2-1 Recovery and Reclaim Equipment

Item	Equipment	Description
1	Booth enclosure (canopy)	Contains the sprayed powder within the booth. It has a conveyor slot in the roof, exit and entry vestibules at each end, and slots and openings in the sides for automatic and manual spray guns.
7	Booth base	Supports the enclosure and houses the exhaust fan, motor, fan damper, cartridge filter pulse valves and air manifold, and final filters. A covered tray running around the top edge of the base houses the system wiring and pneumatic plumbing.
10	Transfer pumps	Pump the reclaimed powder from the color module hoppers to the accumulator. A three-position switch on the system electrical panel controls pump operation.
14	Color module	Houses the cartridge filters, fluidizing plates and pans, and transfer pumps. Oversprayed powder accumulates in hoppers in the bottom of the module. A baffle plate covers the cartridge filters. A steel mesh grill covers the top of the module. A D-gasket seals the joint between the color module and the fan compartment.
15	Sieve	Screens the reclaimed powder. Discards powder particles and clumps too large to pass through the sieve screen. Electrically driven rotary sieves or air-powered vibratory sieves are available.
16	Accumulator	Collects the reclaimed powder pumped from the color module by the transfer pumps. The accumulator provides multiple inlet connections for the transfer hoses. It is vented into the color module.

System Controls

Item numbers in Table 2-2 correspond to callouts in Figure 2-2.

Table 2-2 System Controls

Item	Equipment	Description
2	Motor starter panel	Houses motor starters and overload protectors, transformers, interlock relays, differential-pressure switches, pulse valve timers, and basic system controls and indicator lights. An optional programmable controller can be installed in the panel.
3	Flame detector indicator/relay panel	Provides visible and audible fault and fire alarms and process shutdown relays. If a detector senses a flame, the interlock relays shut down the conveyor, booth exhaust fan, compressed air and electrical power to the spray guns. ANSI/NFPA-33 standards require flame detectors in all systems equipped with automatic spray guns.
5	Pneumatic panel	Houses air-pressure regulators and gauges for the color module, differential pressure switch gauges, feed hoppers, transfer pumps, and other pneumatic equipment.
6	Fan damper control	Opens and closes the fan damper louvers to control air flow through the enclosure. (Used only on Horizon 400.)
8	Pulse air controls	Regulate the pulse air pressure and volume. Controls include a regulator, pressure gauge, and gate valve.
11	Feed-hopper level sensor	Monitors the level of powder in the feed hopper. Turns on the transfer pumps when the level of powder falls below the sensor.
17	Flame detectors	Monitor the enclosure (booth) interior for flames. The detectors use IR sensing technology and provide through-the-lens self test to check for powder build-up.

Application Equipment

Item numbers in Table 2-3 correspond to callouts in Figure 2-2.

Table 2-3 Application Equipment

Item	Equipment	Description
4	Gun control units	Control air pressure to the powder pumps. Generate (cable-fed units) and control electrostatic voltage. Each spray gun requires a control unit. An equipment cabinet houses the automatic gun control units, a master control unit, and air supply controls.
9	Automatic spray guns	Charge powder particles electrostatically and spray them toward the grounded workpieces. The operator uses a manual spray gun for touch-up work.
12	Feed hopper	Stores and fluidizes the powder supply for automatic and manual spray guns.
13	Powder pumps	Pump powder out of the feed hopper to the spray guns. Each spray gun requires a pump.

Application Equipment (contd)




Figure 2-2 System Components

- | | | |
|---|------------------------------|---------------------|
| 1. Booth enclosure | 7. Booth base | 13. Powder pumps |
| 2. Motor starter panel | 8. Pulse air controls | 14. Color module |
| 3. Flame detector indicator/relay panel | 9. Automatic spray guns | 15. Sieve |
| 4. Gun control units | 10. Transfer pumps | 16. Accumulator |
| 5. Pneumatic panel | 11. Feed hopper level sensor | 17. Flame detectors |
| 6. Fan damper control | 12. Feed hopper | |

Typical System Options

Options include those described below. Contact your Nordson Corporation representative for further information on these and other options.

Item numbers in Table 2-4 correspond to callouts in Figure 2-3.

Table 2-4 Typical System Options

Item	Equipment	Description
1	Air dryer	Removes moisture from the system air supply. Most systems use regenerative-desiccant or refrigerated air dryers.
2	Gun movers	Use oscillators or reciprocators to move automatic spray guns in a repetitive pattern for better workpiece coverage. Gun movers may also be equipped to move the spray guns toward and away from the workpieces.
3	Powder drum unloaders	Transfer powder from shipping drums to feed hoppers or color modules.
4	Color change equipment	Consists of additional color modules, feed hoppers, sieves and accumulators. These contain different powders for quick changes.
—	Roll on/roll-off equipment	Move the booth and attached equipment on and off the conveyor line. Manual and powered equipment movers are available.
—	Advanced automation systems	Identify and track parts on the conveyor line; control automatic-gun movement, triggering, air pressure, and voltage. Also gather data on system operation and generate reports.
—	Airflow Management System	Automatically controls air flow through the booth, using a variable-speed motor control and pressure sensors.

Typical System Options (contd)




Figure 2-3 Typical System Options

- | | | |
|---------------|--------------------------|---------------------------|
| 1. Air dryer | 3. Powder drum unloaders | 4. Color change equipment |
| 2. Gun movers | | |

System Electrical and Pneumatic Controls

Basic system controls consist of an electrical panel and a pneumatic panel. Additional optional controls are covered in separate manuals.

Motor Starter Panel

A typical, manually controlled system uses a motor starter panel similar to the one shown in Figure 2-4. Item numbers in Table 2-5 correspond to callouts in Figure 2-4. Your system's electrical panel may be different.

Table 2-5 Motor Starter Panel

Item	Equipment	Description
1, 10, 19	Booth mover enable pushbutton (19)	Activates the booth mover time delay relay (1). During the timer delay, the booth mover alarm buzzer (10) sounds, and the system can be moved online or offline.
2, 13	Transfer pump selector and indicator light (13)	Selects the transfer pump operation. When set to manual, the transfer pumps run continuously. When set to auto feed, the hopper level sensor and transfer pump time delay relay (2) control pump operation.
3, 9	Booth lights selector (9)	NOTE: Power to the lights must be supplied by the customer. Activates the lighting contactor (3) for interior booth lights.
4, 5, 16	Final filter pressure switches	Set the pressure increase that is allowed across the final filters. At 2.5-in. wc, the final filter warning pressure switch (5) closes and activates the final filter warning indicator light (16). At 3-in. wc, the final filter pressure switch (4) opens and automatically shuts down the system.
6	Pulse valve ON timer	Sets the time that pulse valves remain open after triggering. The adjustment range is 0.05–0.5 sec.
7	Pulse valve OFF timer	Sets the time between cartridge filter pulses. The adjustment range is 8–180 sec.
8	Pulse valve LEDs	Indicate that solenoid valves controlling the pulse valves are open.
11	Exhauster speed control	Used with the variable frequency drive to adjust the exhauster fan speed.
12	Exhauster stop pushbutton	NOTE: This pushbutton does not shut down power to the panel. Shuts down the exhauster fan and system.
14	Exhauster start pushbutton/indicator light	Starts the exhauster fan and indicates that system power is on.
15	System ready indicator light	Indicates, when lit, that fire detection module limit switch and air dryer interlocks are closed and that the system is ready to start.
17	Main disconnect switch	Turns the motor starter panel's electrical power on or off.
18	Sieve and non-reclaim transfer enable indicator lights	The sieve light indicates that the sieve is in place and running. The non-reclaim enabled transfer light indicates that the system can transfer powder without the sieve in place.
20	Oscillator 1 and 2 pushbuttons/indicator lights	Turn the oscillators on or off.


Motor Starter Panel (contd)

Figure 2-4 Motor Starter Panel

- | | | |
|---|--|--|
| 1. Booth mover time delay relay | 9. Booth lights selector | 15. System ready indicator light |
| 2. Transfer pump time delay relay | 10. Booth mover alarm buzzer | 16. Final filter warning indicator light |
| 3. Lighting contactor | 11. Exhauster speed control | 17. Main disconnect switch |
| 4. Final filter pressure switch | 12. Exhauster stop pushbutton | 18. Sieve and non-reclaim transfer enable indicator lights |
| 5. Final filter warning pressure switch | 13. Transfer pump selector and indicator light | 19. Booth mover enable pushbutton |
| 6. Pulse valve ON timer | 14. Exhauster start pushbutton/indicator light | 20. Oscillator 1 and 2 pushbuttons/indicator lights |
| 7. Pulse valve OFF timer | | |
| 8. Pulse valve LEDs | | |

System Pneumatic Panel

Table 2-6 and Figure 2-5 describe a typical 12-function pneumatic panel. Functions can change depending on the pneumatic equipment used in the system and the system configuration (reclaim or non-reclaim).

Table 2-6 System Pneumatic Panel

Regulators and Gauges	Function
1	Feed hopper fluidizing air
2	Feed hopper vent-assist air
3	Satellite hopper fluidizing air/spare scrap drum lid
4	Satellite hopper vent-assist air/spare scrap drum lid
5	Fluidizing air #1
6	Transfer pump air #1
7	Fluidizing air #2
8	Transfer pump air #2
9	Fluidizing air #3
10	Transfer pump air #3
11	Fluidizing air #4
12	Transfer pump air #4
13	Blowdown filter pressure gauge (shows pulse-air pressure)
14	<p>Cartridge filter pressure gauge (shows air pressure drop across the cartridge filters in wc)</p> <p>NOTE: The gauge should read 4–6-in. wc. The gauge reading increases as the filters load up with powder.</p>
15	<p>Final filter pressure gauge (shows air pressure drop across the final filters in wc)</p> <p>NOTE: The gauge should read 1–2.5-in. wc. The gauge reading increases as the filters clog. At 3.0-in. wc, the system automatically shuts down.</p>

System Pneumatic Panel (contd)




Figure 2-5 System Pneumatic Panel

Rotary Sieve Pneumatic Panel

See Figure 2-6. This pneumatic panel is used with Nordson NRPS-100 and AZO rotary sieves. Older Nordson rotary sieves did not have a pneumatic panel.




Figure 2-6 Rotary Sieve Pneumatic Panel

- | | |
|------------------------------|-------------------------------|
| 1. Flow meters | 3. Bearing air seal regulator |
| 2. Vent-assist air regulator | |

Section 3

Operation



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

New System Startup



WARNING: Wear an approved respirator or dust mask, and safety glasses or goggles when handling powder. Avoid getting powder on your skin. Wash powder off with soap and water only.

Use these procedures to prepare your Horizon powder coating system for production. Setup and operation of powder application equipment, gun movers, and advanced control systems are covered in separate manuals.

Use the charts at the end of this section to record your booth and spray gun settings. Make extra copies of the charts as needed.

Transfer Pump and Pulse Valve Timer Settings



WARNING: Even with the electrical-panel disconnect switch in the off position, the terminals at the top of the switch are still live. Do not touch them. Failure to observe this warning could result in serious injury or death.

1. See Figure 3-1. Disconnect the system electrical power and open the system electrical panel.
2. Set the transfer pump and pulse valve timers then close the electrical panel.

Transfer pump delay timer (1): 60 seconds

Pulse valve off timer (2): 90 seconds

Pulse valve on timer (3): 0.07 seconds

Transfer Pump and Pulse Valve Timer Settings (contd)




Figure 3-1 Transfer Pump and Pulse-Valve Timers

- | | |
|------------------------------|-------------------------|
| 1. Transfer pump delay timer | 3. Pulse valve on timer |
| 2. Pulse valve off timer | |

Seal Checks

1. See Figure 3-2. Make sure the color module is sealed tight against the fan compartment. When the D-gasket (3) is properly compressed, the gap between the end of the color module and the fan compartment should be 19 mm (0.75 in.) wide. Tighten the clamping straps (4) if necessary.

NOTE: The limit switch (1) must be closed before the system will start. The switch position can be adjusted by loosening the mounting bracket screws and sliding the bracket forward or back.

2. Make sure the skirt seal (2) is correctly installed.




Figure 3-2 Color Module Seals and Limit Switch (Horizon 400 Shown)

- | | | |
|-----------------|-------------|--------------------|
| 1. Limit switch | 3. D-gasket | 4. Clamping straps |
| 2. Skirt seal | | |

Air Pressure and Air Flow Settings

1. Set all air pressure regulators on the pneumatic panel to zero.
2. Turn on the system compressed air supply. Adjust the system air pressure to 6.2 bar (90 psi).
3. Turn on the system electrical power.
4. Press the EXHAUSTER START pushbutton to start the exhaust fan.
5. Fill the feed hopper $\frac{2}{3}$ full of powder.
6. Calibrate the feed hopper level sensor. Refer to *Feed Hopper Level Sensor Calibration* on page 3-6.
7. Set the feed-hopper fluidizing air pressure to 0.7–1 bar (10–15 psi). Adjust the pressure until you see the powder gently boiling. Allow 10–15 minutes for the powder to fluidize before spraying.

Air Pressure and Air Flow Settings (contd)

8. See Figure 3-3. Adjust the pulse-valve air pressure and volume.
 - a. Open the slide gate (4) on the side of the fan section to access the pulse-valve air controls. Set the pulse valve regulator (1) to 345–413 kPa (50–60 psi). The valves will start pulsing. Watch the pressure gauge (3). The pressure will drop when the valves open.
 - b. Adjust the gate valve (2) so the air pressure returns to 345–413 kPa (50–60 psi) just before the next pulse. This adjustment will prevent the powder pumps from being deprived of air during pulses.
9. Adjust the fan damper hand wheel (5) (Horizon 400 only) to obtain the correct air flow through the enclosure. Refer to *Fan Damper Adjustment* on page 3-6.

NOTE: At this point, you can season your cartridge filters. Seasoning is not required, but may extend the life of the filters. Refer to the *Cartridge Filter Seasoning* section in this manual.

10. Start spraying powder. Adjust your application equipment settings to obtain the coverage and film thickness desired.
11. Set the color module fluidizing air pressure to 0.7 bar (10 psi). The recovered powder in the color module hoppers should boil gently. Increase or decrease the fluidizing pressure as necessary.




Figure 3-3 Pulse Air and Fan Damper Controls

- | | | |
|--------------------------|-------------------|--------------------------|
| 1. Pulse valve regulator | 3. Pressure gauge | 5. Fan damper hand wheel |
| 2. Gate valve | 4. Slide gate | |

Rotary Sieve Settings

NOTE: Sieve operation depends on system configuration. The sieve will turn on when the exhaust fan is started, or automatically on a signal from the feed-hopper level sensor.

1. See Figure 3-4. If your system uses a rotary sieve equipped with a pneumatic panel set the bearing-air pressure regulator (3) and flowmeters (1):

Bearing air pressure 1.7 bar (25 psi)

Flow meters 100 SCFH

2. If your system uses an air-operated vibratory sieve, set the motor air pressure to 3 bar (50 psi). Increase or decrease the pressure as needed to maintain the flow of powder through the sieve.

Final Startup Steps

1. Set the accumulator vent-assist air pressure regulator (2). Refer to *Vent-Assist Air Pressure Adjustment* on page 3-8.
2. Set the transfer-pump air pressure to 1 bar (15 psi). Set the transfer-pump selector switch to AUTO. This turns the pumps on and off on a signal from the feed-hopper level sensor.
3. Set the conveyor interlock switch to NORM.




Figure 3-4 Sieve Air Pressure Regulators and Flowmeters

- | | |
|------------------------------|-------------------------------|
| 1. Flow meters | 3. Bearing air seal regulator |
| 2. Vent-assist air regulator | |

Fan Damper Adjustment

The fan damper is used only on the Horizon 400 booth. The fan damper controls air flow through the booth. If the air speed and volume are too low, oversprayed powder can escape into the spray room through the enclosure openings. If the air speed and volume are too high, the sprayed powder will be pulled away from the workpieces.

See Figure 3-3. Use the fan damper hand wheel (5) on the front of the fan section to adjust the fan damper. To open the damper and increase the flow, turn the wheel counterclockwise. To close the damper and decrease the flow, turn the wheel clockwise. Six full turns of the wheel move the damper from fully open to fully closed.

1. Turn on the exhaust fan.
2. Turn the hand wheel counterclockwise until the damper is fully open.
3. Measure the air velocity at the entry and exit vestibules with a velometer. The velocity should be 30–37 m/min (100–120 fpm).
4. If the air velocity is too fast, turn the hand wheel one full turn clockwise. Measure the air velocity again. Continue closing the damper opening until the velocity is 30–37 m/min (100–120 fpm).
5. Coat a few workpieces. Watch the powder spray pattern and look for powder escaping from the enclosure openings.
 - a. If the sprayed powder is being pulled from the guns and workpieces, close the damper.
 - b. If powder is escaping from the enclosure, open the damper.

NOTE: The air flow through the cartridge filters will slowly decrease as fine powder particles clog the filter media. Check the air velocity at the enclosure openings periodically and adjust the fan damper to compensate.

6. Adjust the damper until the air velocity is fast enough to contain the powder within the enclosure without pulling the sprayed powder away from the guns and workpieces.

Feed Hopper Level Sensor Calibration

The level sensor is a capacitive proximity switch. When you install a new sensor, you must calibrate it.

NOTE: Replacement sensors are shipped configured as normally closed (N.C.) switches.

1. See Figure 3-5. Insert the level sensor into the plastic mounting well (1) in the side of the feed hopper until it bottoms out, then tighten the plastic screws on the side of the well to hold the sensor securely.
2. Make sure system power is on and the exhaust fan is running.
3. Open the feed hopper lid and fill the hopper $\frac{2}{3}$ full of powder.
4. Increase the hopper fluidizing air pressure to 0.7–1 bar (10–15 psi). The powder level should rise above the top of the mounting well as the powder fluidizes. Add powder to the hopper if it does not.

5. Shut off the fluidizing air. The mounting well should be coated with a film of powder.
6. If the sensor LED (3) is on, slowly turn the sensor potentiometer (2) clockwise until it goes off. If the LED is off, slowly turn the potentiometer counterclockwise until it lights, then clockwise until it goes off.
7. Increase the fluidizing pressure until the powder level rises above the mounting well. The LED should be off.
8. Turn the potentiometer counterclockwise, counting the number of turns you make, until the LED lights.
9. Turn the potentiometer clockwise for $\frac{1}{2}$ the number of turns you counted in step 8. The LED will go off. The sensor is now set in the midpoint of its sensitivity range.




Figure 3-5 Feed Hopper Level Sensor Calibration

- | | |
|-------------------------|------------------|
| 1. Mounting well | 4. Hopper wall |
| 2. Sensor potentiometer | 5. Bridge jumper |
| 3. LED | |

Vent-Assist Air Pressure Adjustment

To maintain a neutral air pressure in the sieve so it can function properly, the compressed air used to convey the reclaimed powder to the accumulator is vented into the color module. Vent-assist air creates low pressure in the vent tube and increases the air flow. Use the following procedure to adjust the vent-assist air pressure.

NOTE: The vent-assist air pressure regulator is located either on the sieve pneumatic panel, or on the system pneumatic panel.

1. Disconnect the scrap hose from the sieve.
2. Secure a paper or plastic bag to the scrap port with a worm clamp, cable tie, or rubber band.
3. Start the exhaust fan, sieve, and transfer pumps.
4. Watch the bag. If it inflates, increase the vent-assist air pressure. If it deflates, decrease the vent-assist air pressure.

Daily Startup and Shutdown Procedures

Use these procedures for routine operation of your system.

Startup

1. Turn on the system electrical power and compressed air supply.
2. Walk around the booth and verify that the:
 - system equipment is connected to ground
 - flame detector system is on
 - skirt seal is securely fastened to the color module and base
 - transfer and feed hoses are connected to the pumps, accumulators, and spray guns.
3. Turn on the exhaust fan. Set the transfer pump switch to AUTO. Set the conveyor switch to NORM.
4. Turn on the automatic-gun master control unit and the manual-gun control units.
5. Adjust the kV settings and the powder-pump air pressures, if necessary. Refer to your spray gun and control unit manuals.
6. Start the conveyor and start spraying workpieces.
7. Check the air flow through the enclosure. Make sure the sprayed powder is not being pulled from the spray guns and workpieces, or escaping from the enclosure openings. Adjust the fan damper (Horizon 400 only) as needed. Air flow through each opening must be maintained at 30 m/min (100 fpm), minimum.

Shutdown

1. Start the transfer pumps and sieves. Pump the reclaimed powder from the color module hoppers back into the feed hopper.
2. Turn off the automatic-gun master control unit and the manual-gun control units.
3. Perform the daily maintenance procedures described in the *Maintenance* section.
4. Turn off the exhaust fan. Shut off the system electrical power and compressed air supply.

Changing Colors

The following instructions describe powder color-change procedures. Use the *Reclaim-to-Reclaim* procedure if you are going to reclaim the new powder overspray. Use the *Reclaim-to-Non-Reclaim* procedure if you are going to scrap the new powder overspray.

Color Change: Reclaim-to-Reclaim

These instructions describe color-change procedures for reclaim systems that use a separate color module, feed hopper, and sieve assembly for each color.

Old Color Removal

1. See Figure 3-6. Disconnect the feed hoses (7) from the powder pumps. Blow the powder out of the hoses and powder spray guns with compressed air. Clean the spray guns as described in the spray gun manuals.
2. Disconnect the feed hoses from the powder spray guns.
3. Clean the enclosure as described in the *Daily Maintenance* procedures in the *Maintenance* section.
4. Shut off the exhaust fan, system electrical power, and compressed air supply. Relieve the system air pressure.
5. Remove the color module quick-disconnect plates (2). Uncouple the 10-tube connectors (4) from the feed hopper receptacles.
6. If you are using a rotary sieve, unplug the sieve electrical cables from the junction box (10) receptacles on the base.
7. Remove the level sensor (6) from the mounting well. Coil up the cable and store the sensor on the base.
8. Remove the skirt seal from the color module and base.
9. Release the clamping strap ratchets (1) on the sides of the color module. Disconnect the clamping straps from the base.

Old Color Removal *(contd)*

10. Move the transfer hoses (3), air tubing, and cables off the floor and out of the way so they will not be damaged when you remove the color module.
11. Pull the color module, feed hopper, and sieve assembly from under the base, using the handle (9) provided. Move the assembly to a storage area and install a storage cover over the color module.
12. With a vacuum and soft brush, clean the powder from the:
 - edges of the floor inlet
 - hook and loop tape strips
 - underside of the floor
 - area where the color module seals against the fan compartment
13. Inspect the fan compartment. If there is a large amount of powder in the fan compartment, check the filter cartridge media and gaskets for damage. Clean the fan compartment and check the final filters.

New Color Installation

1. Remove the storage cover from the new color module. Inspect the D-gasket and replace it if it is damaged.
2. See Figure 3-6. Position the new color module under the base, aligning the top of the color module with the floor inlet and the D-gasket with the fan compartment opening.
3. Check the gap between the base floor and the color module. Maintain the gap at 19 mm (0.75 in.). Use the color-module leveling screws to raise or lower the color module.

NOTE: If the limit switch (Figure 3-2, item 1) is not closed when the color module is clamped to the fan compartment you will not be able to start the exhaust fan. If it does not close, adjust the switch position. Loosen the mounting screws and slide the switch forward or back.

4. Hook the clamping straps to the base. Tighten the ratchets (1) to compress the D-gasket. The gap between the color module and the fan compartment should be 19 mm (0.75 in.) wide when the D-gasket is properly compressed.
5. Install the skirt seal over the joint between the base floor and the color module. Line up the skirt corners with the inlet corners and smooth down the skirt to press the Velcro strips together.
6. Connect the color module quick-disconnect plate (2) to the base plate.
7. Connect the 10-tube connectors (4) to the receptacles on the feed hopper.
8. Connect the color-module ground strap to the base.
9. Plug the sieve electrical cables into the junction box receptacles (10).
10. Insert the level sensor (6) into the mounting well until it bottoms out, then pull it back about 3 mm (0.125 in.) and tighten the retainer screws.

11. Make sure the accumulator vent hose (5) is connected to the color-module vent stub, and the vent-assist air tubing is connected to the tube fitting.
12. Make sure the transfer hoses (3) are connected to the accumulator (8).
13. Install new feed hoses (7) between the powder pumps and the spray guns, or use hoses that have already been used with the new color.
14. Perform the *Startup after Color Change* procedure on page 3-15.




Figure 3-6 Color Change: Reclaim-to-Reclaim (Horizon 400 Shown)

- | | | |
|----------------------------|-----------------|------------------|
| 1. Clamping strap ratchets | 5. Vent hose | 8. Accumulator |
| 2. Quick-disconnect plates | 6. Level sensor | 9. Handle |
| 3. Transfer hoses | 7. Feed hoses | 10. Junction box |
| 4. 10-tube connectors | | |

Color Change: Reclaim-to-Non-Reclaim

Use this procedure when changing to a powder that you will not reclaim. The overspray will be collected in a new color module and pumped by the transfer pumps into a scrap drum. To supply powder to the spray guns, you can use a feed hopper attached to the color module, or an unattached, portable feed hopper.

New Color Module/Feed Hopper Assembly

1. Complete all the steps under *Old Color Removal* in the *Reclaim-to-Reclaim* procedure.
2. Perform steps 1 through 7 under *New Color Installation* in the *Reclaim-to-Reclaim* procedure.
3. See Figure 3-7. Connect the transfer hoses (3) to a scrap drum (2). Connect a vent hose (1) from the scrap drum to a color-module vent stub.
4. Install new feed hoses (4) between the powder pumps and the spray guns, or use hoses that have already been used with the new color.
5. Set the transfer-pump selector switch.
 - a. Set the switch to MANUAL to continuously pump the collected powder from the color module to the scrap drum.
 - b. Set the switch to OFF if you want to wait until you are done spraying before you pump the powder into the scrap drum.
6. Perform the *Startup after Color Change* procedure on page 3-15.




Figure 3-7 New Color Module/Feed Hopper Assembly (Horizon 400 Shown)

- | | | |
|---------------|-------------------|---------------|
| 1. Vent hose | 3. Transfer hoses | 4. Feed hoses |
| 2. Scrap drum | | |

New Color Module with Portable Feed Hopper

1. Complete all the steps under *Old Color Removal* in the *Reclaim-to-Reclaim* procedure.
2. Perform steps 1 through 5 under *New Color Installation* in the *Reclaim-to-Reclaim* procedure.
3. See Figure 3-8. Position the portable feed hopper (3) so you can connect the feed hoses (5) from the powder pumps (2) to the spray guns.
4. Connect the 10-tube connectors (4) to the receptacles on the feed hopper.
5. Install a vent hose (1) between the feed hopper and a color-module vent stub.
6. Connect the transfer hoses to a scrap drum (6). Connect a vent hose from the scrap drum to a color-module vent stub.
7. Connect the feed-hopper ground strap to the booth base. Make sure all other equipment is connected to ground.
8. Install new feed hoses (5) between the powder pumps and the spray guns, or use hoses that have already been used with the new color.
9. Set the transfer-pump selector switch to MANUAL or OFF.
 - a. Set the switch to MANUAL to continuously pump the collected powder from the color module to the scrap drum.
 - b. Set the switch to OFF if you want to wait until you are done spraying before you pump the powder into the scrap drum.
10. Perform the *Startup after Color Change* procedure on page 3-15.




Figure 3-8 New Color Module with Portable Feed Hopper (Horizon 400 Shown)

- | | | |
|-----------------|----------------------|---------------|
| 1. Vent hose | 3. Feed hopper | 5. Feed hoses |
| 2. Powder pumps | 4. 10-tube connector | 6. Scrap drum |

Startup after Color Change

Before starting the system, make sure all air tubing, hoses, electrical cables, and ground straps have been reconnected.

1. Turn on the system electrical power and compressed air supply.
2. Start the exhaust fan.
3. Fill the feed hopper $\frac{2}{3}$ full of powder. Adjust the hopper fluidizing-air regulator until the powder boils gently. Wait 5–10 minutes for the

powder to fluidize.

4. Start spraying parts.
5. Adjust the powder-pump air pressures and gun voltages, if necessary (different colors or powders may require different settings).

Equipment	Recommended Initial Settings	Final Setting	Changes
Primary Air Pressure (plant supply)	6.2 bar (90 psi)		
Collector Module			
#1 Fluidizing	0.7 bar (10 psi)		
#2 Fluidizing	0.7 bar (10 psi)		
#3 Fluidizing	0.7 bar (10 psi)		
#4 Fluidizing	0.7 bar (10 psi)		
#1 Transfer Pump	1.0 bar (15 psi)		
#2 Transfer Pump	1.0 bar (15 psi)		
#3 Transfer Pump	1.0 bar (15 psi)		
#4 Transfer Pump	1.0 bar (15 psi)		
Feed Hopper — Reclaim			
Fluidizing	0.5 bar (8 psi)		
Vent-Assist	0.5 bar (8 psi)		
Feed Hopper — Non-Reclaim			
Fluidizing	0.5 bar (8 psi)		
Vent-Assist	0.5 bar (8 psi)		
Pulse Manifold			
Air pressure	3.5–4.1 bar (50–60 psi)		
Rotary Sieve			
Flowmeters	100 SCFH		
Bearing Air Pressure	1.7 bar (25 psi)		
Vent-assist Air Pressure	0.5 bar (8 psi)		
Vibratory Sieve			
Air Pressure	3.5 bar (50 psi)		
Pulse Valve Timers			
Delay (OFF) timer	90.0 sec		
Duration (ON) timer	0.07 sec		
Transfer Pump Timers			
Delay timer	60 sec		
Maximum Filter Pressure			
Cartridge filters	4–6-in. wc		
Final filters	1-in. wc		

Section 4

New Cartridge Filter Seasoning



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



WARNING: Wear an approved respirator or dust mask, and safety glasses or goggles when handling powder. Avoid getting powder on your skin. Wash off powder with soap and water only.

Introduction

This section describes procedures for seasoning new cartridge filters. Seasoning is not required, but can improve performance and extend the life of the filters. Season the cartridge filters whenever you install a new color module with new cartridges, or when you install new cartridges in an existing color module.

Seasoning with a Manual Operated Fan Damper

1. Remove the final filters.
2. Turn on the exhaust fan.
3. Open the seasoning slide gates.
4. Measure the face velocity at the booth openings with a hand-held velometer.
5. Close the fan damper until the average face velocity is 30–38 m/min (100–125 fpm).
6. Disconnect the powder feed hoses from the spray guns. Secure the hoses to the gun mounting bars. Do not point the hoses directly at the cartridge filters.
7. Turn on the gun control units. Do not turn on the electrostatic voltage.
8. Adjust the flow rate and atomizing air regulators on each gun control console to approximately 1.4 bar (20 psi). Raise or lower the air pressure until you obtain a light flow of powder from the feed hoses.

Seasoning with a Manual Operated Fan Damper *(contd)*

9. Monitor the face velocity. Open the fan damper a little at a time to keep the face velocity at 30–38 m/min (100–125 fpm).
10. When the damper is fully open, or, after opening the fan damper slightly, the face velocity no longer decreases as more powder accumulates on the cartridges, start pulsing the filters. Set the pulse air pressure to approximately 2.75 bar (40 psi).

NOTE: Pulse the cartridges for a few minutes, then stop. Let powder build up on the cartridges for a few minutes, until the pressure drop across the cartridges increases. Start pulsing the cartridges again.

11. Continue pulsing the cartridge filters. Increase the pulse pressure in 0.3 bar (5 psi) increments every 20 minutes until it reaches 4.1 bar (60 psi).
12. Shut off the powder flow.
13. Close the slide gates.
14. Adjust the fan damper until the average face velocity is 30–38 m/min (100–125 fpm) through all enclosure openings.

Seasoning with a Manual AMS System

Use the *Seasoning with a Manually Operated Fan Damper* procedure, along with the following instructions.

Set the AMS controller to provide an average face velocity of 30–38 m/min (100–125 fpm). Adjust the controller as powder builds up on the filters. Start pulsing when you approach the setting limits, or when the face velocity fails to decrease as powder continues to flow.

Seasoning with an Automatic AMS System

Use the *Seasoning with a Manually Operated Fan Damper* procedure, along with the following instructions.

Set the AMS controller to provide an average face velocity of 30–38 m/min (100–125 fpm). Start the powder flow. Although the AMS system should automatically keep the face velocity constant, check it periodically. When the fan rpm approaches the upper limits, start pulsing the cartridge filters. Set the pulse air pressure to 2.75 bar (40 psi). The AMS system will automatically reduce the fan rpm to keep the air flow constant. Continue the powder flow and cartridge filter pulsing for approximately one hour.

Seasoning Without a Fan Damper or AMS System

1. Remove the final filters.
2. Open the seasoning slide dampers.
3. Start the exhaust fan. Measure the face velocity at the enclosure openings with a hand-held velometer. Record your readings.
4. Disconnect the powder feed hoses from the powder spray guns. Secure the hose to the gun mounting bars. Do not point the hoses directly at the cartridge filters.
5. Turn on the gun control units. Do not turn on the electrostatic voltage.
6. Adjust the flow-rate and atomizing air regulators on each gun control unit to approximately 1.4 bar (20 psi). Raise or lower the pressures until you obtain a light flow of powder from the feed hoses.
7. Take readings with the velometer until the face velocity decreases to $\frac{1}{2}$ of the initial values recorded in step 3.
8. Adjust the pulse air pressure to 1.7 bar (25 psi) and start pulsing the cartridge filters.
9. Continue to take velometer readings until the face velocity again reaches $\frac{1}{2}$ of the value recorded in step 3.
10. Adjust the pulse air pressure to 2.75 bar (40 psi).
11. Repeat step 9.
12. Adjust the pulse air pressure to 4.1 bar (60 psi). Adjust the gate valve so the pressure decreases during a pulse and slowly builds back to 4.1 bar (60 psi) just before the next pulse. This will prevent starving the powder pumps of air during pulses.
13. Close the seasoning slide gates. The face velocity should rise to 30–38 m/min (100–125 fpm) and remain steady.
14. Shut off the exhaust fan and install the final filters.
15. Check the face velocity. If it is below 30 m/min (100 fpm), contact your Nordson representative.

Section 5

Maintenance



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Daily Maintenance

Perform these procedures daily to keep your system clean and functioning properly.

Cleaning

Perform this procedure daily and when changing powder color or type.



WARNING: Wear an approved respirator and safety glasses or goggles when performing maintenance or cleaning operations. Obtain and read Material Safety Data Sheets for each powder used.

1. Turn off the automatic-gun master-control unit(s) and manual-gun control units.
2. Turn on the exhaust fan.
3. Disconnect the powder-feed hoses from the powder pumps. Blow the powder out of the hoses and spray guns with compressed air.
4. Ground the gun electrodes and clean the spray guns according to the instructions in the spray gun manuals.
5. Clean the enclosure roof, walls, and floor with a rubber squeegee. Push the collected powder into the color module.
6. Remove the remaining powder residue from the enclosure with an air-powered vacuum and a soft brush attachment. Wipe down all surfaces with a damp, lint-free cloth (do not use tack cloths). If you remove the color module, clean the floor inlet and surrounding area.
7. Turn off the exhaust fan.
8. Clean the operator's platform and the floor around the booth.

Daily Equipment Maintenance

Use the guidelines listed in Table 5-1 to establish a daily maintenance schedule for your Horizon powder coating system.

Table 5-1 Daily Maintenance

Equipment	Procedure
Accumulators and Vent Hoses	Vacuum out the accumulators and blow the powder out of the vent hoses with compressed air.
Air Dryers	Refer to your air dryer manual for maintenance procedures and schedules.
Air Velocity	Measure the air velocity at all booth openings with a velometer. Minimum velocity is 30 m/min (100 fpm).
Compressed Air Supply	<p>NOTE: The air dryer should remain on at all times to prevent moisture from accumulating in the compressed air system.</p> <p>Hold a clean, white cloth under the drop leg and open the drop-leg drain valve. Water, oil, or other contaminants will stain the cloth. Eliminate any source of contamination. Drain the filters and separators and check the filter elements. Check all air pressure regulator settings.</p>
Fan Section	<p>Remove the final filters and inspect the fan compartment. Vacuum out any powder. If significant amounts of powder have accumulated in the fan compartment, the cartridge filters may be leaking. Refer to the <i>Troubleshooting</i> section for instructions.</p> <p>Inspect the V-belts. Replace cracked or worn belts.</p>
Filters	<p>Check the final-filter differential pressure gauge. It should read between 1 and 2.5 inches of water (wc). Make sure no powder is leaking from around the filter gaskets or through the face.</p> <p>Check the cartridge-filter differential pressure gauge. It should read between 4 and 6 inches of water (wc). Check the pulse valve timing.</p>
Flame Detector System	Check the detector sensors every four hours and clean the lenses, if necessary. Make sure air is being supplied to the sensors. Make sure the detector system is operating properly.
Gun Movers (Oscillators and Reciprocators)	Each shift, make sure the gun movers are stroking smoothly and at the proper speed. Make repairs and adjustments if necessary. Lubricate the gun movers as described in their manuals.
Powder Guns	Disassemble and clean the spray guns according to the instructions in their manuals.
Powder Pumps	Disassemble and clean the pumps according to the instructions in their manuals. Replace worn parts.
Rotary Sieves	<p>Empty the scrap pail.</p> <p>Open the sieve housing and clean the rotor and screen with a soft brush. Replace the screen if it is damaged.</p> <p>Check the bearing air pressure and flow rate. Check the vent-assist air pressure. Refer to your sieve manual for more information.</p>
Continued...	

Equipment	Procedure
Transfer Pumps	<p>Disconnect the transfer hoses from the pumps. Blow the powder out of the hoses with compressed air.</p> <p>Remove the transfer pumps from the adapters. Blow out the adapters and pickup tubes.</p> <p>Disassemble the pumps. Clean the parts with a low-pressure air gun and a clean cloth. Replace any worn or damaged parts.</p>
Vibratory Sieve	<p>Open the hopper lid. Disconnect the ground clip and remove the screen from the sieve. Clean the screen and replace it if it is damaged. Reconnect the ground clip to the screen after reinstalling the screen.</p>
Workpiece and Conveyor Grounds	<p>WARNING: An ungrounded or poorly grounded workpiece, hanger, or conveyor can cause electrical arcing. If arcing is observed, shut down the system immediately. Correct the cause before resuming operations. Refusing to observe this warning could result in a fire or explosion, causing property damage and possible personal injury or death.</p> <p>Make sure all workpieces are grounded through the hangers and conveyor. The resistance between the workpieces and the hangers, and the hangers and ground, must be less than one megohm. Use a megohm meter to check resistances. You will get better transfer efficiency and workpiece coverage at 500 ohms or less. Clean the hangers regularly.</p>

Weekly Maintenance

Use the guidelines listed in Table 5-2 to establish a weekly maintenance schedule for your Horizon powder coating system.

Table 5-2 Weekly Maintenance

Equipment	Procedure
Air Knife Blower (Optional Equipment)	Inspect and clean the air intake screen.
Booth Enclosure	<p>Turn on the exhaust fan and vacuum the enclosure roof, walls, and floor with a soft brush attachment. Wipe down the enclosure with damp, lint-free cloths. Clean the booth exterior, all attached equipment, and the spray room.</p> <p>Check the panels for cracks, damage and dirt. Clean dirt and powder from the exterior. Seal any cracks or replace the panels. Make sure the roof supports are secure.</p>
Color Module	<ol style="list-style-type: none"> 1. Start the exhaust fan and activate the pulse valves to blow off as much powder as possible off the cartridge filters. Pump the powder out of the color module. 2. Inspect the cartridge filter media and gaskets. Check the interior of the cartridges for powder. Powder inside the cartridges indicates leaking. Contamination of the media indicates problems with the air filters or dryer. Replace the filters if they are leaking or contaminated. Do not vacuum the cartridge filters. 3. Disconnect the transfer hoses from the transfer pumps. Blow the powder out of the hoses with compressed air. Remove the transfer pumps and clean them as described in their manuals. Remove and clean the pump adapters and pickup tubes. Replace any worn parts. 4. Vacuum the color module interior. Check the fluidizing plates. If they are stained, the air supply could be contaminated by oil or moisture. Replace the fluidizing plates if they are contaminated. 5. Check the pulse valves and nozzles, mouth gasket, limit switch, clamping straps, and skirt seal. Replace any damaged components.
Feed Hoppers	Remove the powder from the hopper. Vacuum the interior. Check the fluidizing plate. If the plate is stained, the air supply could be contaminated by oil or moisture. Check the air dryer and air filters. Replace the fluidizing plate if it is contaminated.
Powder Spray Guns and Cables	Clean the spray guns. Perform electrostatic resistance checks as described in the spray gun and gun control unit manuals.
Powder Pumps and Feed Hoses	Disassemble the pumps and clean them according to the instructions in their manuals. Replace any worn or damaged parts. Blow out the feed hoses with compressed air. Replace damaged or clogged hoses.

Periodic Maintenance

Use the guidelines listed in Table 5-3 to establish a periodic maintenance schedule for your Horizon powder coating system.

Table 5-3 Periodic Maintenance

Equipment	Procedure
Air Dryer	Check the air dryer operation. Refer to your air dryer manual for maintenance procedures and schedules.
Bearings	Every six months, lubricate the fan shaft bearings with two shots of No. 2 lithium grease from a grease gun. The grease fittings are on the front of the fan section, between the final filters.
Differential Pressure Gauges	Observe and record the differential pressure gauge readings. Pressure drop across cartridge filters: 4–6-in. wc Pressure drop across final filters: 1–2.5-in. wc If the pressure drop across the cartridge filters exceeds 6-in. wc, the filters are clogged. If the pressure drop across the final filters exceeds 2.5-in. wc, the system will shut down.
Electrical Connections	Check all terminal blocks and junction boxes for loose wires. Tighten any loose connections and inspect the system wiring. Replace any wires with damaged insulation.
Exhaust Fan V-belts	Every six months, adjust the tension of the exhaust fan V-belts. You should not be able to deflect the belts more than 13–19 mm (0.5–0.75 in.) (one belt diameter).
Gaskets	Inspect all gaskets and seals for damage. Replace them if they are damaged.
Guns and Cables	Perform electrostatic resistance checks as described in the spray gun, and gun control unit or electrostatic power unit manuals.
Powder Feed and Transfer Hoses	Disconnect the hoses from the pumps. Blow the powder out of the hoses with compressed air. Never blow air through the hoses toward the pumps. Replace the hoses if they are clogged with impact-fused powder.
Rotary Sieves	AZO sieves: Every three months, lubricate the lip seals with a white lithium grease as described in your AZO sieve manuals. Nordson sieves: Refer to your sieve manual for instructions.
Wheels and Casters	Lubricate the casters and flanged wheel bearings (roll/on-roll/off booths) with 2 shots of white lithium grease every six months.

Maintenance Check List

Activity	Each Shift	Daily	Weekly	Monthly	Color Change
Cleaning					
Accumulator		✓			
Booth enclosure		✓	✓		✓
Color module			✓		✓
Fan compartment			✓		✓
Feed and transfer hoses	✓				✓
Fire detector head lenses*	✓				
Gun pumps	✓	✓	✓		✓
Guns	✓		✓		✓
Rotary sieve	✓	✓			✓
Transfer pumps	✓	✓			✓
Vent hoses		✓			✓
Vibratory sieve	✓	✓			✓
Resistance Checks — Guns and Cables			✓		
Visual Checks					
Air supply drop leg		✓			
Air dryer drain		✓			
Cartridge filter differential-pressure gauge	✓				
Electrical connections			✓		
Exhaust fan V-belts				✓	
Final filter differential-pressure gauge	✓				
Fire detector sensors	✓				✓
Gaskets			✓		✓
Gun movers	✓				
Powder levels	✓				
Workpiece clearance**	✓				
Workpiece grounding	✓				✓
* Every 4 hours.					
** Clearance should be monitored continuously.					

Lubrication	Every Three months	Every Six Months
AZO rotary-sieve lip seals	✓	
Fan and motor bearings		✓

Section 6

Troubleshooting



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Introduction

These procedures cover only the most common problems that you may encounter. If you cannot solve the problem with this information, contact your local Nordson representative for help.

No.	Problem	Page
1.	Spray guns are surging or spitting; powder flow is inadequate or intermittent	6-2
2.	Problems with coating uniformity, edge coverage, film build, wrap, or penetration into recesses	6-2
3.	Powder not transferring from color module to feed hopper	6-3
4.	Powder not fluidizing, or clouds of powder erupting from surface	6-4
5.	Final filters clogged; powder in fan compartment	6-5
6.	Cartridge filters clogged	6-5
7.	System shuts down or will not start	6-6
8.	Sieve not screening powder	6-6
9.	Sieve scrap bucket filling up with powder	6-6
10.	Powder escaping from booth openings	6-7

Troubleshooting Procedures

Problem	Possible Cause	Corrective Action
1. Spray guns are surging or spitting; powder flow is inadequate or intermittent	Powder in feed hopper inadequately fluidized	Adjust the fluidizing air pressure. The powder should be gently boiling. Refer to problem 4.
	Low powder level in feed hopper	Add powder to the feed hopper. Refer to problem 3.
	Powder pump venturi nozzles or throats worn; adapter O-rings leaking; pump or pickup tube clogged	Clean the pump and pickup tube. Replace any worn parts. Replace the adapter O-rings, if they are damaged.
	Obstruction in powder feed hose	Disconnect the feed hose from the pump. Blow the powder out of the hose with compressed air. Make sure the hose is clear. Eliminate kinks or severe bends in hose. Hose should be no longer than 7.6 m (25 ft) with a maximum 2.7-m (9-ft) vertical rise.
	Severe tribo-charging in powder feed hose	Contact your Nordson Corporation representative for a suitable hose material. Contact your powder supplier.
	Obstruction in spray gun	Clean the spray gun. If you are using conical nozzles, make sure there is a 3 mm (0.125 in.) or larger gap between the deflector and the nozzle.
	Flow rate or atomizing air pressure incorrect	Refer to the spray gun and control unit manuals for recommended air pressures and ratios.
2. Problems with coating uniformity, edge coverage, film build, wrap, or penetration into recesses	Poor workpiece grounding	Resistance from the workpiece to the ground must be less than one megohm. For best results, resistance should not be more than 500 ohms. Clean the workpiece hangers, fixtures, and hooks if necessary. Check the conveyor ground.
	Gun placement incorrect	Position the spray guns 254–355 mm (10–14 in.) from the workpieces. Stagger the spray guns 304 mm (12 in.) apart vertically and 381 mm (15 in.) apart horizontally to avoid fan pattern and electrostatic field overlap. Contact your Nordson Corporation representative for advice.
Continued...		

Problem	Possible Cause	Corrective Action
	Fan damper open too far, powder being pulled away from workpieces	Close damper to decrease air flow through the booth. Refer to <i>Fan Damper Adjustment</i> in the <i>Operation</i> section.
2. Problems with coating uniformity edge coverage, film build, wrap, or, penetration into recesses (contd)		<i>Continued...</i>
	Powder pump flow-rate and atomizing air pressure incorrect	Refer to the spray gun and control unit manuals for the recommended air pressures and ratios.
	Electrostatic voltage (kV) or AFC setting incorrect for workpieces being coated	Adjust the voltage to 90–100 kV for large flat surfaces and 60–75 kV for recesses. Never set the voltage below 60 kV. Refer to the gun and control unit manuals for the recommended voltage, AFC, and air pressure settings and ratios.
	Wrong nozzles being used	Use flat spray nozzles for large, regular-shaped workpieces. Use conical nozzles for deep recesses and most manual touch-ups.
	Powder feed problems	Refer to problem 1.
3. Powder not transferring from color module to feed hopper	Transfer pump air pressure too low	Increase the air pressure.
	Transfer pump venturi nozzle clogged or throat worn	Clean the pump and replace worn parts.
	Transfer hose plugged	Blow the powder out of the hose with compressed air.
	Sieve screens clogged, or motor running in wrong direction	Clean the sieve screens. Refer to the <i>Reversing Motor Direction</i> procedure in this section.
	Accumulator plugged	Clean out the inlet ports. Clean the accumulator interior.
	Accumulator vent-assist air pressure too high	Reduce the vent-assist air pressure.
	Transfer pump delay too long, level sensor sensitivity adjusted incorrectly, or sensor failed	Decrease the transfer pump delay. Calibrate the level sensor. Replace the level sensor if the problem continues.
	Powder in color module not fluidized. Deep hole in powder around pickup tube	Increase the fluidizing pressure. If the problem continues, go to the next cause.
	Powder damp or contaminated; cannot be fluidized or pumped	Refer to problem 4.
<i>Continued...</i>		

Troubleshooting Procedures *(contd)*

Problem	Possible Cause	Corrective Action
4. Powder not fluidizing, or clouds of powder erupting from surface	Fluidizing pressure too low or too high	Check the powder in the hoppers. Increase the fluidizing air pressure until the powder is gently boiling. Decrease the pressure if clouds of powder are erupting from the surface.
	Moist or oil-contaminated powder	Open the drain valve at the air-supply drop leg and check the air supply for water or oil. Check the filters, separators, and air dryer. Replace the powder in the hoppers. Refer to the next cause.
	Air leaking from fluidizing pan gasket instead of diffusing through fluidizing plate, or contaminated air plugging pores in fluidizing plates	Check for air leaks around the fluidizing pan gaskets. If leaks are found, remove the pan and replace the gasket. If fluidizing air pressure increases or decreases abruptly, remove the powder from the hoppers and inspect the fluidizing plates for stains, discoloration, or polished surfaces. Replace the fluidizing plates if they are contaminated or plugged.
	Transfer pumps or hoses are plugged, or fluidizing plate in color module or feed hopper is cracked	Clean the transfer pumps and replace worn parts. Blow the powder out of the transfer hoses with compressed air. Make sure the hoses are clear. Check the fluidizing plate and replace it if it is cracked.
	Incorrect ratio of reclaimed-to-new powder	Change the transfer-pump air pressure to increase or decrease the transfer rate. Add new powder to hopper. The powder supply should be no more than 3 parts reclaim-to-1 part new powder.
	Uneven distribution of powder in hopper	Increase the fluidizing pressure. Check the powder and the fluidizing plate for contamination as previously described.
<i>Continued...</i>		

Problem	Possible Cause	Corrective Action
5. Final filters clogged, powder in fan compartment	Leaking cartridge filter gaskets, or hole in filter media	Make sure the gaskets are sealing correctly. If you can slip a 0.4 mm (0.015-in.) feeler gauge between the gasket and the sealing surface, tighten the tension screws to compress the gaskets. Refer to the <i>Repair</i> section for instructions. If the gaskets continue to leak, remove the cartridges. Clean and inspect the gaskets, sealing surfaces, and filter media. Replace the cartridges if the gaskets or filter media are damaged. Refer to the <i>Repair</i> section. Replace clogged final filters.
	Leak in front plate of color module	Locate and seal any leaks with RTV sealant.
6. Cartridge filters clogged	Pulse air pressure inadequate	Increase the pulse air pressure or volume. Decrease the pulse timer delay (off time).
	Powder too fine or contaminated	Reduce the ratio of reclaim-to-new powder. Check the powder particle size. Replace contaminated powder and fix the source of contamination.
	Pulse valves out of position	Position the valves as described in the <i>Repair</i> section.
	Timer board settings incorrect	Adjust the timer board settings as described in the <i>Operation</i> section.
	Pulse valve or solenoid valves clogged or malfunctioning	Open the pulse valve timer panel. If you do not hear a pulse each time a LED on the timer panel lights, the solenoid valve connected to that LED may have failed, or the pulse valve connected to the solenoid valve may have failed. Follow these steps: 1. Check the wiring to the solenoid valve. 2. Check for leaking compressed air at the pulse valve. Repair or replace as necessary. 3. Replace the solenoid valve if necessary.
	Powder level in color module too high	Pump out excess powder.
	Valve wiring failure or pulse valve spring failure	Replace the valves.
Continued...		

Troubleshooting Procedures *(contd)*

Problem	Possible Cause	Corrective Action
7. System shuts down or will not start	Flame detector system sees a flame or spark, or is malfunctioning	Check the inside of the enclosure and color module, the detector head aim, and the workpiece and conveyor grounds Follow the troubleshooting procedures in the flame detector system manual.
	Final filters clogged	Locate the source of powder leakage and correct the problem. Refer to problem 5.
	Color module not closing limit switch	Tighten the color module clamping straps, or reposition the limit switch. If the problem continues, replace the switch.
	Final filter pressure switch failed	Adjust the setting or replace the switch.
	Air dryer not operating, or interlock not activated	Start the air dryer. Follow the troubleshooting procedures in the dryer manual. Check the interlock circuit. (Air dryer interlock not used after April 2009.)
	Fuse(s) blown	Check the fuses in the system electrical panel. Correct the electrical problem, and replace the fuse(s).
	Electrical failure	Trace the circuits and correct the problem.
8. Sieve not screening powder	Screen clogged or damaged	Clean or replace the screen.
9. Sieve scrap bucket filling up with powder	Scrap bucket lid not sealed	The lid must be airtight. Tighten the lid. Check the scrap hose connections.
	Screen clogged	Clean or replace the screen.
	Hopper or accumulator vents clogged or hose kinked	Clean the vents, and check the hoses.
	Vent-assist air pressure too low	Increase vent-assist air pressure. Refer to <i>Vent-Assist Air Pressure Adjustment</i> in the <i>Operation</i> section.
<i>Continued...</i>		

Problem	Possible Cause	Corrective Action
10. Powder escaping from booth openings	Cartridge filters clogged	If the differential pressure gauge shows more than 6-in. wc, refer to problem 6.
	Cross drafts interfering with exhaust fan draw	Check for cross drafts at all enclosure openings. Eliminate or divert drafts.
	Fan damper closed	Open the fan damper to increase the air flow through the enclosure. Refer to <i>Fan Damper Adjustment</i> in the <i>Operation</i> section.
	Workpieces entering booth are too hot	Cool the workpieces before moving them into the booth. The workpiece temperature should not exceed 49°C (120 °F).
	Powder gun output exceeds booth containment capability	Reduce the powder flow and/or the number of the spray guns.
	Booth openings too large	Close or decrease the size of the openings.
	Fan section slide dampers open	Close the two slide dampers on the front of the fan section.
	Workpieces too large for booth	Contact your Nordson Corporation representative.
	Spray guns too close to entrance and exit vestibules or openings	Move the spray guns farther away from the vestibules or openings.
	Fan rotation backward	Reverse the rotation of the motor. Refer to the <i>Reversing Motor Direction</i> procedure in this section.
	Air leaks around color module	Inspect the D-gasket and replace it if it is damaged. Tighten the clamping straps to compress the D-gasket. Check the skirt seal. Make sure it is sealing properly around all four sides. Refer to <i>Installing a New Color Module and Feed Hopper</i> in the <i>Operation</i> section. Replace the skirt if it is damaged.

Reversing Motor Direction

Improperly connecting the exhaust fan and sieve motor starters will cause them to rotate in the wrong direction. If the exhaust fan is rotating in the wrong direction, powder will be blown out of the enclosure. If the sieve rotates in the wrong direction, powder will back up in the accumulator. Use the following procedures to check and correct, if necessary, fan and sieve rotation.

Exhaust Fan Motor

1. Turn on system electrical power.
2. Start the exhaust fan motor.
3. Observe the direction of fan rotation. The fan should rotate in the direction indicated by the yellow arrow on the front of the fan section. The fan shaft should rotate clockwise when viewed from the sheave (pulley) end (from above the fan). If the rotation is backward, go to the next step.



WARNING: Even with the disconnect switch in the off position, the terminals at the top of the switch are still live. Do not touch them. Failure to observe this warning could result in serious injury or death.

4. Shut off system electrical power. Open the electrical panel door and reverse any two wires (L1, L2, or L3) connected to the fan motor starter (M407). Close the electrical panel door.
5. Turn on electrical power. Start the fan and check the rotation direction.

Sieve Motor

1. Check your sieve manual for the proper motor rotation direction. If it is rotating in the wrong direction, perform the next step.



WARNING: Even with the disconnect switch in the off position, the terminals at the top of the switch are still live. Do not touch them. Failure to observe this warning could result in serious injury or death.

2. Shut off system electrical power. Open the electrical panel door. Reverse any two wires (L1, L2, or L3) connected to the sieve motor starter (M412). Close the electrical panel door.
3. Restore system electrical power. Start the sieve and check the rotation direction.

Schematics

Pneumatic Schematic




Figure 6-1 Pneumatic Schematic

Electrical Schematic




Figure 6-2 System Electrical Schematic (1 of 4)




Figure 6-3 System Electrical Schematic (2 of 4)



Electrical Schematic (contd)

Figure 6-4 System Electrical Schematic (3 of 4)



Section 7

Repair



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Introduction

NOTE: The Horizon 400 powder coating systems are FM (Factory Mutual) approved. Use only approved Nordson replacement parts. Using unapproved parts may void FM approval of your system. Contact your Nordson representative for more information.

The procedures and illustrations in this section apply to both the Horizon 200 and 400 powder coating systems. Differences between the booths are noted in the procedures.

Final Filter Replacement



WARNING: Wear a NIOSH-approved respirator or dust mask and safety glasses or goggles when handling powder or cleaning powder off equipment. Avoid getting powder on your skin. Wash with soap and water only.

1. Shut off the exhaust fan. Shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.
2. See Figure 7-1. Unscrew and remove the threaded knobs (3) and brackets (2) securing the final filters (1) to the fan compartment.
3. Remove the old filters and discard them.
4. Check the interior of the fan compartment. If you see large amounts of powder inside the compartment, powder is leaking through the cartridge filters or mounting plate. Clean the fan compartment and fix the leak before starting the system.

NOTE: Do not use damaged filters.

5. Remove the new filters from their cartons. Inspect the filter housings, gaskets, and media for damage.

Final Filter Replacement *(contd)*

6. Insert the new filters into the openings.
7. Install the brackets over the threaded studs. Thread the knobs onto the studs.
8. Tighten the knobs to compress the filter gaskets slightly. Do not overtighten the knobs.
9. Restore system electrical power. Start the exhaust fan and check for leaks around the filter gaskets.




Figure 7-1 Final Filter Replacement

1. Final filters

2. Brackets

3. Knobs

Cartridge Filter Replacement

Use this procedure to replace the cartridge filters.



WARNING: Wear a NIOSH-approved respirator or dust mask and safety glasses or goggles when handling powder or cleaning powder off equipment. Avoid getting powder on your skin. Wash with soap and water only.

Cartridge Filter Removal

1. Remove the color module from under the base as described in the *Reclaim-to-Reclaim Color Change* procedure in the *Operation* section.
2. See Figure 7-2. Remove the grates (1) and baffle (2).
3. Loosen the jam nuts (8) on the torque screws (7). Turn the screws counterclockwise until the push plates (6) retract against the side of the color module.
4. Remove the screws and washers (9, 10, 11) securing the tension rods (5) to the color module. Save them for reuse.
5. Remove the tension rods and save them for reuse.
6. Remove the cartridge filters (3, 4) from the color module.

Cartridge Filter Installation



CAUTION: Do not use any cartridge filters other than those specified for your system. Using unapproved cartridge filters could seriously affect the operation and performance of your system, as well as void FM approvals. Do not use damaged filters.

Remove the new closed-end and open-end cartridge filters from the shipping boxes. Carefully inspect the new cartridge filters for

- cuts or other damage to the rubber gaskets
 - bent or dented end caps
 - holes or other damage to the filter media
1. See Figure 7-2. Thoroughly clean the inside back wall of the color module around the cartridge filter openings, to provide a clean surface for the filter gaskets.
 2. Clean the push plates (6).
 3. Place the closed-end cartridge filters (3) on the support rods, with the closed end toward the push plates. Push the filters against the push plates.
 4. Place the open-ended cartridge filters (4) on the support rods with the gaskets on the filters facing the round outlet holes in the color module.
 5. Install the tension rods (5) with the screws and washers (9, 10, 11).

Cartridge Filter Installation (contd)



CAUTION: Do not overtighten the torque screws, or you may damage the cartridge filters.

6. Tighten the torque screws (7) until the cartridge filter gaskets compress to 11-mm (0.5-in.) thick.
7. Tighten the jam nuts (8) against the weld nuts to lock the torque screws in place.
8. Install the baffle (2) and grates (1).
9. Install the color module as described in *Installing a New Color Module and Feed Hopper* in the *Operation* section.




Figure 7-2 Cartridge Filter Replacement (Horizon 400 Shown)

- | | | |
|---------------------------------|------------------|------------------|
| 1. Grates | 5. Tension rods | 9. Screws |
| 2. Baffle | 6. Push plates | 10. Lockwashers |
| 3. Closed-end cartridge filters | 7. Torque screws | 11. Flat washers |
| 4. Open-end cartridge filters | 8. Jam nuts | |

Color Module Fluidizing Plate Replacement

Replace the fluidizing plates if they become contaminated by dirty air, clogged with fine powder particles, or damaged.



WARNING: Wear a NIOSH-approved respirator or dust mask and safety glasses or goggles when handling powder or cleaning powder off equipment. Avoid getting powder on your skin. Wash with soap and water only.

Preparation

1. Start the transfer pumps and pump the powder in the color module hoppers back into the feed hopper. If the powder is contaminated, pump it into a scrap container.
2. Remove the color module from under the fan section as described in the *Reclaim-to-Reclaim Color Change* procedure in the *Operation* section.
3. Remove the grates, baffle, transfer pumps, and cartridge filters from the color module. Refer to *Cartridge Filter Replacement* for instructions.
4. Remove all the powder from the color module hoppers. Vacuum the hoppers and fluidizing plates. Wipe them clean with damp, lint-free cloths. Do not use tack cloths.

Fluidizing Plate Replacement

1. See Figure 7-3. Unscrew the screws (6) on the clamping channels (5) about 6–10 mm (0.25–0.375 in.) to clear the fluidizing plate gaskets (1). Remove the outside clamping channels (5) (the inner clamping channels are welded to the color module).
2. Slide the fluidizing pans (4), fluidizing plates (2), and gaskets (1) out from under the color module.
3. Remove the fluidizing plates and baffles (3) from the pans. Discard the old plates and gaskets.
4. Clean the pans, baffles, diffuser plates, the removable and fixed clamping channels, and the color module hopper flanges.
5. Install the baffle plates in the fluidizing pans.
6. Install new fluidizing plates and gaskets on the pans.
7. Slide the pans and plates into the fixed clamping channels under the color module. Install the outside clamping channels over the color module and fluidizing pan flanges.
8. Tighten the clamping channel screws, using a torque wrench, to 2.8 N•m (2.1 ft-lb). Tighten the screws in a criss-cross pattern to avoid distorting the flanges.
9. Install the cartridge filters, baffle, grates, and transfer pumps. Install the color module under the base.




Figure 7-3 Color Module Fluidizing Plate Replacement (Horizon 400 Shown)

- | | | |
|----------------------|--------------------|----------------------|
| 1. Gaskets | 3. Baffles | 5. Clamping channels |
| 2. Fluidizing plates | 4. Fluidizing pans | 6. Screws |

Feed Hopper Fluidizing Plate Replacement

These instructions are for the Nordson HTM hopper used with the Horizon 400 booth. The Horizon 200 booth uses a HR-16-150 round hopper. Refer to the HR-16-150 hopper manual for fluidizing plate replacement instructions.



WARNING: Wear a NIOSH-approved respirator or dust mask and safety glasses or goggles when handling powder or cleaning powder off equipment. Avoid getting powder on your skin. Wash with soap and water only.

Preparation

1. Pump the powder from the feed hopper. Disconnect the powder feed hoses, transfer hoses, accumulator vent hose, and 10-tube quick-disconnects from the feed hopper, powder pumps, and accumulator.
2. Remove the level sensor from the feed hopper.
3. Unplug the sieve power and control cords (electrically driven sieves only). Disconnect the feed hopper ground wire.
4. Remove the screws, washers, and nuts securing the feed hopper to the direct vent plate. Roll the hopper to a clean work area.
5. Remove the remaining powder from the hopper and thoroughly clean the hopper, accumulator, and sieve.

Fluidizing Plate Replacement

1. See Figure 7-4. Block up the fluidizing pan (5) so the pan and hopper flanges will not bend when you start removing the clamping channels (3).
2. Loosen the screws (4) about 6–10 mm (0.25–0.375 in.) to clear the gasket (2). Remove the clamping channels.
3. Remove the pan and the fluidizing plate (1) from under the feed hopper.
4. Discard the old fluidizing plates and gaskets.
5. Clean the pan and the feed hopper flanges.
6. Position the new fluidizing plate and gasket on the pan.
7. Slide the pan under the hopper. Align the edges of the feed hopper flange, gasket, and pan flange evenly on all sides. Block up the pan to hold it in position.
8. Install the clamping channels over the pan and hopper flanges. Tighten the clamping channel screws to 2.8 N•m (2.1 ft-lb) in a criss-cross pattern to avoid distorting the flanges.
9. Attach the feed hopper to the color module. Connect the hoses, quick-disconnects, power cords, and ground wires. Install the level sensor.




Figure 7-4 HTM Feed Hopper Fluidizing Plate Replacement

- 1. Fluidizing plate
- 2. Gasket

- 3. Clamping channels
- 4. Screws

- 5. Pan

Vibratory Sieve Repair

1. Open the feed hopper lid. Reach inside the hopper and disconnect the sieve ground wire.
2. Remove the bolts and washers from the hopper cover.
3. Lift the cover (with the accumulator and sieve attached) off the hopper. Block up the cover to prevent damage to the screen assembly on the underside.
4. Unfasten the two toggle clamps and remove the screen basket. Discard any scrap powder and vacuum out the basket. If the basket is damaged, replace it. If no further disassembly of the sieve is necessary, reattach the basket and disregard steps 5 through 7.
5. To remove the air motor, disconnect the two air lines. Remove the bolt and spacer.
6. Remove the accumulator from the sieve and disassemble the rest of the sieve. Note the position of the screws, washers, nuts, rubber grommets or washers, and gaskets.
7. Clean powder residue from the accumulator and sieve parts.
8. Assemble the sieve and install it on the hopper. Cap any unused accumulator inlet tubes.

Pulse Valve Replacement

The pulse valves connect directly to the air manifold. To avoid connecting the valves to the wrong solenoids, remove and replace one valve at a time. Incorrect connections will cause the valves to open in the wrong order.



WARNING: Before performing the following procedure, shut off the system compressed-air supply and relieve the system air pressure. Shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.

1. Remove the color module from under the base as described in the *Reclaim-to-Reclaim Color Change* procedure in the *Operation* section.
2. See Figure 7-5. Disconnect the pilot air tubing (6) from the pulse-valve tube fitting (5).
3. Unscrew the pulse valve (7) from the manifold nipple.
4. Remove the tube fitting and nozzle (8) from the old valve. Wrap PTFE tape around the threads of the tube fitting and nozzle. Install the fitting and nozzle into the new valve.

5. Wrap PTFE tape around the threads of the manifold nipple. Screw the new valve onto the nipple. Position the valve so the final adjustment will tighten the threads and form an air-tight seal.
6. Adjust the valve so the centerline through the nozzle and valve is perpendicular (90°) to the manifold centerline (4).
7. Measure from the center of the nozzles to the outside edge of the fan compartment opening. This distance should be 35 cm (13.75 in.) If it is not, loosen the screws securing the manifold to the fan compartment and adjust the manifold position. Keep the manifold parallel to the fan compartment opening.
8. Connect the pilot air tubing to the pulse-valve tube fitting.




Figure 7-5 Pulse Valve Replacement (Horizon 400 Shown)

- | | | |
|-----------------|------------------------------|-----------------|
| 1. Screws | 4. Manifold centerline | 7. Pulse valves |
| 2. Lock washers | 5. Pulse-valve tube fittings | 8. Nozzles |
| 3. Flat washers | 6. Pilot air tubing | |

Fan and Fan Drive Repair

The fan and fan drive repair procedures cover the replacement of the following components:

- V-belt
- Sheaves and bushings
- Motor
- Fan
- Fan shaft and bearings

NOTE: Whenever any of the components in the fan drive are replaced, adjust the drive to the dimensions given in Figure 7-6 .

The Horizon 400 motor is mounted to the floor of the fan compartment. The Horizon 200 motor is mounted on the side of the two fan-shaft bearing supports. Removal and installation procedures for the V-belts, sheaves, motor, fan and inlet cone, and fan shaft and bearings are the same, except for the location of the motor.




Figure 7-6 Fan Drive Mounting Dimensions

V-Belt Replacement

Use this procedure to replace the V-belts on the Horizon 200 and 400 booths. In the Horizon 200 booth, the motor is mounted up on the side of the fan shaft bearing supports.



WARNING: Before performing the following procedures, shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.

1. Remove the final filters and access panels from the fan compartment.
2. See Figure 7-7. Loosen the nuts (5) so the motor can move on its mounting.
3. Turn the tension screw (3) on the end of the motor mounting plate (4) to move the motor toward the fan and loosen the V-belts (1).
4. Rotate the motor and roll the V-belts off the motor sheave (2) and fan sheave (6).
5. Roll the new belts onto the sheaves and seat the V-sections in the grooves. Use only properly sized, matched belts.
6. Turn the tension screw to move the motor away from the fan and tension the belts.
7. Check the belt tension by pressing on the belts midway between the sheaves. You should not be able to deflect the belts more than 13–19 mm (0.5–0.75 in.) or one belt diameter.
8. Tighten the nuts (5).
9. Install the access panels and final filters.




Figure 7-7 V-Belt Replacement

- | | | |
|-----------------|-------------------------|---------------|
| 1. V-belts | 3. Tension screw | 5. Nuts |
| 2. Motor sheave | 4. Motor mounting plate | 6. Fan sheave |

Sheave Replacement

This procedure covers fan and motor sheave replacement. See Figure 7-6 for the Horizon 400 fan drive mounting dimensions.



WARNING: Before performing the following procedures, shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.

Sheave Removal

1. Remove the V-belts as described in the *V-Belt Replacement* procedure.

NOTE: The cap screws shipped with the bushing are hardened. Do not use softer-grade screws to break the bushing loose from the sheave. The ends of the screws will flatten, preventing you from removing them from the bushing.

2. See Figure 7-8. Unscrew the three cap screws (1) and remove them from the unthreaded holes in the bushing (2). Thread the screws through the threaded holes in the bushing until they bottom out on the sheave (4) hub.
3. Tighten the screws evenly, a quarter turn at a time, until the bushing breaks loose from the sheave.

NOTE: Do not lubricate the sheave, bushing, or motor shaft.

4. Pull the sheave and bushing off the shaft (5). Remove the screws from the bushing. Inspect the sheave, bushing, and key (3), and replace them if they are damaged. Clean the parts that will be reused.

Sheave Installation

1. Install the sheave and bushing on the shaft. Line up the unthreaded holes in the bushing with the threaded holes in the sheave, and the keyway in the bushing with the keyway in the shaft.
2. Install the key into the keyway.
3. Install the three cap screws through the unthreaded holes in the bushing and thread them into the sheave.
4. Place a square across the top of the fan and motor sheaves. Slide the sheave and bushing up the shaft until both sheaves are parallel with each other and to the dimensions shown in Figure 7-6. If the sheaves are not parallel, the belts will wear prematurely.



CAUTION: Do not overtighten the screws. You could crack the sheave hub, or break off the screws. If the sheave pulls up against the bushing flange, the shaft diameter is too small.

5. Tighten the cap screws evenly, a quarter turn at a time, to the specifications in Table 7-1. This will pull the sheave and bushing together. Maintain a gap of 3–6 mm (0.125–0.25 in.) between the bushing flange and the sheave.

Table 7-1 Motor Bushing Cap Screw Torque and Pull Specifications

Screw Size (in.)	Torque N•m (ft-lb)	Open End or Socket Wrench	
		Length mm (in.)	Pull kg (lb)
$\frac{1}{4}$	12 (9)	102 (4)	12 (27)
$\frac{5}{16}$	20 (15)	152 (6)	14 (30)
$\frac{3}{8}$	40 (30)	152 (6)	27 (60)

6. Check again to make sure the motor and fan sheaves are parallel with each other and to the dimensions in Figure 7-6. If they are not, separate the bushing and sheave and repeat the installation steps.
7. Install the V-belts as described in the *V-Belt Replacement* procedure.

Sheave Replacement *(contd)*




Figure 7-8 Sheave Replacement

- 1. Cap screw
- 2. Bushing

- 3. Key
- 4. Sheave

- 5. Shaft

Motor Replacement



WARNING: Before performing the following procedures, shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.

Motor Removal

1. See Figure 7-9. Remove the cover from the junction box (1). Tag and disconnect the wiring from the motor leads. Disconnect the conduit (2) from the junction box.
2. Remove the V-belts, as described in the *V-Belt Replacement* procedure, from the motor sheave.
3. Remove the nuts and washers (3) securing the motor to the mounting plate.
4. Remove the motor from the compartment and move it to a clean work area.
5. Remove the motor sheave and bushing from the motor as described in the *Sheave Replacement* procedure.

Motor Installation

1. Install the new motor on the mounting plate with the nuts and washers. Do not tighten the nuts until you install and tension the V-belts.
2. Install the motor sheave and bushing on the motor shaft as described in the *Sheave Replacement* procedure.
3. Install the V-belts on the sheave and adjust the belt tension as described in the *V-Belt Replacement* procedure.
4. Connect the conduit to the motor junction box and the wiring to the motor leads. Install the cover.
5. Turn on the system electrical power and start the exhaust fan. Check the direction of air flow through the final filters. If air is being pulled into the final filters, the motor is rotating in the wrong direction. Refer to *Reversing Motor Direction* in the *Troubleshooting* section.

Motor Replacement *(contd)*




Figure 7-9 Motor Replacement

- 1. Junction box
- 2. Conduit

- 3. Nuts and washers

Fan Replacement



WARNING: Before performing the following procedures, shut off electrical power at the system electrical panel. Lock and tag the disconnect switch.

See Figure 7-10.

Fan Removal

1. Remove the screws (3), washers (4, 5), retainers (6), and the inlet cone (7) from the fan section.
2. Loosen the key and shaft set screws in the hub of the fan (10).
3. Remove the screw (8) and retainer washer (9) from the bottom of the fan shaft (1).
4. Remove the fan and key (2) from the fan section.

Fan Installation

1. Install the new fan on the shaft, line up the keyways, and install the key.
2. Install the retainer washer and screw onto the end of the shaft. Hold the fan and tighten the screw securely.
3. Install the inlet cone in the fan section with the retainers, washers, and screws. Do not tighten the screws.
4. Adjust the position of the fan on the shaft. The bottom of the fan should sit inside the cone (overlap) 3–6 mm (0.125–0.25 in.). Torque the set screws in the fan hub to 3.5 N•m (2.5 ft-lbs).
5. Adjust the inlet cone so the gap between the fan and the cone is the same all the way around. Use your finger to check the gap.
6. Tighten the screws securing the inlet cone to the fan compartment. Rotate the fan and make sure it does not rub against the cone.
7. Start the exhaust fan. If you notice any noise caused by the fan rubbing against the cone, stop the fan. Re-adjust the cone position.

Fan Installation (contd)






Figure 7-10 Fan Replacement

- | | | |
|-----------------|-----------------|--------------------|
| 1. Fan shaft | 5. Flat washers | 8. Screw |
| 2. Key | 6. Retainers | 9. Retainer washer |
| 3. Screws | 7. Inlet cone | 10. Fan |
| 4. Lock washers | | |

Fan Shaft and Bearing Replacement

Bearing Types

The design of the bearings has been updated. Refer to the following table to determine which type of bearings are in your system. If you order new bearings, you will receive the new style.

Old Style Part 177622 Rev A	New Style Part 177622 Rev B or higher
	
The old-style bearings use set screws to hold the inner bearing race to the fan shaft	The new-style bearings use a split adapter sleeve and lock nut to hold the inner bearing race to the fan shaft

Fan Shaft and Bearing Removal

See Figure 7-11.

1. Remove the inlet cone and fan as described in the *Fan Replacement* procedure. Remove the V-belts from the fan sheave as described in the *V-Belt Replacement* procedure.
2. Loosen both inner bearing races and pull the fan shaft (1) out of the bearings (2, 9).
 - **Old Style:** Loosen the top and bottom bearing-race set screws.
 - **New Style:** Loosen the lock nut around the fan shaft.
3. If you are replacing the shaft, remove the fan sheave, bushing, and key from the shaft as described in the *Sheave Replacement* procedure.
4. If you are replacing the bearings, disconnect the grease tubing (3) from the tube fittings (4). Remove the screws (5), washers (6, 7), and nuts (8) securing the bearings to the vertical supports.

NOTE: Replace the bearings with the ones listed in the *Parts* section only. Do not use unapproved bearings.

5. Remove the tube fittings from the old bearings. Remove the grease fittings from the new bearings and install the tube fittings in their place.

Fan Shaft and Bearing Installation

New-Style Bearings Only: Install $\frac{1}{16}$ -in. shims between the mounting surface and the expansion bearing (2). Do not install shims on the non-expansion bearing (9).


1. Install the new bearings on the supports with the screws, washers, and nuts. Do not tighten the screws. Connect the tubing to the tube fittings.
2. Install the shaft through the bearings. If you have trouble getting the shaft through the bearings,

New-Style Bearings: Loosen the lock nut.

Old-Style Bearings: Try one or more of the steps below:

- Loosen the bearing-race set screws.
 - Clean the shaft and ID of the bearing inner-race with a clean cloth and a small amount of penetrating oil. Do not get any oil inside the bearing races. The penetrating oil will dissolve the grease needed to lubricate the bearings.
 - Gently drive the shaft through the bearings with a soft-faced mallet or a hammer. If you use a hammer, place a block of wood on the end of the shaft and strike the wood, not the shaft.
 - Chill the shaft in a freezer or with dry ice and install it through the bearings while it is cold.
3. Level the shaft and square it with the support.
 4. If removed, install the fan sheave, bushing, and key on the shaft. Tighten the bushing cap screws enough to hold the sheave on the shaft. Refer to the *Sheave Replacement* procedure.

Old-Style Bearing and Fan Shaft Adjustment



Part 177622 Rev A


1. Tighten the bearing mounting screws to 68 N•m (600 in.-lb).
2. Place a square across the motor and fan sheaves. Adjust the fan shaft forward or back until the sheaves are parallel. This is a rough adjustment and will have to be repeated later.
3. Install the fan and key on the shaft. Tighten the key set screw in the fan hub to hold the fan in place. Install the retainer washer and screw on the end of the shaft.
4. Square the shaft with the support and tighten the bearing-race set screws. Torque the set screws to the torque values in Table 7-2.

Table 7-2 Recommended Torque Values for Bearing Set Screws

Set Screw Size (in.)	Hex Key Size (in.)	Torque N•m (in.-lb)	
		Standard Ball Bearing	Stainless Steel
#10	$\frac{3}{32}$	3.4 (30)	2.8 (25)
$\frac{1}{4}$	$\frac{1}{8}$	7.9 (70)	6.8 (60)
$\frac{5}{16}$	$\frac{5}{32}$	15.8 (140)	13.2 (117)
$\frac{3}{8}$	$\frac{3}{16}$	24.4 (216)	23.3 (206)

5. Install the inlet cone and adjust the fan overlap as described in the *Fan Replacement* procedures.
6. Tighten the fan sheave bushing screws to the torque values in the *Sheave Replacement* procedure. Use the square to make sure the sheaves are parallel.
7. Install the V-belts on the sheaves and adjust the belt tension as described in the *V-Belt Replacement* procedure.
8. Turn on the system electrical power and start the exhaust fan. Make sure the fan is not rubbing against the inlet cone. If you hear a rumbling noise coming from the bearings, stop the fan, lock out power to the system, and check the fan shaft alignment.

New-Style Bearing and Fan Shaft Adjustment



Part 177622 Rev B or higher

1. Place a square across the motor and fan sheaves. Adjust the fan shaft forward or back until the sheaves are parallel. This is a rough adjustment and will have to be repeated later.
2. See Figure 7-11. Install the fan and key on the shaft. Tighten the key set screw in the fan hub to hold the fan in place. Install the retainer washer and screw on the end of the shaft.
3. Apply a coating of light oil or rust preventative to the adapter area of the shaft and bearing bore.
4. Remove all weight from the bearings by blocking up the fan wheel to the proper overlap. Secure the fan shaft to prevent rotation during bearing adjustment.
5. Adjust the non-expansion bearing (9):
 - a. Turn the lock nut by hand as tightly as possible. Wear gloves while tightening the lock nut.
 - b. Scribe a line on the lock nut at the adapter slot. The line and adapter slot will serve as reference points as you tighten the lock nut.
 - c. Using a spanner wrench, tighten the lock nut $\frac{2}{3}$ -1 turn.
 - d. Tighten the lock nut set screw to 2.8 N•m (25 in.-lb).
 - e. Tighten the bearing mounting bolts to 67.8 N•m (600 in.-lb).
6. Adjust the expansion bearing (2):
 - a. With the $\frac{1}{16}$ -in. shims in place, turn the lock nut by hand as tightly as possible. Wear gloves while tightening the lock nut.
 - b. Scribe a line on the lock nut at the adapter slot. The line and adapter slot will serve as references point as you tighten the lock nut.
 - c. Using a spanner wrench, tighten the lock nut $\frac{1}{8}$ turn.
 - d. Remove the $\frac{1}{16}$ -in. shims and, using an alternating pattern, tighten the bearing mounting bolts to 67.8 N•m (600 in.-lb).
 - e. Lock the bearing onto the shaft by turning the lock nut a total of $\frac{2}{3}$ -1 turn.
 - f. Tighten the lock nut set screw to 2.8 N•m (25 in.-lb).
7. Rotate the shaft by hand. You should not feel any binding or excessive drag.
8. Install the inlet cone and adjust the fan overlap as described in the *Fan Replacement* procedures.

9. Tighten the fan sheave bushing screws to the torque values in the *Sheave Replacement* procedure. Use the square to make sure the sheaves are parallel.
10. Install the V-belts on the sheaves and adjust the belt tension as described in the *V-Belt Replacement* procedure.
11. Turn on the system electrical power and start the exhaust fan. Make sure the fan is not rubbing against the inlet cone. If you hear a rumbling noise coming from the bearings, stop the fan, lock out power to the system, and check the fan shaft alignment.




Figure 7-11 Fan Shaft and Bearing Replacement

- | | | |
|----------------------|------------------|--------------------------|
| 1. Fan shaft | 4. Tube fittings | 7. Lock washers |
| 2. Expansion bearing | 5. Screws | 8. Nuts |
| 3. Grease tubing | 6. Lock washers | 9. Non-expansion bearing |

Note: New-style bearings shown. Old-style bearings use set screws (instead of the lock nut) to secure the bearing race to the shaft.

Section 8

Parts

Introduction

To order parts, call the Nordson Finishing Customer Support Center at (800) 433-9319 or your local Nordson representative. Use the illustrations and parts lists to locate and describe parts correctly.

System Electrical Panel

See Figure 8-1. Refer to Tables 8-2 through 8-5 for cross references listed in the Part column of Table 8-1. Refer to Table 8-6 for total current calculations.

Table 8-1 Electrical Sub-Panel

Item	Part	Descriptions	Quantity
AH427	XB-19-201QM	Alarm	1
CN510	CN35AN2AB	Contactactor	1
CR319, CR410, CR414	RH2B-UAC120V	Relay control	3
FU 306	Refer to Table 8-2	Fuse	3
FU 309, FU323	Refer to Table 8-3	Fuse	6
FU312, FU315	Refer to Table 8-4	Fuse	6
FU401	Refer to Table 8-5	Fuse	2
M407	Refer to Table 8-2	Contactactor	1
M503, M425, M426	CE15ANS3AB	Contactactor	3
M416, M419	CE15BNS3AB	Contactactor	2
OL407	Refer to Table 8-2	Overload	1
OL503, OL425	Refer to Table 8-3	Overload	2
OL416, OL419	Refer to Table 8-4	Overload	2
TDR423	RTE-P22-AC120V	Time delay relay	1
TDR508	GT5Y-2SN1A100	Time delay relay	1
—	28-2468-7	Lamp	AR
AR: As Required. Quantity needed is dependent on controller configuration.			




Figure 8-1 System Electrical Panel

System Electrical Panel *(contd)*

Table 8-2 Exhauster Parts Cross Reference

Horizon 200 — 5 HP Motor						
Item	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
M407	CE15DNS3AB	CE15DBS3AB	CE15CNS3AB	CE15BNS3AB	CE15BNS3AB	CE15ANS3AB
OL407	C316FNA3R	C316FNA3R	C316FNA3Q	C316FNA3P	C316FNA3P	C316FNA3N
FU306	LPJ-35SP	LPJ-30SP	LPJ-20SP	LPJ-20SP	LPJ-15SP	LPJ-12SP
FUSE BLOCK	J60060-3CR	J60030-3CR	J60030-3CR	J60030-3CR	J60030-3CR	J60030-3CR
Horizon 400 Low Flow — 7 ¹ / ₂ HP Motor						
Item	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
M407	CE15FNS3AB	CE15ENS3AB	CE15DNS3AB	CE15DNS3AB	CE15CNS3AB	CE15BNS3AB
OL407	C316FNA3T	C316FNA3S	C316FNA3R	C316FNA3Q	C316FNA3Q	C316FNA3P
FU306	LPJ-45SP	LPJ-40SP	LPJ-30SP	LPJ-25SP	LPJ-20SP	LPJ-20SP
FUSE BLOCK	J60060-3CR	J60060-3CR	J60030-3CR	J60030-3CR	J60030-3CR	J60030-3CR
Horizon 400 High Flow — 10 HP Motor						
Item	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
M407	CE15HNS3AB	CE15FNS3AB	CE15ENS3AB	CE15DNS3AB	CE15DNS3AB	CE15CNS3AB
OL407	C316KNA3C	C316FNA3T	C316FNA3S	C316FNA3R	C316FNA3R	C316FNA3Q
FU306	LPJ-60SP	LPJ-50SP	LPJ-35SP	LPJ-30SP	LPJ-25SP	LPJ-20SP
FUSE BLOCK	J60060-3CR	J60060-3CR	J60060-3CR	J60030-3CR	J60030-3CR	J60030-3CR

Table 8-3 ¹/₂ HP Motor (Booth Mover, Sieve) Cross Reference

Item	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
OL503, OL425	C316FNA3J	C316FNA3H	C316FNA3G	C316FNA3F	C316FNA3F	C316FNA3E
FU309, FU323	LP-CC-8	LP-CC-8	LP-CC-5	LP-CC-4	LP-CC-4	LP-CC-3

Table 8-4 3 PH ¹/₂ HP Oscillator Cross Reference

Item	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
OL416, OL419	C316FNA3N	C316FNA3M	C316FNA3L	C316FNA3L	C316FNA3J	C316FNA3J
FU312, FU315	LP-CC-25	LP-CC-20	LP-CC-15	LP-CC-12	LP-CC-10	LP-CC-8

Table 8-5 Transformer Cross Reference

T402	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
750VA	PT750MGJ	PT750MQMJ	PT750MGJ	PT750MDMX	PT750MQMJ	PT750MBMH
FU401	FN-R-9	FNQ-R-71/2	FNQ-R-5	FNQ-R-4	FNQ-R-4	FNQ-R-32/10
CB404	SPCL1C08	SPCL1C08	SPCL1C08	SPCL1C08	SPCL1C08	SPCL1C08
1.0 KVA	PT1000MGJ	PT1000MQMJ	PT1000MGJ	PT1000MDMX	PT1000MQMJ	PT1000MBMH
FU401	FNQ-R-12	FNQ-R-10	FNQ-R-61/4	FNQ-R-6	FNQ-R-5	FNQ-R-4
CB404	SPCL1C10	SPCL1C10	SPCL1C10	SPCL1C10	SPCL1C10	SPCL1C10

Table 8-6 Total Current Calculation Chart

	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
$\frac{1}{2}$ HP	2.5	2.2	1.5	1.3	1.1	0.9
x QTY						
	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
$1\frac{1}{2}$ HP	6.9	6.0	4.3	3.6	3.0	2.4
x QTY						
	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
5 HP (Horizon 200)	17.5	15.2	10.6	8.8	7.6	6.1
$7\frac{1}{2}$ HP (Horizon 400 Low-Flow)	25.3	22.0	15.4	12.7	11.0	9.0
10 HP (Horizon 400 High-Flow)	32.2	28.0	19.6	16.1	14.0	11.0
	208 Volt	230 Volt	380 Volt	415 Volt	460 Volt	575 Volt
750 VA TRANX (Horizon 200)	3.6	3.1	2.0	1.8	1.6	1.3
1.0 KVA TRANX (Horizon 400)	4.8	4.2	2.6	2.4	2.1	1.7
= TOTAL CURRENT						

Horizon 400 Parts

Base Parts

See Figure 8-2.

Item	Part	Description	Quantity	Note
1	177647	SEAL, Velcro, 2 in., with adhesive	AR	
2	177648	SEAL, Velcro, 1 in., with adhesive	AR	
3	981402	SCREW, hex, $\frac{3}{8}$ -16 x 1.00 in., cap, zinc-plated steel	AR	
4	-----	CASTERS, roll-on/roll-off (optional)	4	A
5	983160	WASHER, lock, split, $\frac{3}{8}$ in., nickel-plated steel	AR	
6	983061	WASHER, flat, 0.406 x 0.812 x 0.065 in., zinc-plated steel	AR	
7	177644	BLOCK, leveling, pad (optional)	4	B
8	981461	SCREW, hex, $\frac{1}{4}$ -20 x 0.75 in., zinc, G5	2	
9	983041	WASHER, flat, 0.250 x 0.500 x 0.049 in., zinc-plated steel	2	
10	983140	WASHER, lock, split, $\frac{1}{4}$ in., nickel-plated steel	2	
11	984086	NUT, hex, mach, $\frac{1}{4}$ -20, zinc-plated steel	2	
12	178952	BRACKET, limit switch	1	
13	305645	SWITCH, limit, with arm	1	
14	981176	SCREW, slotted pan head, #10-32 x 1.50 in., zinc-plated steel	2	
15	983079	WASHER, lock, split, #10, zinc-plated steel	2	
16	984120	NUT, hex, machine, #10-32, zinc-plated steel	2	
NS	184025	BELT, with ratchet, 36 in.	2	
NS	176308	GATE, slide	2	
NS	176355	SCREW, thumb, $\frac{1}{4}$ -20 x 1.00 in.	8	
NOTE A: Used on roller-base units only. B: Used on fixed-base units only. AR: As Required NS: Not Shown				




Figure 8-2 Horizon 400 Base Parts

Pulse Valves and Air Manifold Parts

See Figure 8-3.

Item	Part	Description	Quantity	Note
1	172438	MANIFOLD, pulse	1	
2	-----	NUT, hex, serrated, $\frac{3}{8}$ -16, zinc-plated steel	4	
3	-----	SCREW, hex, serrated, $\frac{3}{8}$ -16 x 1 in., zinc-plated steel	4	
4	124792	HOSE, 0.75 in. ID, 200 psi	AR	
5	178971	FITTING, barbed, $\frac{3}{4}$ in. NPT x $\frac{3}{4}$ in.	1	
6	972119	ELBOW, male, $\frac{1}{4}$ in. tube x $\frac{1}{8}$ in. NPT	4	
7	310717	TUBING, PTFE PFA, 0.25 in. OD x 0.12 in. ID	AR	
8	174710	VALVE, pulse, 1 in. NPT x 1 in. NPT	4	
9	165726	NOZZLE, cartridge pulse	4	
AR: As Required				




Figure 8-3 Horizon 400 Pulse Valves and Air Manifold Parts

Pulse Valve Solenoids and Air Volume Control Parts

See Figure 8-4.

Item	Part	Description	Quantity	Note
1	178970	ENCLOSURE, Goyen valve	1	
2	177630	ELBOW, tee, pull, 1 in.	1	
3	973013	NIPPLE, hex, 0.5 x 0.5 x 1.89 in., stainless steel	3	
4	177628	ELBOW, 90°, pull, 1/2 in.	3	
5	177633	CONNECTOR, straight, 1/2 in. conduit	2	
6	-----	CONDUIT, flex, electric, bulk, 1/2 in.	AR	
7	310717	TUBING, PTFE PFA, 0.25 in. OD x 0.12 in. ID	AR	
8	972119	ELBOW, male, 1/4 in. tube x 1/8 in. NPT	4	
9	-----	NUT, hex, serrated, 3/8-16, zinc-plated steel	2	
10	-----	SCREW, hex, serrated, 3/8-16 x 1.5 in., zinc-plated steel	2	
11	176301	CONTROL, air volume, assembly	1	
12	178971	FITTING, barbed, 3/4 in. NPT x 3/4 in.	1	
AR: As Required				




Figure 8-4 Horizon 400 Pulse Valve Solenoids and Air Volume Control Parts

Fan and Fan Drive Parts

See Figure 8-5.

Item	Part	Description	Quantity	Note
1	981402	SCREW, hex, $\frac{3}{8}$ -16 x 1.00 in., cap, zinc-plated steel	8	
2	983160	WASHER, lock, split, $\frac{3}{8}$ in., nickel-plated steel	12	
3	983061	WASHER, flat, 0.406 x 0.812 x 0.065 in., zinc	12	
4	158658	RETAINER, inlet cone	8	
5	177620	CONE, inlet, alum, 100% width	1	
6	981530	SCREW, hex, $\frac{1}{2}$ -20 x 1 in., black, G5	1	
7	178973	WASHER, flat, special	1	
8	177619	WHEEL, fan	1	
9	177622	BEARING, fan	2	
10	310717	TUBING, PTFE PFA, 0.25 in. OD x 0.12 in. ID	AR	
11	971415	CONNECTOR, male, $\frac{1}{4}$ in. tube x $\frac{1}{8}$ in. NPT	2	
12	984170	NUT, hex, reg, $\frac{1}{2}$ -13, zinc-plated steel	8	
13	983180	WASHER, lock, split, $\frac{1}{2}$ in., nickel-plated steel	8	
14	983007	WASHER, flat, 0.531 x 1.000 x 0.063 in., zinc	16	
15	982526	SCREW, hex head, $\frac{1}{2}$ -13 x 2.50 in., black	8	
16	-----	BELT, fan	2	
17	174780	BUSHING, quick disconnect, 1.937 in.	1	
18	174774	SHEAVE, quick disconnect, 4.60 in. pitch diameter	1	
19	176260	SHAFT, fan	1	
20	174809	KEY, fan sheave, 0.50 x 0.312 x 2.62 in.	1	
21	177627	KEY, fan, 0.5 x 0.5 x 4.07 in.	1	
22	-----	BUSHING, motor	1	A
23	-----	SHEAVE, motor	1	A
24	-----	MOTOR	1	A
25	-----	PLATE, motor mount, adjustable	1	
26	981998	SCREW, hex head, $\frac{3}{8}$ -16 x 1.25 in., zinc, G5	4	
27	973993	NIPPLE, hex, 1.00 x 1.00 x 2.34 in., zinc-plated steel	2	
28	177629	ELBOW, 90°, pull, 1 in.	2	
29	803874	FITTING, 1.00 in. flex, conduit	2	
30	-----	CONDUIT, flex, liquid-tight, 1 in.	AR	

NOTE A: Refer to *Belt/Bushing/Sheave/Motor/Mounting Plate* for part numbers.

AR: As Required




Figure 8-5 Horizon 400 Fan and Fan Drive Parts

Belt/Bushing/Sheave/Motor/Mounting Plate Parts

Item	Low-Flow Part	High-Flow Part	Description	Quantity
16	178972	176378	BELT, fan	2
22	177621	177634	BUSHING, quick disconnect, 1.375 in.	1
23	174775	172518	SHEAVE, motor	1
24	174754	174753	MOTOR, fan (7.5 hp–low flow, 10 hp–high flow)	1
25	172520	172519	PLATE, motor mount, adjustable	1

Fan Damper Parts

See Figure 8-6.

Item	Part	Description	Quantity	Note
1	981402	SCREW, hex, $\frac{3}{8}$ –16 x 1.00 in., cap, zinc-plated steel	8	
2	983160	WASHER, lock, split, $\frac{3}{8}$ in., nickel-plated steel	8	
3	154203	DUCT, air damper	1	
4	154186	CONTROL UNIT, damper assembly	1	
5	983041	WASHER, flat, 0.200 x 0.500 x 0.049 in., zinc-plated steel	4	
6	981218	SCREW, hex, $\frac{1}{4}$ –20 x 1.00 in., cap, zinc-plated steel	4	
7	983140	WASHER, lock, split, $\frac{1}{4}$ in., nickel-plated steel	4	
8	177643	COVER, damper mounting	4	A
NOTE A: Used only when fan damper not installed.				




Figure 8-6 Horizon 400 Fan Damper Parts

Final Filters and Mounting Parts

See Figure 8-7.

Item	Part	Description	Quantity	Note
1	172436	PLATE, final filter/access door	1	
2	156995	FILTER, final 20 x 24 in., internal	4	
3	176366	CLAMP, final filter	8	
4	176367	KNOB, final filter clamp	16	
5	981315	SCREW, hex, $\frac{5}{16}$ -18 x 1.00 in., cap, zinc-plated steel	24	
6	983150	WASHER, lock, split, $\frac{5}{16}$ in., nickel-plated steel	24	
7	983050	WASHER, flat, 0.344 x 0.625 x 0.063 in., zinc-plated steel	24	




Figure 8-7 Horizon 400 Final Filters and Mounting Parts

Color Module Parts

See Figures 8-8 and 8-9.

Item	Part	Description	Quantity	Note
1	172493	GRATE, color module, Horizon 400	2	
2	172507	GASKET, color module, Horizon 400	1	
3	-----	ADHESIVE, spray, high tack, approved for neoprene contact	AR	
4	180771	FILTER, cartridge, closed-end, 36 in., heavy duty	4	A
5	180770	FILTER, cartridge, open-end, 36 in., heavy duty	4	A
6	984170	NUT, hex, reg, $\frac{1}{2}$ -13 in., zinc-plated steel	8	
7	-----	SCREW, hex, $\frac{1}{2}$ -13 x 3.00 in., cap, zinc-plated steel	4	
8	981402	SCREW, hex, $\frac{3}{8}$ -16 x 1.00 in., cap, zinc-plated steel	32	
9	983061	WASHER, flat, 0.406 x 0.812 x 0.065 in., zinc-plated steel	32	
10	983160	WASHER, lock, split, $\frac{3}{8}$ in., nickel-plated steel	32	
11	174545	CASTER, 4 in., swivel	4	
12	309473	MOUNT, pump, with pickup tube, 6 in.	4	
13	174548	SCREW, hex, $\frac{1}{2}$ -13 x 4 in., special	4	
14	981315	SCREW, hex, $\frac{5}{16}$ -18 x 1.00 in., cap, zinc-plated steel	AR	
15	983050	WASHER, flat, 0.344 x 0.625 x 0.063 in., zinc-plated steel	AR	
16	983150	WASHER, lock, split, $\frac{5}{16}$ in., nickel-plated steel	AR	
17	981211	SCREW, hex, $\frac{1}{4}$ -20 x 0.75 in., cap, zinc-plated steel	4	
18	174546	PLATE, filter, pusher	4	
19	176467	PLATE, direct vent, Horizon 400/200	1	
20	172509	GASKET, direct vent, Horizon 400/200	1	
21	174549	PLATE, cover, vent stub, 3.5 in.	1	
22	179159	GASKET, vent stub	1	
23	172491	ROD, filter, Horizon 400/200	4	
25	177648	SEAL, Velcro, 1 in., with adhesive	AR	
26	172492	BAFFLE, color module, Horizon 400	1	
27	981619	SCREW, hex, $\frac{7}{16}$ -14 x 0.75, cap, zinc-plated steel	8	
28	983248	WASHER, flat, 0.468 x 0.922 x 0.065 in., zinc-plated steel	8	
29	983170	WASHER, lock, split, $\frac{7}{16}$, nickel-plated steel	8	
NS	172514	SKIRT, seal, color module, Horizon 400	1	
NOTE A: Standard filter shipped with booth. Refer to <i>Cartridge Filters</i> for filter options.				
AR: As Required				
NS: Not Shown				

Color Module Parts (contd)




Figure 8-8 Horizon 400 Color Module Parts (1 of 2)

Color Module Fluidizing Plates, Direct Vent, and Vent Stub Parts

See Figure 8-9.

Item	Part	Description	Quantity	Note
1	179159	GASKET, vent stub	1	
2	174800	FLANGE, vent, 3.5 in.	1	
3	981315	SCREW, hex, $\frac{5}{16}$ -18 x 1.00 in., cap, zinc-plated steel	AR	
4	983050	WASHER, flat, 0.344 x 0.625 x 0.063 in., zinc-plated steel	AR	
5	983150	WASHER, lock, split, $\frac{5}{16}$ in., nickel-plated steel	AR	
6	-----	VENT OPTIONS	—	A
7	172509	GASKET, direct vent, Horizon 400/200	1	
8	172513	GASKET, fluidizing plate, Horizon 400/200	4	
9	172508	PLATE, fluidizing, Horizon 400/200	4	
10	172495	BAFFLE, fluidizing pan, Horizon 400/200	4	
11	172494	PAN, fluidizing, Horizon 400/200	4	
12	972240	ELBOW, male, 12 mm tube x $\frac{1}{2}$ in. unithread	4	
13	973326	NIPPLE, steel, schedule 40, $\frac{1}{2}$ in., 10-in. long	4	
14	973327	COUPLING, pipe, 150 lb, $\frac{3}{4}$ x $\frac{1}{2}$ in., plain	4	
15	124851	MUFFLER, $\frac{3}{4}$ in. NPT, 40 micron	4	
16	172497	CLAMP, fluidizing pan, Horizon 400/200	16	
NOTE A: Refer to <i>Vent Options</i> for part numbers.				
AR: As Required				
NS: Not Shown				

Cartridge Filters

Closed End	Open End	Description	Note
180771	180770	FILTER, 36 in., heavy duty	A, B
153134	153129	FILTER, 36 in., high efficiency	A, C
151086	151085	FILTER, 36 in., PowderGrid	A, C
NOTE A: Horizon 400 module requires four closed-end and four open-end filters. Horizon 200 module requires two closed-end and two open-end filters. Do not mix media types in same module.			
B: Standard filter shipped with booth.			
C: Optional filter.			

Vent Options

Part	Description	Note
172435	HOUSING, direct vent, Horizon 400/200	
172503	PLATE, vent assist, Horizon 400/200	
184179	VENT, direct, 2-tube, remote hopper	

Color Module Parts (contd)




Figure 8-9 Horizon 400 Color Module Parts (2 of 2)

Horizon 200 Parts

Base Parts

Many of the parts in the Horizon 200 module are the same as the Horizon 400 module. However, the Horizon 200 module may have half the number of similar parts.

Part	Description	Quantity
156995	FILTER, final, 20 x 24 in., internal	2
176366	CLAMP, final filter	4
176367	KNOB, final filter clamp	8
174710	VALVE, pulse, 1 in. NPT x 1 in. NPT	2
165726	NOZZLE, cartridge pulse	2
178970	ENCLOSURE, Goyen valve	1
184025	BELT, with ratchet, 36 in.	2
-----	ASSEMBLY, pneumatic receiver tank	1
174606	CASTER	4
174829	PAD, leveling (fixed base)	4
178952	BRACKET, limit switch	1
176301	CONTROL, air volume, assembly	1
176308	GATE, slide	2
176355	SCREW, thumb, 1/4-20 x 1.00 in.	8
305645	SWITCH, limit, with arm	1
601367	SENSOR, level	1
900517	TUBING, poly spiral cut, 0.62 in. ID	AR
900586	TUBING, polyethylene, 6 mm OD x 4 m ID, blue	AR
900593	TUBING, polyethylene, 10 mm OD x 8 mm ID, blue	AR
900613	TUBING, polyethylene, 12 mm OD x 9.5 mm ID, blue	AR
900741	TUBING, polyurethane, 6/4 mm, black	AR
971100	CONNECTOR, male, 6 mm tube x 1/4 in. unithread	2
971104	CONNECTOR, male, 12 mm tube x 1/4 in. unithread	2
971114	UNION, tee, 6 mm tube x 6 mm tube	2
997778	UNION, bulkhead, 6 mm tube	2
992093	ELBOW, male, 12 mm tube x 1/4 in. unithread	2
972125	ELBOW, male, 10 mm tube x 1/4 in. unithread	1
972126	ELBOW, male, 6 mm tube x 1/8 in. unithread	1
972240	ELBOW, male, 12 mm tube x 1/2 in. unithread	2
972873	COUPLING, insert with ring, 1/2 x 12 mm	6
972876	COUPLING, insert, 10 mm	6
AR: As Required		

Fan and Fan Drive

Each of the part columns in this parts list are for one of the four versions of the Horizon 200 system:

Roll/Lo	Roll On/Off Base, Low-Flow Exhaust Fan
Roll/Hi	Roll On/Off Base, High-Flow Exhaust Fan
Fixed/Lo	Fixed Base, Low-Flow Exhaust Fan
Fixed /Hi	Fixed Base, High-Flow Exhaust Fan

Roll/Lo	Roll/Hi	Fixed/Lo	Fixed/Hi	Description	Quantity
174795	174795	174795	174795	BEARING, tapered, roller flange	1
174780	174780	174780	174780	BUSHING, quick disconnect, 1.937 in.	1
174784	-----	174784	-----	SHEAVE, quick disconnect, 4.80 pitch diameter	1
184029	184029	184029	184029	BUSHING, motor, Horizon 200	1
174792	-----	174792	-----	SHEAVE, quick disconnect, 7.40 pitch diameter	1
-----	184028	-----	184028	SHEAVE, fan/motor, Horizon 200H	2
184027	184027	184027	184027	MOTOR, 5 hp, 230/460/60/3	1
184037	184030	184037	184030	BELT, fan, Horizon 200	2

Color Module

Many of the parts in the Horizon 200 module are the same as the Horizon 400 module. However, the Horizon 200 module may have half the number of similar parts.

Part	Description	Quantity
124851	MUFFLER, $\frac{3}{4}$ in. NPT, 40 micron	2
154205	PLATE, cover, quick disconnect	2
165633	PUMP, transfer, 10 mm x 19 mm	2
309473	MOUNT, pump, with pickup tube, 6 in.	2
172508	PLATE, fluidizing, Horizon 400/200	2
172513	GASKET, fluidizing plate, Horizon 400/200	2
174545	CASTER, 4 in., swivel	4
174546	PLATE, filter, pusher	2
174549	PLATE, cover, vent stub, 3.5 in.	1
174800	FLANGE, vent, $3\frac{1}{2}$ in.	1
17467	PLATE, direct vent, Horizon 400	1
172509	GASKET, direct vent, Horizon 400/200	2
180770	FILTER, cartridge, 36 in., heavy duty, open-end	2
180771	FILTER, cartridge, 36 in., heavy duty, closed-end	2
184033	COVER, color module baffle, Horizon 200	1
184034	GRATE, expanded metal, Horizon 200	2
184035	GASKET, D, color module, Horizon 200	1
228643	SKIRT, seal, color module, Horizon 200	1
900551	TUBING, powder, 19-mm (0.75-in.) ID, black	AR
939459	CLAMP, hose (transfer)	4
972240	ELBOW, male, 12 mm tube x $\frac{1}{2}$ in. unithread	2
972869	COUPLING, spring lock, $\frac{1}{2}$ x 12 in.	2
972871	COUPLING, connector body, $\frac{1}{2}$ x 12 in.	4
972874	COUPLING, spring lock, 10 mm	2
972875	COUPLING, connector body, 10 mm	4
AR: As Required		

Cart-Mounted Feed Hoppers and Sieves

Hopper with Vibratory Sieve

Part	Description	Quantity
165633	PUMP, transfer, 10 mm in x 19 mm out	2
309473	MOUNT, pump, with pickup tube, 6 in.	2
174545	CASTER, 4 in., swivel	4
174659	SIEVE, vibratory, 8 in.	1
174664	LID, 8 in., vibratory sieve	1
183929	RING, adapter, 6 in.	2
184179	VENT, direct, 2 tube, remote hopper	1
184180	CART, 150# hopper, without lid	1
237193	HOPPER, HR-16-150, with level sensor well	1
243052	• HOSE, flexible, 10 ft, 3 ¹ / ₂ in. diameter	1
246930	• CLAMP, hose, 1.055–1.22 in. OD	4
970970	• CLAMP, hose, no. 52	2
242402	HOSE, flexible, 10 ft, 2 in. diameter	1
245718	CONNECTOR, spout	1
900651	TUBING, powder, 19 mm (0.75 in.) ID, blue	AR
939459	CLAMP, hose (transfer)	4
970966	CLAMP, hose, 2 ¹ / ₂ in. diameter	2
970968	CLAMP, hose, 6 in. diameter	2
AR: As Required		

Hopper with 10-Port Cyclone

Part	Description	Quantity
165633	PUMP, transfer, 10 mm x 19 mm	2
309473	TUBE, pickup, with pickup tube, 6 in.	2
174545	CASTER, 4 in., swivel	4
176271	LID, cart, hopper, cyclone	1
183929	RING, adapter, 6 in.	2
184179	VENT, direct, 2 tube, remote hopper	1
184180	CART, 150 lb hopper, without lid	1
237193	HOPPER, HR-16-150, with level sensor well	1
243052	• HOSE, flexible, 10 ft, 3 ¹ / ₂ in. diameter	1
246930	• CLAMP, hose, 1.055–1.22 in. OD	4
970970	• CLAMP, hose, no. 52	2
237615	ACCUMULATOR, 8 in., 10-port	1
245718	CONNECTOR, spout	1
249445	BRACKET, mounting, 10 tube, rectangular	1
900651	TUBING, powder, 19 mm (0.75 in.) ID, blue	AR
939459	CLAMP, hose (transfer)	4
970968	CLAMP, hose, 6 in. diameter	2
AR: As Required		

Hopper with Nordson 230/460 V Rotary Sieve

Part	Description	Quantity
144837	BUCKET, scrap, sieve, 5 gallon	1
165633	PUMP, transfer, 10 mm x 19 mm	2
309473	MOUNT, pump, with pickup tube, 6 in.	2
174545	CASTER, 4 in., swivel	4
174805	PLATFORM, scrap bucket	1
176346	PLATE, cover, power cord	1
176347	RECEPTACLE, 600 volts, 30 amps, ac	1
176348	PLUG, power cord	1
176349	BOOT, plug, power cord	1
176350	RECEPTACLE, sieve limit	1
176351	PLUG, sieve limit	1
176352	BOOT, sieve limit	1
176376	ADAPTER, 3 ¹ / ₂ to 2 in.	1
176377	CORD, power, 14–4, sieve	AR
176390	RECEPTACLE BOX, sieve motor and limit	2
176391	GRIP, ¹ / ₂ in., 14–4 cord, sieve motor	1
176392	COVER, receptacle, sieve limit	1
176393	GRIP, ³ / ₄ in., 14–3 cord, sieve limit	1
176394	CORD, S.O., 14–3, sieve limit	AR
184181	LID, hopper, cart, Nordson sieve	1
183929	RING, adapter, 6 in.	2
184179	VENT, direct, 2 tube, hopper cart	1
184180	CART, 150 lb hopper, without lid	1
237193	HOPPER, HR-16-150, with level sensor well	1
243052	• HOSE, flexible, 10 ft, 3 ¹ / ₂ in. diameter	1
246930	• CLAMP, hose, 1.055–1.22 in. OD	4
970970	• CLAMP, hose, no. 52	2
237615	ACCUMULATOR, 8 in., 10 port	1
242402	HOSE, flexible, 10 ft, 2 in. diameter	1
245718	CONNECTOR, spout	1
249445	BRACKET, mounting, 10 tube, rectangular	1
-----	SIEVE, rotary	1
900651	TUBING, powder, 19 mm (0.75 in.) ID, blue	AR
939459	CLAMP, hose (transfer)	4
970966	CLAMP, hose, 2 ¹ / ₂ in.	2
970968	CLAMP, hose, 6 in. diameter	2
AR: As Required		

Feed Hopper with AZO Sieve

Part	Description	Quantity
144837	BUCKET, scrap, sieve, 5 gallon	1
165633	PUMP, transfer, 10 mm x 19 mm	2
309473	MOUNT, pump, with pickup tube, 6 in.	2
174545	CASTER, 4 in., swivel	4
174644	SIEVE, rotary, AZO, E240/460	1
174662	SEAL, air, AZO	1
174805	PLATFORM, scrap bucket	1
176346	PLATE, cover, power cord	1
176347	RECEPTACLE, 600 volts, 30 amps, ac	1
176348	PLUG, power cord	1
176349	BOOT, plug, power cord	1
176350	RECEPTACLE, sieve limit	1
176351	PLUG, sieve limit	1
176352	BOOT, sieve limit	1
176376	ADAPTER, 3 ¹ / ₂ to 2 in.	1
176377	CORD, power, 14-4, sieve	AR
176390	RECEPTACLE box, sieve motor and limit	2
176391	GRIP, 1 ¹ / ₂ in., 14-4 cord, sieve motor	1
176392	COVER, receptacle, sieve limit	1
176393	GRIP, 3 ³ / ₄ in., 14-3 cord, sieve limit	1
176394	CORD, S.O., 14-3, sieve limit	AR
184178	LID, cart, hopper, rotary sieve	1
183929	RING, adapter, 6 in.	2
184179	VENT, direct, 2 tube/remote hopper	1
184180	CART, 150 lb hopper, without lid	1
226703	SERVICE KIT, air volume control	1
237193	HOPPER, HR-16-150, with level sensor well	1
243052	• HOSE, flexible, 10 ft, 3 ¹ / ₂ in. diameter	1
246930	• CLAMP, hose, 1.055-1.22 in. OD	4
970970	• CLAMP, hose, no. 52	2
237615	ACCUMULATOR, 8 in., 10 port	1
242402	HOSE, flexible, 10 ft, 2 in. diameter	1
245718	CONNECTOR, spout	1
249445	BRACKET, mounting, 10 tube, rectangular	1
900651	TUBING, powder, 19 mm (0.75 in.) ID, blue	AR
939459	CLAMP, hose (transfer)	4
970966	CLAMP, hose, 2 ¹ / ₂ in.	2
970968	CLAMP, hose, 6 in. diameter	2
AR: As Required		

Feed Hopper with Nordson NRPS-100 Rotary Sieve

Part	Description	Quantity
111686	GASKET, base, rotary sieve	1
111687	GASKET, inlet, rotary sieve	1
144837	BUCKET, scrap, sieve, 5 gallon	1
165633	PUMP, transfer, 10 mm x 19 mm	2
309473	MOUNT, pump, with pickup tube, 6 in.	2
174545	CASTER, 4 in., swivel	4
174805	PLATFORM, scrap bucket	1
176346	PLATE, cover, power cord	1
176347	RECEPTACLE, 600 volts, 30 amps, ac	1
176348	PLUG, power cord	1
176349	BOOT, plug, power cord	1
176350	RECEPTACLE, sieve limit	1
176351	PLUG, sieve limit	1
176352	BOOT, sieve limit	1
176377	CORD, power, 14-4, sieve	AR
176390	RECEPTACLE BOX, sieve motor and limit	2
176391	GRIP, $\frac{1}{2}$ in., 14-4 cord, sieve motor	1
176392	COVER, receptacle, sieve limit	1
176393	GRIP, $\frac{3}{4}$ in., 14-3 cord, sieve limit	1
176394	CORD, S.O., 14-3, sieve limit	AR
183929	RING, adapter, 6 in.	2
184178	LID, cart, hopper, rotary sieve	1
184179	VENT, direct, 2 tube, remote hopper	1
184180	CART, 150 lb, hopper, without lid	1
223920	SIEVE, NRPS-100, 320-460/3/60	1
226703	SERVICE KIT, air volume control	1
237193	HOPPER, HR-16-150, with level sensor well	1
243052	• HOSE, flexible, 10 ft, $3\frac{1}{2}$ in. diameter	1
246930	• CLAMP, hose, 1.055-1.22 in. OD	4
970970	• CLAMP, hose, no. 52	2
237615	ACCUMULATOR, 8 in., 10 port	1
242402	HOSE, flexible, 10 ft, 2 in. diameter	1
245718	CONNECTOR, spout	1
249445	BRACKET, mounting, 10 tube, rectangular	1
900651	TUBING, powder, 19 mm (0.75 in.) ID, blue	AR
939459	CLAMP, hose (transfer)	4
970966	CLAMP, hose	2
970968	CLAMP, hose, 6 in. diameter	2
AR: As Required		

Section 9

Specifications

Dimensions and Capacities

NOTE: Equipment specifications are subject to change without notice due to continuing technological and quality improvements.

Refer to Table 9-1 for the dimensions and capacities of the Horizon 200 and 400 powder coating systems.

Table 9-1 Dimensions and Capacities

Dimensions and Capacities	Horizon 200	Horizon 400
Overall dimensions		
Height (add part height)	163 cm (64 in.)	198 cm (78 in.)
Width	152 cm (60 in.)	182 cm (72 in.)
with optional gun vestibules		244 cm (96 in.)
with platforms		457 cm (180 in.)
Length	508 cm (200 in.)	680 cm (268 in.)
Fan		
High flow	2920 rpm/2750 cfm	2680 rpm/5500 cfm
Low flow	2630 rpm/2000 cfm	2400 rpm/4000 cfm
Fan motor	5 hp/1750 rpm	7.5 (L) or 10 (H) hp/1750 rpm
Number of cartridge filters	4	8
Number of final filters	2	4
Number of pulse valves	2	4
Maximum air pressure	7 bar (100 psig)	7 bar (100 psig)
Manual/auto gun capacity	1/6 or 2/8	2/10

Operating Environment

Locate your powder coating system in a proper environment. If temperature and humidity in the spray room exceed the following ranges, you must install air conditioning equipment.

Temperature	21–26 °C (70–80 °F)
Humidity	45–55% RH

Utilities

Primary Electrical Service: 230, 460, or 575 Vac. The customer must install a fused disconnect switch with lock-out capability, wired in accordance with the National Electric Code, NFPA-70.

Compressed Air Supply: The air supply line must be 38-mm (1.5-in.) ID minimum. Supply air pressure must be 5.5–7 bar (80–100 psi). The pressure dewpoint must be 3.3 °C (38 °F) or less at 7 bar (100 psi). The air temperature must be less than 37.8 °C (100 °F).

Normal Design Standards

Systems are custom-designed to each customer's requirements, so some may deviate from these design standards. Contact your Nordson representative if you need more information about the design of your booth.

End Openings: 152-mm (6-in.) clearance on all four sides of the largest part.

Part Hanger Keyhole Slot: 305-mm (12-in.) high.

Cross Drafts: No more than 18 m/min (60 fpm).

Average Face Velocity: 30 m/min (100 fpm) (minimum) through all openings in the booth enclosure.

Temperature of Parts Entering Booth: No more than 49 °C (120 °F).

Powder: Use commercially available powder coatings. Note that the characteristics and properties of a powder coating can affect system operation. Powder coatings generally have an average particle size of 25–35 microns, with no more than 10% of the total being less than 15 microns. When the percentage of particles less than 15 microns exceeds 10% of the total, the filter media can get clogged.

Cartridge Filters: Cartridge filters are considered wear items. The variables affecting the life expectancy of a cartridge filter include

- type of coating material
- particle size distribution
- humidity and temperature of the spray room air
- hours of operation
- dew point and cleanliness of the compressed air supply
- pressure and frequency of air pulses used to clean the filters
- transfer efficiency