

Encore® HD/XD Pump

Customer Product Manual
Document Number 1605708-12
– English –
Issued 04/2025

**For parts and technical support, call the Industrial Coating
Solutions Customer Support Center at (800) 433-9319 or
contact your local Nordson representative.**

This document is subject to change without notice.
Check <http://emanuals.nordson.com> for the latest version.



Table of Contents

| | | | |
|--|-----------|--|-----------|
| Safety | 1 | Maintenance | 12 |
| Introduction..... | 1 | Troubleshooting | 13 |
| Qualified Personnel..... | 1 | Vacuum Check..... | 16 |
| Intended Use..... | 1 | Delivery Check..... | 18 |
| Regulations and Approvals..... | 1 | Suction Check..... | 18 |
| Personal Safety..... | 1 | Repair | 19 |
| Fire Safety..... | 2 | Fluidizing Tube Replacement..... | 19 |
| Grounding..... | 2 | Pump Disassembly..... | 20 |
| Action in the Event of a Malfunction..... | 2 | Pump Assembly..... | 22 |
| Disposal..... | 2 | Procedure..... | 22 |
| Description | 3 | Replacing Pump Gasket..... | 23 |
| Pump..... | 3 | Parts | 24 |
| Features and Benefits..... | 3 | Pump for Manual Systems..... | 25 |
| Pump Components..... | 4 | Pump for Automatic Systems..... | 25 |
| Theory of Operation..... | 5 | Kits for Both Manual and Automatic System Pumps..... | 25 |
| Pumping..... | 5 | Pump Service Kits..... | 25 |
| Purging..... | 6 | Fluidizing Tube Kits..... | 25 |
| Stage 1: Soft Purge to Spray Gun..... | 6 | Kits for Both Manual and Automatic System Pumps continued..... | 26 |
| Stage 2: Soft Purge to Feed Source..... | 6 | Gaskets..... | 26 |
| Stages 3 and 4: Hard Purge to Spray Gun and Feed Source..... | 6 | Miscellaneous Parts..... | 26 |
| Pump Port Functions..... | 7 | Kits for Manual System Pumps..... | 27 |
| Operation | 8 | Cap and Plug Kit..... | 27 |
| Specifications | 9 | Check Valve Kit..... | 27 |
| Installation | 10 | Kits for Automatic System Pumps..... | 28 |
| Pump Tubing Installation..... | 10 | Fluid Tube and Plug Kit..... | 28 |
| Standard 8 mm OD Poly (Semi-Rigid) Tubing..... | 10 | Manifold Kit..... | 29 |
| Flexible 8 mm OD Tubing..... | 10 | Kits for Automatic System Pumps continued..... | 30 |
| Antistatic 8.2 mm OD/5.6 mm ID Tubing..... | 10 | Grounding Kits..... | 30 |
| Installing the Pump Gasket..... | 10 | Air and Powder Tubing Part Numbers..... | 31 |
| Pump to Cabinet, Panel, or Housing..... | 11 | | |
| Pump Ground Check..... | 11 | | |

Contact Us

Nordson Corporation welcomes requests for information, comments, and inquiries about its products. General information about Nordson can be found on the Internet using the following address:

<http://www.nordson.com>.

<http://www.nordson.com/en/global-directory>

Notice

This is a Nordson Corporation publication which is protected by copyright. Original copyright date 2017. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Nordson Corporation. The information contained in this publication is subject to change without notice.

- Original Document -

Trademarks

Color-on-Demand, Encore, Nordson, and the Nordson logo are registered trademarks of Nordson Corporation. All other trademarks are the property of their respective owners.

Change Record

[illegible]

Safety

Introduction

Read and follow these safety instructions. Task- and equipment-specific warnings, cautions, and instructions are included in equipment documentation where appropriate.

Make sure all equipment documentation, including these instructions, is accessible to persons operating or servicing equipment.

Qualified Personnel

Equipment owners are responsible for making sure that Nordson equipment is installed, operated, and serviced by qualified personnel. Qualified personnel are those employees or contractors who are trained to safely perform their assigned tasks. They are familiar with all relevant safety rules and regulations and are physically capable of performing their assigned tasks.

Intended Use

Use of Nordson equipment in ways other than those described in the documentation supplied with the equipment may result in injury to persons or damage to property.

Some examples of unintended use of equipment include:

- using incompatible materials
- making unauthorized modifications
- removing or bypassing safety guards or interlocks
- using incompatible or damaged parts
- using unapproved auxiliary equipment
- operating equipment in excess of maximum ratings

Regulations and Approvals

Make sure all equipment is rated and approved for the environment in which it is used. Any approvals obtained for Nordson equipment will be voided if instructions for installation, operation, and service are not followed.

All phases of equipment installation must comply with all federal, state, and local codes.

Personal Safety

To prevent injury follow these instructions.

- Do not operate or service equipment unless you are qualified.
- Do not operate equipment unless safety guards, doors, or covers are intact and automatic interlocks are operating properly. Do not bypass or disarm any safety devices.
- Keep clear of moving equipment. Before adjusting or servicing any moving equipment, shut off the power supply and wait until the equipment comes to a complete stop. Lock out power and secure the equipment to prevent unexpected movement.
- Relieve (bleed off) hydraulic and pneumatic pressure before adjusting or servicing pressurized systems or components. Disconnect, lock out, and tag switches before servicing electrical equipment.
- Obtain and read Material Safety Data Sheets (SDS) for all materials used. Follow the manufacturer's instructions for safe handling and use of materials, and use recommended personal protection devices.
- To prevent injury, be aware of less-obvious dangers in the workplace that often cannot be completely eliminated, such as hot surfaces, sharp edges, energized electrical circuits, and moving parts that cannot be enclosed or otherwise guarded for practical reasons.

Fire Safety

To avoid a fire or explosion, follow these instructions.

- Ground all conductive equipment. Use only grounded air and fluid hoses. Check equipment and workpiece grounding devices regularly. Resistance to ground must not exceed one megohm.
- Shut down all equipment immediately if you notice static sparking or arcing. Do not restart the equipment until the cause has been identified and corrected.
- Do not smoke, weld, grind, or use open flames where flammable materials are being used or stored. Do not heat materials to temperatures above those recommended by the manufacturer. Make sure heat monitoring and limiting devices are working properly.
- Provide adequate ventilation to prevent dangerous concentrations of volatile particles or vapors. Refer to local codes or your material SDS for guidance.
- Do not disconnect live electrical circuits when working with flammable materials. Shut off power at a disconnect switch first to prevent sparking.
- Know where emergency stop buttons, shutoff valves, and fire extinguishers are located. If a fire starts in a spray booth, immediately shut off the spray system and exhaust fans.
- Shut off electrostatic power and ground the charging system before adjusting, cleaning, or repairing electrostatic equipment.
- Clean, maintain, test, and repair equipment according to the instructions in your equipment documentation.
- Use only replacement parts that are designed for use with original equipment. Contact your Nordson representative for parts information and advice.

Grounding



WARNING: Operating faulty electrostatic equipment is hazardous and can cause electrocution, fire, or explosion. Make resistance checks part of your periodic maintenance program. If you receive even a slight electrical shock or notice static sparking or arcing, shut down all electrical or electrostatic equipment immediately. Do not restart the equipment until the problem has been identified and corrected.

Grounding inside and around the booth openings must comply with NFPA requirements for Class II, Division 1 or 2 Hazardous Locations. Refer to NFPA 33, NFPA 70 (NEC articles 500, 502, and 516), and NFPA 77, latest conditions.

- All electrically conductive objects in the spray areas shall be electrically connected to ground with a resistance of not more than 1 megohm as measured with an instrument that applies at least 500 volts to the circuit being evaluated.
- Equipment to be grounded includes, but is not limited to, the floor of the spray area, operator platforms, hoppers, photoeye supports, and blow-off nozzles. Personnel working in the spray area must be grounded.
- There is a possible ignition potential from the charged human body. Personnel standing on a painted surface, such as an operator platform, or wearing non-conductive shoes, are not grounded. Personnel must wear shoes with conductive soles or use a ground strap to maintain a connection to ground when working with or around electrostatic equipment.
- Operators must maintain skin-to-handle contact between their hand and the gun handle to prevent shocks while operating manual electrostatic spray guns. If gloves must be worn, cut away the palm or fingers, wear electrically conductive gloves, or wear a grounding strap connected to the gun handle or other true earth ground.
- Shut off electrostatic power supplies and ground gun electrodes before making adjustments or cleaning powder spray guns.
- Connect all disconnected equipment, ground cables, and wires after servicing equipment.

Action in the Event of a Malfunction

If a system or any equipment in a system malfunctions, shut off the system immediately and perform the following steps:

- Disconnect and lock out system electrical power. Close hydraulic and pneumatic shutoff valves and relieve pressures.
- Identify the reason for the malfunction and correct it before restarting the system.

Disposal

Dispose of equipment and materials used in operation and servicing according to local codes. Description

Description

Pump

See Figure 1. The Encore HD and XD powder feed pump transports precise amounts of powder from a feed source to a powder spray gun.




Figure 1 Encore HD/XD Pump

Features and Benefits

- Standard pump (HD) has blue pinch valves, machined Tivar® Y blocks and standard porous tubes.
- Extreme duty pump (XD) is the same as the HD pump with high flow rate capacity.
- Higher powder output.
- Improved uniformity of powder output.
- Maintains high reliability of pinch valves.
- One screw maintenance design.
- Easier filter replacement.
- Improved gasket design.
- Centralized wear parts.
- Over torque protection.

Pump Components

See Figure 2.

| Item | Description | Function |
|------|-------------------------------------|--|
| 1 | Purge Air Fittings and Check Valves | Route high pressure purge air through the pump. Check valves prevent powder contamination of the purge valves. |
| 2 | Fluidizing Tubes | Porous cylinders that draw powder into the pump when a vacuum is applied, and force powder out of the pump when air pressure is applied. |
| 3 | Purge Manifold | Contains the fluidizing tubes, check valves, and air passages. |
| 4 | Upper Y Block | Interface between the pinch valves and the porous tubes; consists of two Y-shaped passages that join the inlet and outlet branches of either half of the pump. |
| 5 | Pinch Valves | Open and close to allow powder to be drawn in or dispensed out of the fluidizing tubes. |
| 6 | Pinch Valve Chamber Block | Houses the pinch valves. Made from clear plastic allowing for visual inspection of the pinch valves. |
| 7 | Lower Y Block | Connect the inlet and outlet fittings to the pinch valves on either half of the pump. |
| 8 | Inlet Fitting | Connects to the tubing leading from the power source |
| 9 | Outlet Fitting | Connects to the tubing leading to the powder spray gun |




Figure 2 Encore HD/XD Pump Components

Theory of Operation

Pumping

The Encore HD/XD pump consists of two halves that function identically. The halves alternately draw powder in and dispense powder out of the pump; while one half is drawing powder in, the other half is dispensing powder out.

Left Half Drawing Powder In

See Figure 3.

The left suction pinch valve is open, while the left delivery pinch valve is closed. Negative air pressure is applied to the left porous fluidizing tube, which draws powder in the inlet fitting, up the left side of the inlet manifold wear block, through the left suction pinch valve, and into the left fluidizing tube.

After the negative air pressure has been on for the specified time, the fluidizing tube's negative air pressure shuts off and the left suction pinch valve closes.

Right Half Dispensing Powder Out

See Figure 4.

The right suction pinch valve is closed, while the right delivery pinch valve is open. Positive air pressure is applied to the right porous fluidizing tube, which dispenses the powder out of the fluidizing tube, down the right delivery pinch valve, down the right side of the outlet manifold wear block, out the delivery fitting, and out to the tubing that leads to the powder spray gun.

As the sides complete these processes, they alternate. In the example explained above, the left half would now dispense powder out while the right half would draw powder in.

As each half dispenses powder out, the powder in the tubing blends together, resulting in a consistent flow of powder from the spray gun.




Figure 3 Left Side Drawing In, Right Side Dispensing

NOTE: Illustration is viewed from the right, rear of the pump.





Figure 4 Left Side Dispensing, Right Side Drawing In

Purging

See Figure 5. When the operator initiates a color change, the pump goes through a three-stage purge process.


Stage 1: Soft Purge to Spray Gun

The suction pinch valves close, while the delivery pinch valves remain open. Pump assist air pressure turns on, starting at a low pressure and building up to maximum pump assist pressure. The air dispenses powder out of both fluidizing tubes, through the powder delivery tubing and spray gun and out into the booth.



Stage 2: Soft Purge to Feed Source

The suction pinch valves are open, while the delivery pinch valves close. Pump assist air pressure turns on, starting at a low pressure and building up to maximum pump assist pressure. The air dispenses powder out of both fluidizing tubes, through the powder suction tubing, and back into the powder feed source.



Stages 3 and 4: Hard Purge to Spray Gun and Feed Source

The delivery pinch valves open. Pump assist air pressure turns on at maximum pressure, while pulses of line air pressure are sent down the purge air fittings at the tops of the fluidizing tubes. The pulses of air remove any powder that remains in the pump, spray gun, and suction and delivery tubing.

After the delivery side is purged, the delivery pinch valves close and the suction pinch valves open. The suction side is purged in the same way as the delivery side.




Figure 5 Purging Operation

Pump Port Functions

Figure 6 identifies the functions of the ports on the rear face of the pump.

| Position | Function |
|----------|---------------------------------|
| 1 | Right Side Suction Pinch Valve |
| 2 | Right Side Delivery Pinch Valve |
| 3 | Right Side Fluidizing Tube |
| 4 | Left Side Fluidizing Tube |
| 5 | Left Side Delivery Pinch Valve |
| 6 | Left Side Suction Pinch Valve |




Figure 6 Pump Port Functions

Operation



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



CAUTION: Do not adjust the regulators inside the pump cabinet. The regulators are factory set and should not be adjusted without guidance from your Nordson representative.

Pump operation is controlled through the spray gun controller. Refer to the *Operation* section of the applicable controller manual for specific instructions.

Pump operation is controlled by specifying a set point from 0-100 (which translates to a percent of flow) at the spray gun controller. At the pump, each set point results in a predefined cycle rate. Increasing the cycle rate increases the powder delivery rate. Decreasing the cycle rate decreases the powder delivery rate.

The manifold also has a spray gun pattern air flow control valve. spray gun pattern air is controlled by setting the flow rate (in either scfm or m3/hr) at the spray gun control unit.

NOTE: When the fluidizing tubes become clogged with powder, the powder delivery rate decreases. The spray gun controller will generate a fault to indicate this condition and notify you that it is time to replace the fluidizing tubes. Correct vacuum reading is (9-14 in. Hg).

Specifications

See Figure 7.

| Standard Pump Output (Maximum) | |
|---|--|
| HD: 80 lb/hour (600 g/min) | |
| XD: 100 lb/hour (750 g/min) | |
| Air Consumption | |
| Conveying Air | 12.5-31 l/min (0.438-1.1 scfm) |
| Gun Pattern Air | 6-57 l/min (0.2-2.0 scfm) |
| Total Consumption | 85-170 l/min (3-6 scfm) |
| Operating Air Pressure | |
| Pinch Valves | 37 psi (2.6 bar) |
| Flow Control (to pattern air/ pump assist) | 85 psi (5.9 bar) |
| Vacuum Generator | 80 psi (5.5 bar) |
| Powder Tubing | |
| Size | 8 mm OD x 6 mm ID |
| Length | Output: 18.3 m (60 ft) Input: 3.5-12 ft (1-3 m) |




Figure 7 Encore Pump Dimensions

Installation

Pump Tubing Installation

See Figure 8.

Standard 8 mm OD Poly (Semi-Rigid) Tubing

NOTE: Cut the semi-rigid tubing with a tubing cutter. Powder cross-contamination may result if the powder tubing is cut unevenly.

Install the semi-rigid tubing (3) into the lower Y block (1) and push to internal connector fitting (not shown).

Flexible 8 mm OD Tubing

NOTE: The barbed adapters used to connect flexible tubing to the pump are shipped with the pump.

1. Install the end of the adapter (2) into the lower Y block (1). Push to internal connect fitting.
2. Push the flexible powder tubing (4) over the barbed ending of the adapter (2).





Figure 8 Powder Tubing Installation

Antistatic 8.2 mm OD/5.6 mm ID Tubing

Refer to the *Encore HD Antistatic Tubing Grounding Kit* instruction sheet (1620023). Only used with Encore HD Antistatic Tubing Grounding Kit.

Installing the Pump Gasket

See Figure 9.

NOTE: If replacing a damaged gasket with a new gasket, refer to the *Replacing Pump Gasket* in the *Repair* section.

Remove the sticker backing from gasket (1) and place on the pump (2), aligning the holes of the gasket (1) with the port holes on the pump (2).

CAUTION: Ensure gasket is not covering any of the port holes on pump. A second gasket is provided with pumps as an additional spare.




Figure 9 Replacing the Pump Gasket

Pump to Cabinet, Panel, or Housing



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Follow the below instructions to install the pump to an existing pump panel.

See Figure 10.

1. Make sure that the gaskets on the pump (1), are not damaged, replace them if necessary.
2. Line the pump to the appropriate mounting location on the cabinet wall or housing (3). See *Pump Port Functions* in the *Description* section for port locations.
3. Secure the pump hand tight to the cabinet wall with the pump mounting hardware (2).
4. Tighten all hardware securely.




Figure 10 Pump Mounting to Cabinet

Pump Ground Check

NOTE: This procedure requires a multimeter.

See Figure 11

Perform a resistance test with a multimeter to ensure their are good ground connections.

1. Check for good ground connection between the manifold (1) and the screw (3) on the bottom of the pump. Resistance should be less than 1 MΩ.

If the resistance ground is high or there is no continuity, check the following:

- Improper torque - confirm the bottom screw (3) does not exceed 20-25 in-lb (2.3-2.8 N•m).
- Damaged upper Y block (2) or its custom O-ring (4) - replace both upper Y block and custom O-ring.




Figure 11 Pump Ground Check






Maintenance

Perform these maintenance procedures to keep your pump operating at peak efficiency.



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

NOTE: You may have to perform these procedures more or less frequently, depending on factors such as operator experience and type of powder used.

| Frequency | Part | Procedure |
|--|---|--|
| Daily Visual Inspection | <div>Pinch Valve Chamber Block</div>  | Inspect the pinch valve body for signs of powder leakage. If powder is seen in the pinch valve body or there are stress cracks in the pinch valves, replace the pinch valve chamber block and filter discs using HD or XD service kit. |
| Every Six Months or Each Time the Pump Is Disassembled | <div>Upper Y Block</div>  <div>Y Block Gasket</div>  <div>Lower Y Block</div>  | <p>NOTE: To reduce downtime, keep a spare upper manifold and set of lower wear blocks in stock to install while the other set is being cleaned.</p> <p>Disassemble the pump and inspect the lower Y block and upper Y block for signs of wear or impact fusion. Clean these parts in an ultrasonic cleaner if necessary.</p> <p>Replace the Y block gasket.</p> <p>NOTE: Y block gasket must be replaced any time the pump is disassembled.</p> <p>NOTE: Torque screw to 25-30 in.-lb (2.8-3.4 N•m) for assembly.</p> |
| | <div>Gasket</div>  | Inspect the gasket for damage. Replace if necessary. |

Troubleshooting



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

These troubleshooting procedures cover only the most common problems that you may encounter. If you cannot solve the problem with the information given here, call the Nordson Finishing Customer Support Center at (800) 433-9319 or contact your local Nordson representative for help.

| Problem | Possible Cause | Corrective Action |
|--|---|--|
| 1. Reduced powder output (pinch valves are opening and closing) | Blockage in the powder tubing to the spray gun. | Check the tubing for blockages. Purge the pump and spray gun. |
| | Defective pump air flow control valve. | Clean the pump air flow control valve. If the problem persists, replace the pump air flow control valve. |
| | Defective pump check valve. | Replace the check valves. |
| 2. Reduced powder output (pinch valves are not opening and closing) | Defective pinch valve. | Replace the pinch valve chamber block and filter discs using the HD or XD service kit. |
| | Defective solenoid valve. | Replace the solenoid valve. Refer to the applicable controller manual (per application) to determine which solenoid valve controls the affected pinch valve. |
| | Defective pump check valve. | Replace the check valves. |
| 3. Reduced powder input (loss of suction from feed source) | Blockage in the powder tubing from the feed source. | Check the tubing for blockages. Purge the pump and spray gun. |
| | Loss of vacuum at the vacuum generator. | Check the vacuum generator for contamination. Check the pump panel exhaust muffler. If the exhaust muffler appears to be plugged, replace it. |
| | Defective pump air flow control valve. | Clean the pump air flow control valve. If the problem persists, replace the pump air flow control valve. |
| 4. Spray gun fan pattern changes | Defective pattern air flow control valve | Clean the pattern air flow control valve. If the problem persists, replace the pattern air flow control valve. |
| <i>Continued...</i> | | |

| Problem | Possible Cause | Corrective Action |
|---|---|---|
| 5. Powder tubing too stiff | Spiral wrap too close to the spray gun. | Remove any spiral wrap that is within 24 in. of the spray gun handle. |
| 6. Streams of powder disrupting uniform spray pattern | Pattern air setting too low. | Increase the pattern air setpoint. |
| | Nozzle plugged. | Remove the nozzle, disassemble, and clean. |
| | Input air pressure too low. | Increase the input air pressure. |
| | Calibration constants incorrect. | Verify that the calibration constants on the manifold match what is entered in the manual spray gun controller. |
| 7. Powder delivery problems: Surging, fading, intermittent flow, low flow | Assist air compensation incorrect. | Increase or decrease the assist air compensation setting for the current preset. |
| | | Set the controller to a positive number if the spray gun is surging. |
| | | Set the controller to a negative number if the spray gun is fading. |
| | Fluidizing air pressure incorrect | Increase or decrease the fluidizing air pressure. The powder should be gently boiling. |
| | Powder damp or contaminated | Check the air driers and filter/separators. Check the powder in the feed hoppers and make sure it flows easily. |
| | Suction tubing too long. | Move the hoppers closer to the pump and shorten the suction tube length. The tube length must be less than 12 ft. from the powder feed. |
| | Suction or delivery tubing blocked or kinked. | Check the tubing. Blow out the tubing or replace it as necessary. |
| | Pump panel regulator pressure incorrect. | Adjust the regulators in the pump panel to the proper pressures. Refer to <i>Delivery Check</i> in <i>Troubleshooting</i> section for the proper pressure settings. |
| | Pump mount O-rings worn. | Replace the pump mount O-rings. Refer to your pickup tube instruction sheet or hopper manual for part numbers. |
| | Pickup tube not tightly threaded into pump mount. | Tighten the pickup tube into the pump mount. |
| | Loose connections. | Check the barbed tubing adapter for wear. Replace if damaged. Replace lower Y block. |
| | | Check for air leaks between the manifold and cabinet and between the manifold and pump. |
| | Improper delivery tubing arrangement. | The delivery tubing must be arranged in a 3-ft. coil and be parallel to the ground. |
| | Delivery tubing length is not to specification. | The delivery tubing can be either 20 or 60 ft in length from the pump to the spray gun depending on type of system. Check system documentation for applicable length. |
| | Problem with pump or pump control manifold. | Perform <i>Vacuum Check</i> procedure in <i>Troubleshooting</i> section. (Requires 0-30 in. Hg vacuum gauge.) |
| Continued... | | |

| Problem | Possible Cause | Corrective Action |
|--|--|--|
| 8. Pump is bad, requires repair (Suction Check) | Fluidizing tube blinded or plugged. | <p>Replace the fluidizing tubes.</p> <p>Verify O-rings are in place. If missing, powder buildup could occur in the muffler.</p> <p>NOTE: The filter discs must be installed flush with the aluminum body. If the discs are even slightly raised, the gasket will leak, causing the pump to malfunction.</p> |
| | Pinch valve leaking. | Replace the pinch valve chamber block and filter disks using the HD or XD service kit. |
| | Lower Y block plugged. | Remove and clean the lower Y blocks. |
| 9. Control manifold is bad, requires repairs (Suction Check) | Pump manifold valves 2 and 5 are contaminated with powder. | <p>Remove and inspect the valves. If they are contaminated, blow out the manifold and replace the valves.</p> <p>NOTE: If using an old harness with three positions, use the supplied adapter. If using a new harness with two positions, the supplied adapter can be discarded.</p> |
| | Vacuum generator is blocked. | <p>Remove and inspect the vacuum generator venturi nozzle. If it is blocked, blow it out or replace the vacuum generator.</p> <ol style="list-style-type: none"> 1. Remove the vacuum generator at the manifold. Check for vacuum with your finger. 2. Remove the vacuum generator vent hose at the bottom of the cabinet (inside). Trigger the spray gun on. Check for exhaust and increase the powder flow. 3. Check for proper direction of the check valve. |

Vacuum Check

NOTE: Procedure requires a 0-30 in. Hg vacuum gauge. See Figure 13 for reading examples.

1. Purge the pump and spray gun. Do not load a new color.
 2. Set the kV output to 0. Set the powder flow to 35%.
 3. Disconnect the powder tubing from the pump. Connect a vacuum gauge to the suction fitting or place your finger over the fitting as shown in Figure 12.
 4. Trigger the spray gun and watch the vacuum gauge or feel for the vacuum.
- For correct vacuum readings (9-14 in. Hg) on both sides of pump (or you feel less vacuum on one side of pump than the other), proceed to Delivery Check procedure.
 - For low vacuum readings (less than 8 in. Hg) on one side of pump (or you feel less vacuum on one side of pump than the other), proceed to Suction Check procedure.
 - For low vacuum readings (less than 8 in. Hg) on both sides of pump (or you feel weak or no vacuum on both sides of pump cycle), proceed to Suction Check procedure.




Figure 12 Vacuum Check Options




Figure 13 Vacuum Readings

Delivery Check

The problem is not in the pump or the control manifold. Check for problems in delivery tubing or suction tubing.

1. Reconnect the delivery tubing to the pump.
2. Trigger the spray gun and observe the vacuum gauge. The correct vacuum reading ranges from 9-14 in. Hg.

If the problem is in the delivery tubing or spray gun:

1. Clean or replace the delivery tubing.
2. Check the spray gun lock nut O-ring and replace it if it is missing or damaged.
3. Remove the nozzle and powder tubing adapter from the spray gun and clean or replace it.

If the problem is in the suction tubing, fittings, pickup tube, or powder:

1. Connect the suction tubing as shown in Figure 14.
2. Trigger the gun and observe the powder flow.

Suction Check

Low vacuum reading: less than 8 in. Hg in one or both sides of the pump

The problem is not in the pump or control manifold.

1. Remove the pump and replace it with a functioning pump.
2. Connect the vacuum gauge to the pump suction fitting.
3. Trigger the spray gun and observe the vacuum gauge.
 - If the problem disappears, then check the suction tubing fittings and adapter O-rings. Clean the pickup tube. For Color-on-Demand® systems, proceed to procedure on page 19.
 - If the problem persists, the suction tubing is blocked. Replace the suction tubing.
 - If the problem disappears, the original pump was bad. See *Pump is bad, requires repair* in the *Troubleshooting* table.
 - If the problem remains, the pump control manifold is bad. See *Pump is bad, requires repair* in the *Troubleshooting*.




Figure 14 Tubing Connections

Repair



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Fluidizing Tube Replacement



WARNING: Shut off and relieve system air pressure before performing the following tasks. Failure to relieve air pressure may result in personal injury.

1. See Figure 15. Perform a color change to remove old powder from the pump, then relieve the system air pressure and disconnect the purge air tubing.




Figure 15 Removing the Purge Air Tubing

2. See Figure 16. Loosen the fluidizing tube access plug and pull the fluidizing tube straight out of the pump body.




Figure 16 Loosening the Fluidizing Tubes

3. See Figure 17. Pull the old fluidizing tube off the access plug, then seat the new fluidizing tube against the red O-ring.




Figure 17 Removing the Tube from the Access Plugs

4. See Figure 18. Install the fluidizing tube assemblies into the pump body. Tighten the access plugs, then reconnect the purge air tubing.




Figure 18 Reinstalling the Purge Air Tubing

Pump Disassembly

To reduce downtime, keep a spare pump in stock to replace a pump that is being repaired.

NOTE: Any time the pump is disassembled, the Y block gasket (item 19 in Figure 20) must be replaced.



WARNING: Shut off and relieve system air pressure before performing the following tasks. Failure to relieve air pressure may result in personal injury.

NOTE: Tag all air and powder tubing before disconnecting from the pump.

1. See Figure 19. Disconnect the purge air lines from the top of the retrofit pump (1) where applicable.
2. See Figure 20. Disconnect the inlet (2) and outlet powder tubing (3) from the bottom of the pump.
3. Remove the cabinet mounting hardware securing the pump to the pump panel (4) and move the pump to a clean work surface.
4. See Figure 21. Starting with the fluidizing tubes, disassemble the pump as shown. Gaskets that are glued on do not need to be removed unless they are damaged. Refer to *Replacing Pump Gasket* in the *Repair* section if replacement is needed.




Figure 19 Retrofit Pump Disassemble Preparation




Figure 20 Standard Pump Disassemble Preparation




Figure 21 Pump Disassembly (Encore HD Shown)

- | | | |
|-------------------------|-------------------------|-----------------------------------|
| 1. Fitting caps (2) | 9. Purge manifold (1) | 16. Filter discs (4) |
| 2. O-Rings (2) | 10. Manifold gasket (1) | 17. Pinch valve chamber block (1) |
| 3. Check valves (2) | 11. Block seal (1) | 18. Y block gasket (1) |
| 4. O-rings (2) | 12. Upper Y block (1) | 19. Lower Y block (1) |
| 5. Access plugs (2) | 13. Lock washers (12) | 20. Hose barbs (2) |
| 6. O-rings (2) | 14. Screws, M4 x 25 (6) | 21. Screw, M5 x 85 (1) |
| 7. Fluidizing tubes (2) | 15. O-rings (2) | |
| 8. O-rings (2) | | |

Pump Assembly



CAUTION: Follow the assembly order and specifications shown. Pump damage may occur if you do not carefully follow the assembly instructions.

NOTE: Any time the pump is disassembled, the Y block gasket (item 10 in Figure 23) must be replaced.

Procedure

1. See Figure 22. Place the customized O-ring (1) into the upper Y block (2) as shown, then fasten the upper Y block to the purge manifold housing (3) with the provided hardware.




Figure 22 Assemble the Lower Y Block to Purge Manifold

2. See Figure 23. Assemble filter discs (4) and O-rings (5) into pinch valve chamber block (6).




Figure 23 Assemble the Pinch Valve Housing

3. See Figure 24. Assemble gasket (8) over lower Y block (9), then thread long screw (10) through the lower y block and into the pinch valve housing, upper Y block and purge manifold. Torque screw to 25-30 in.-lb (2.8-3.4 N•m).




Figure 24 Assemble Gasket and Lower Y Block

4. See Figure 25. Assemble the check valves (13) O-rings (12) access plugs (14), and fitting caps (11) together before replacing the fluidizing tubes (16). Then, once that is complete, assemble the complete access plugs (15) and additional O-rings onto the fluidizing tubes (16).




Figure 25 Assemble Fittings to Fluidizing Tubes

- See Figure 26. Insert the assembled fluidizing tube (17) into the top of the purge manifold (18). Snug fit tubes to manifold.




Figure 26 Fasten Fluidizing Tubes into Manifold

- See Figure 24. After the pump is assembled, completely tighten the long screw (10) to fit all components together completely.
- Mount the pump to the cabinet before assembling the feed tubing to the ports in the bottom of the pump. Refer to *Installation* on page 10 for more information.




Figure 27 Assemble Tubing into Lower Y Block

Replacing Pump Gasket

- See Figure 28. Remove pump gasket from the pump.
- Using an industrial citrus based adhesive remover and plastic scraper, remove any residual adhesive left from old gasket from the pump. Clean any debris from port holes.
- Remove the sticker backing from the new gasket and place on the pump, aligning the holes of the gasket with the port holes on the pump.



CAUTION: Ensure gasket is not covering any of the port holes on pump. A second gasket is provided with pumps as an additional spare.




Figure 28 Replacing Pump Gasket

Parts

To order parts, call the Nordson Industrial Coating Systems Customer Support Center at (800) 433-9319 or contact your local Nordson representative.

See Figure 29 and the following parts lists.




Figure 29 Encore HD and XD Standard Parts (shown with manual system pumps)

Pump for Manual Systems

| Part | Description | Quantity | Note |
|---------|--------------------------|----------|------|
| 1605940 | PUMP ASSEMBLY, Encore HD | — | |
| 1611247 | PUMP ASSEMBLY, Encore XD | — | |

Pump for Automatic Systems

| Part | Description | Quantity | Note |
|---------|-----------------------------------|----------|------|
| 1612248 | PUMP, Encore HD retrofit assembly | | |
| 1612250 | PUMP, Encore XD retrofit assembly | | |

Kits for Both Manual and Automatic System Pumps

See Figure 29 and the following parts list.

Pump Service Kits

| Item | Description | Quantity | Note |
|--|--|----------|------|
| 1625730 | - KIT, service, HD pump | — | |
| 1625731 | - KIT, service, XD pump | — | |
| 4 | • O-RING, -012, 0.375 x 0.500 x 0.063 in., silicone, 70 Duro | 4 | |
| 6 | • O-RING, -013, 0.437 x 0.562 x 0.063 in., silicone, 70 Duro | 4 | |
| 11 | • Fluidizing tube | 2 | |
| 12 | • O-RING, -017, 0.688 x 0.813 x 0.062 in., silicone, 70 Duro | 2 | |
| 14 | • DISC, filter, pump | 4 | |
| 18 | • GASKET, conductive, lower Y block | 1 | A |
| 19 | • BLOCK, pinch valve chamber | 1 | B |
| NOTE: A. Must be replaced any time pump is disassembled. | | | |
| B. Pinch valves come preassembled in chamber block. | | | |

Fluidizing Tube Kits

See Figure 29 and the following parts list.

| Item | Description | Quantity | Note |
|---------|--|----------|------|
| 1057258 | - KIT, HDLV pump fluid tube, 4 pack, HD pump | — | |
| 1093557 | - KIT, hi-flow fluid tube, HDLV pump, 4 pack, XD pump | — | |
| 6 | • O-RING, -013, 0.437 x 0.562 x 0.063 in., silicone, 70 Duro | 8 | |
| 11 | • Fluidizing tube | 4 | |

Kits for Both Manual and Automatic System Pumps continued

Gaskets

| Item | Part | Description | Quantity | Note |
|------|---------|---|----------|------|
| 7 | 1625736 | KIT, conductive gasket, upper Y-block, 4 pack, HD/XD pump | 4 pack | |
| 13 | 1625735 | KIT, manifold gasket, 8 pack, HD/XD pump | 8 pack | |
| 18 | 1625734 | KIT, conductive lower gasket, 4 pack, HD/XD pump | 4 pack | |

Miscellaneous Parts

| Item | Part | Description | Quantity | Note |
|------|---------|---|----------|------|
| 9 | UA | WASHER, lock, split M4, zinc plated steel, DIN 7980 | 1 | |
| 10 | UA | SCREW, socket cap M4 x 25, zinc plated steel, DIN 912 | 1 | |
| 15 | 1078006 | ADAPTER, tube, barb, powder | 1 | |
| 16 | 1619013 | SCREW, socket M5, shoulder, stainless steel, HD pump | 1 | A |
| | 1620035 | SCREW, socket, M5, shoulder, blue, stainless steel, XD pump | 1 | A |
| 17 | 1626212 | BLOCK, lower Y assembly, pump, Encore HD Tivar | 1 | A |

NOTE: A. If removing screw, replace lower conductive gasket (18).

UA: Unavailable for purchase through Nordson. Contact local distributor or local source.

Kits for Manual System Pumps

See Figure 29 and the following parts list.

Cap and Plug Kit

| Item | Description | Quantity | Note |
|---|--|----------|------|
| 1625732 - KIT, cap and plug, HD/XD pump | | — | |
| 1 | • PLUG, fluid | 2 | |
| 2 | • O-RING, -014, 0.500 x 0.625 x 0.063 in., silicone, 70 Duro | 2 | |
| 4 | • O-RING, -012, 0.375 x 0.500 x 0.063 in., silicone, 70 Duro | 2 | |
| 5 | • PLUG, fluid access | 2 | |
| 5a | • O-RING, -015, 0.563 x 0.688 x 0.063 in., silicone, 70 Duro | 2 | |
| 6 | • O-RING, -013, 0.437 x 0.562 x 0.063 in., silicone, 70 Duro | 2 | |

Check Valve Kit

| Item | Description | Quantity | Note |
|--|--|----------|------|
| 1625733 - KIT, check valve, HD/XD pump | | — | |
| 3 | • VALVE ASSEMBLY, check, Encore HD | 2 | |
| 4 | • O-RING, -012, 0.375 x 0.500 x 0.063 in., silicone, 70 Duro | 2 | |

Kits for Automatic System Pumps

Fluid Tube and Plug Kit

See Figure 30 and the following parts list.




Figure 30 Retrofit Fluid Tube and Plug Kit

| Item | Description | Quantity | Note |
|---|--|----------|------|
| 1610812 - PLUG, retrofit, fluid tube, Encore HD | | — | |
| 1 | • CONNECTOR, 10 mm T x 3/8 uni | 1 | |
| 2 | • CHECK VALVE ASSEMBLY, pump | 1 | |
| 3 | • PLUG, retro, fluid tube access, Encore HD | 1 | |
| 4 | • O-RING, -012, 0.375 x 0.500 x 0.063 in., silicone, 70 Duro | 1 | |
| 6 | • O-RING, -013, 0.437 x 0.562 x 0.063 in., silicone, 70 Duro | 1 | |
| 1078161 - KIT, service, check valve, pump Prodigy | | — | |
| 2 | • CHECK VAVLE ASSEMBLY, pump, Prodigy | 2 | |

Manifold Kit

See Figure 31 and the following parts list.

| Item | Description | Quantity | Note |
|---|--|----------|------|
| 1616440 - KIT, Encore to Prodigy manifold | | — | |
| 1 | • ADAPTER, Encore, HD pump to Prodigy manifold | 1 | |
| 2 | • GASKET, adapter, Encore HD pump to Prodigy | 1 | |
| 1625737 - KIT, adapter gasket, 8 pack, HD/XD pump | | — | |
| 2 | • GASKET, adapter, Encore HD pump to Prodigy | 8 | |




Figure 31 Manifold Kit

Kits for Automatic System Pumps continued

Grounding Kits

See Figure 32 and the following parts list.

| Item | Description | Quantity | Note |
|--|---|----------|------|
| 1621252 - KIT, ground, pump controller, Encore HD | | — | |
| 1 | • JUMPER, ground, 72 in. | 4 | |
| 2 | • LUG, ground, dual tap | 1 | |
| 3 | • SCREW, socket set, 1/4-20 x 0.50, flat zinc | 2 | |
| 4 | • NUT, hex, M5, brass | 1 | |
| 5 | • WASHER, lock, M, split, M5, steel, zinc | 9 | |
| 6 | • WASHER, flat, M5, brass | 9 | |
| 7 | • TAG, ground | 1 | |
| 8 | • SCREW, pan, slot, M5 x 16, brass | 8 | |
| 9 | • FITTING, barb, 8 mm, anitstatic hose, stainless steel | 8 | |
| 10 | • GROUND BLOCK, right, hose, pump, Encore | 8 | |
| 11 | • GROUND BLOCK, left, hose, pump, Encore | 8 | |
| 1620013 - KIT GROUND PUMP, Encore, antistatic tubing | | — | |
| 9 | • FITTING, barb, 8 mm, anitstatic hose, stainless steel | 1 | |
| 11 | • GROUND BLOCK, left, hose, pump, Encore | 1 | |
| 1 | • JUMPER, ground, 72 in. | 1 | |
| 6 | • WASHER, flat, M5, brass | 1 | |
| 5 | • WASHER, lock, M, split, M5, steel, zinc | 1 | |
| 8 | • SCREW, pan, slot, M5 x 16, brass | 1 | |
| 10 | • GROUND BLOCK, right, hose, pump, Encore | 1 | |




Figure 32 Grounding Kits

Air and Powder Tubing Part Numbers

See Figure 33 and the following parts list..




Figure 33 Air and Powder Tubing Part Numbers

| Item | Part | Description | Note |
|------|---------|---|------|
| 1 | 900740 | 6.5 mm x 10 mm OD, blue polyurethane | D |
| 2 | 1613849 | 6 mm ID x 8 mm OD, polyolefin, 40 m | A |
| 2 | 1613850 | 6 mm ID x 8 mm OD, polyolefin, 160 m | A |
| 2 | 1615026 | 6 mm ID x 8 mm OD, polyurethane 60 ft | B |
| 2 | 1606695 | 6 mm ID x 8 mm OD, polyurethane 500 ft | B |
| 2 | 173101 | 6 mm ID x 8 mm OD, natural, polyethylene | B, E |
| 2 | 1620002 | TUBING, powder, antistatic, 5.6 x 8.2 mm 160 m roll | C |
| 2 | 7035356 | TUBING, powder, antistatic, 5.6 x 8.2 mm 23 m roll | C |

NOTE: A. Barbed fitting required.

B. Optional powder hose to use in place of the standard polyolefin.

C. Encore HD antistatic tubing for eliminating turbo-charging. Must be used with Encore pump grounding kits 1620013 and 1621252.

D. For purge air.

E. For suction line.

EU DECLARATION of Conformity

Product: Encore HD High Density Powder Pump

Models: Encore HD, Encore HD+, Encore XD Pump

Description: These pumps allow for low velocity air / high density powder and are used to deliver powder coating material to the applicator. These pumps are labeled for use in a Zone 22 area. The Encore HD is the standard Model. The Encore HD+ has higher flow then the standard. The Encore XD is for high abrasive powders and powder which have tendency to impact fuse.

Applicable Directives:

2006/42/EC - Machinery Directive

2014/34/EU - ATEX Directive

Standards Used for Compliance:

EN1127-1 EN/ISO12100 EN/ISO80079-36 EN/ISO80079-37

Principles:

This product has been designed & manufactured according to the directives & standards / norms described above.

Markings and Certs:

Flammable Atmosphere Marking: Ex h IIIC T40°C Dc

Tech File: Notified Body #2813, Sira CSA Group, Netherlands B.V.

DNV ISO9001

ATEX Quality Notification – Baseefa Fimko Oy, Helsinki Finland



Date: 16March2021

Jeremy Krone
Engineering Development
Industrial Coating Systems
Amherst, Ohio, USA

Nordson Authorized Representative in the EU

Contact: Operations Manager
Industrial Coating Systems
Nordson Deutschland GmbH
Heinrich-Hertz-StraBe 42-44
D-40699 Erkrath



Nordson Corporation • 100 Nordson Dr, Amherst, Ohio 44001. USA

DOC14045-04

UK DECLARATION of Conformity

This Declaration is issued under the sole responsibility of the manufacture.

Product: Encore HD High Density Powder Pump

Models: Encore HD, Encore HD+, Encore XD Pump

Description: These pumps allow for low velocity air / high density powder and are used to deliver powder coating material to the applicator. These pumps are labeled for use in a Zone 22 area. The Encore HD is the standard Model. The Encore HD+ has higher flow then the standard. The Encore XD is for high abrasive powders and powder which have tendency to impact fuse.

Applicable UK Regulations:

Supply Machinery Safety 2008

Equipment & Protective Systems Intended for use in Potentially Explosive Atmosphere Regulation 2016

Standards Used for Compliance:

EN1127-1 EN/ISO12100 EN/ISO80079-36 EN/ISO80079-37

Principles:

This product has been designed & manufactured according to the directives & standards / norms described above.

Markings and Certs:

Flammable Atmosphere Marking: Ex h IIIC T40°C Dc

Tech File: Notified Body #2813, Sira CSA Group, Netherlands B.V.

DNV ISO9001

- SGS Baseefa NB 1180 (Buxton, Derbyshire, UK)



Date: 08FEB22

Jeremy Krone
Supervisor Product Development Engineering
Industrial Coating Systems
Amherst, Ohio, USA

Nordson Authorized Representative in the UK

Contact: Technical Support Engineer
Nordson UK Ltd.; Unit 10 Longstone Road
Heald Green; Manchester, M22 5LB.
England



Nordson Corporation • 100 Nordson Dr, Amherst, Ohio 44001. USA

DOC14060-02