

Quick Start Guide P/N 1607389-02

iTrax[®] PC Replacement

Use this procedure to upload the current software onto a new iTrax[®] PC. To access the newest software, contact ICS Technical Support at <u>ics.tech.support@nordson.com</u>.



Follow the safety, operation, and maintenance instructions in the accompanying Operator Card and Product Manual.

Pre-Software Installation



Prepare to Install

1. Be sure all power to the control unit containing all of the iTrax modules is OFF.

2. Install and wire the iTrax SM, SC, and PRx modules using the included instructions.



Install the Network Wiring Install the network wiring and included terminating resistor into the DB-9 connector. Assemble the connector halves. Disconnect the Softing Network Interface from the USB until after the Softing Drivers are installed.



Connect the other end of the network wiring to the main terminal block in the control unit.

Refer to your system drawing for specific wiring instructions.



Installing Software onto iTrax PC



Locate Flash Drive

Locate flash drive or CD with the current software. If the original software cannot be found, contact your Nordson container specialist.





Copying Flash Drive Files

NOTE: Before installing iTrax firmware or software, copy the programs from the blue flash drive to the new iTrax PC. The flash drive contains all of the software needed to operate the iTrax system and modules.

Create a folder on the C:/drive of the iTrax PC. Name the folder "iTrax Blue Flash Drive."

Faceback	rganize • 🧊 Open Include in library •	Share with Burn New folder				800 -	. 0
Bitspin Appn MODELS (ALM) Feature	Favorites	Name	Date modified	Туре	Size		
§ contraction (1999) Section (19	Desktop	Apps	1/9/2014 1:06 AM	File folder			
ReadPrice Failure 20202331.001 Failure Uberie 10/0012531.001 Failure Compute 10/001253.0100 Failure Compute 10/00125.0100 Failure Failure 10/0012000 Failure	Downloads	🔒 dell	1/9/2014 1:26 AM	File folder			
Inde	3 Recent Places	Hotfix	2/28/2012 5:51 PM	File folder			
Ubanie Biorage 6.//2013 28 / W Technikar Compart 1.0/2013 28 / W Technikar Compart 0.000 (M) 0.000 (M) Technikar Compart 0.000 (M) 0.000 (M) Technikar Compart 0.000 (M) 0.000 (M) Technikar Nature 0.000 (M) 0.000 (M) Technikar Feddam 0.000 (M) 1.000 (M) Technikar Feddam 1.0000 (M) 1.0000 (M) Technikar Feddam 1.0000 (M)		🗼 Intel	1/9/2014 1:52 AM	File folder			
Comparing Find Read Read Note 10,0003150 RM Find Name & Oblik (K) Comparing	2 Libraries	🔒 lacomp	4/4/2014 2:40 PM	File folder			
Computer MX0014 65/20151121 AM Finiture Grade AC Grade AC 10/201123 AM Finiture Manual Grade AC 10/201123 AM Finiture Manual Grade AC 0.10/201123 AM Finiture Participant 0.00/201124 AM Finiture Participant 0.00/201124 AM Finiture Participant 0.00/201124 AM Finiture Participant Finiture 0.00/20124 AM Finiture Parinterimeter 0.00/20124 AM		🌲 iTrax Blue Flash Drive	1/8/2015 1:55 PM	File folder			
	Computer	J LMD2054	4/5/2014 11:28 AM	File folder			
MRMT 10/0711-327_AM Finitum Finitum 4/0211-310_AM Finitum Finitum 0.10011-307_AM Finitum Finitum 0.10011-307_AM Finitum Finitum 0.10011-307_AM Finitum Finitum 0.00012-307_AM Finitum	SDisk (C:)	🔒 Logs	1/9/2014 12:36 AM	File folder			
National Reformant Constant Co		MININT	1/9/2014 2:42 AM	File folder			
FindLag 7.02.00011.20.001 FinLag FinLag Program 1.00011.01.001 FinLag FinLag Program 1.00011.01.001 FinLag FinLag Vietnes 1.00011.01.01.01 FinLag FinLag Vietnes 1.00011.01.01 FinLag FinLag Vietnes 1.00011.01.01 FinLag FinLag Vietnes 1.00010.01.01.01 FinLag Bin	Network	😹 Nordson	4/14/2014 7:49 PM	File folder			
Bypegene Files 1.0/0714.10 /M. File Indian Bypegene Files (add) 1.0/073.22 /M. File Indian Others 6.0/073.22 /M. File Indian Byteme Eine (add) 1.0/073.22 /M. File Indian Byteme Eine (add) 1.0/073.22 /M. File Indian Byteme Eine (add) 1.0/073.22 /M. File Indian Byteme Eine (add) 1.0/073.21 /M. File Indian		PerfLogs	7/13/2009 11:20 PM	File folder			
Program File (a) 12//2013 22 PM File folior Uniting 4.07/2013 30 PM File folior Uniting 12//2013 00 PM File folior Windows 12//2013 00 PM File folior Windows 12//2013 00 PM File folior Windows 12//2013 00 PM File folior		🌲 Program Files	1/9/2014 1:05 AM	File folder			
Others 4.1/2731451 2M Tite Instance 0.006min 1.4/2731451 2M Tite Instance 0.006min 1.4/273142 2M Tite Instance 0.006min 1.4/2731241 2M Tite Instance 0.006min 1.2/173142 2M Tite Instance 0.006min 1.2/173142 2M Tite Instance 0.006min 1.2/173142 2M Tite Instance		Program Files (x86)	1/8/2015 2:22 PM	File folder			
Wilsim 1/2/2015 L104 AM / File Inform Windows 1/2/2015 D174 Application status Bill Middle 1/2/2015 D174 Application status BM KEI		🌲 Users	4/4/2014 8:53 AM	File folder			
Windows 1/k7005 221 PM File folder mediatio.dt 1/2/2000 5037 PM Application intens BMA KII		🌲 Utilities	1/8/2015 11:49 AM	File folder			
modia00.dl 12/1/2000 10:37 PM Application extens 884 KB MODMLRD2 AM Configuration 12 KB		Windows	1/8/2015 2:21 PM	File folder			
All COM 852 MM Conference 1 MR		🐋 msdia80.dll	12/1/2006 10:37 PM	Application extens	884 KB		
Comparation set. 1 kb		 tmuninet 	4/4/2014 8:53 AM	Configuration sett	1 KB		
En annanna an		 tmuninet 	4/4/2014 8:53 AM	Configuration sett	1 KB		



1. Plug the flash drive in the USB drive and navigate to its drive.

2. Copy all folders and files from the flash drive to the *iTrax Blue Flash Drive* folder.

3. Verify that the contents of the newly created folder match those from the flash drive.

4. Properly remove the blue iTrax USB flash drive and store in a safe place.





C:/iTraxBlueFlashDrive/softing_CANproUSB. Run the file.



When the *Softing CAN Interface Manager* appears (as shown), select CLOSE.













Configure Hardware

1. Start the OPC Server is and then the OPC Local Client 1 using the shortcuts on the Windows desktop.

2. Select *Display Help* from the main toolbar to obtain assistance in configuring the iTrax system.

NOTE: Refer to the Setup Procedure topic under OI and Gun Setup to add guns and set up the Operator Interface.





Calibrate Spray Monitors

When the coating system is producing acceptable product, calibrate the spray monitors and enable faults as needed.



Reprogramming iTrax Spray Monitor Modules



Shutting Down iTrax Operator Interface

Before starting the CAN Programmer, close the CanWorks iTrax Operator Interface.

NOTE: The CanWorks iTrax Operator Interface may take several seconds to close.





Shutting Down the iTrax Server

1. Once the operator interface is closed, close the *CanWorks OPC Server*.

2. Verify that there are no active iTrax application icons on the taskbar.





Programming the Module

1. If the iTrax modules are OFF, power the modules ON. If the iTrax modules are ON, cycle the power OFF and back ON.

2. Select the Nordson CAN Programmer icon on the iTrax PC Desktop to open the CAN Programmer main screen.

3. Select *iTrax Monitor* from the list box (6). Once selected, the module address listing (7) will show all of the iTrax monitors in the system. The list displays each module's current software version and serial number.

4. Navigate to C:/JTAG/iTraxSM (2) folder.

5. Select the S-record file *iTrax0520.S* (1) and the file name appears in the location field (3).

6. Select the modules to be updated in the module address listing (7).

NOTE: If selecting all modules, select *All* (8) to quickly select all in the list.

7. Select *All at Once* (5) to allow all selected modules to update



E

Programming the Module (contd)

8. Select <i>Prog</i> (9) at the bottom of the screen. Reprogramming the module should take about 1 minute. The progress bar will display indicating progress.			
9. After programming is complete, select OK and exit the programmer.	Verdson - Container CAN Programmer	C:L.J/TAG/iTrax5M C Individually (unicate) (Trax0520.5 C Individually (unicate) (Trax0520.5 C Individually (unicate)	
10. Cycle 24 VDC power to all of the iTrax Modules. Cycling ensures that all iTrax modules are re-booted and running the new code.	Common Common	Address Stru. Version Data Version Serial Humber 65 4.8 0.4 P50500275 5 66 4.8 0.4 P50500275 5 67 4.8 0.4 P50500259 5 68 4.8 0.4 P50500259 5 69 4.8 0.4 P50500259 5 70 4.8 0.4 P505002500 5	<u> </u>
and the <i>iTrax OPC Server</i> application on the PC.	Trevensor	י Who י Nose י All י Prog & Set ע Start ע View	
12. The information screen on the iTrax operator interface can be used to verify that the reprogrammed module now has the correct software version.	<u> </u>	9	_

Minimum System Requirements

Type II	BM-compatible personal or ndustrial computer
Operating System V	Vindows 7 or XP with the most
C	urrent Service Pack
Processor F	Pentium 4, 2.2 Ghz
(1	recommended) Pentium III,
8	50 MHZ (minimum: for up to
1	0 spray monitors)
RAM5	512 MB (minimum)
Video	SVGA, 2 MB (minimum), 1024
Х	(768, 16-bit color

Hard Drive Space	10 MB for program software
	10 GB for data storage
Removable Media	CD-ROM drive
Ports	USB (v. 1.0 or 2.0), Ethernet
nput Device	Touch screen or keyboard and
	mouse
CAN Adapter	One free USB port (v. 1.0 or
	2.0)

www.nordson.com 800.626.8303 www.enordson.com http://emanuals.nordson.com www.nordson.com

Issued 09/19

Original copyright date 2015. Encore, Nordson and the Nordson logo are registered trademarks of Nordson Corporation.