

iControl[®] Prodigy[®] Console Hardware Manual

Installation, Troubleshooting, Repair, Parts

Part 1056419A05

Issued 3/10

**For parts and technical support, call the
Finishing Customer Support Center at (800) 433-9319.**

This document is subject to change without notice.
Check <http://emanuals.nordson.com> for the latest version.



NORDSON CORPORATION • AMHERST, OHIO • USA

Contact Us

Nordson Corporation welcomes requests for information, comments, and inquiries about its products. General information about Nordson can be found on the Internet using the following address:
<http://www.nordson.com>.

Address all correspondence to:

Nordson Corporation
Attn: Customer Service
555 Jackson Street
Amherst, OH 44001

Notice

This is a Nordson Corporation publication which is protected by copyright. Original copyright date 2004. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Nordson Corporation. The information contained in this publication is subject to change without notice.

Trademarks

iControl, Sure Coat, Prodigy, Versa-Spray, Tribomatic, Nordson, and the Nordson logo are registered trademarks of Nordson Corporation.

CompactFlash is a registered trademark of SanDisk Corporation.

Table of Contents

Safety	1-1
Introduction	1-1
Qualified Personnel	1-1
Intended Use	1-1
Regulations and Approvals	1-1
Personal Safety	1-2
Fire Safety	1-2
Grounding	1-3
Action in the Event of a Malfunction	1-3
Disposal	1-3
Safety Labels	1-4
 System Overview	 2-1
iControl System Manuals	2-1
Console and System Hardware and Software	2-2
Options	2-2
Operator Interface	2-4
Interlock Keyswitch Functions	2-4
CAN and Ethernet Networks	2-5
Digital Inputs	2-5
Encoder	2-5
Gun Control Cards	2-6
Gun Pump Control	2-6
Specifications	2-6
General	2-6
Prodigy Pump and Spray Gun Pattern Air Quality	2-7
Approvals	2-7
Approved Program and User Data Cards	2-7

Installation	3-1
Introduction	3-1
Hardware Installation	3-1
CAN Network Connections and Settings	3-2
iControl Console CAN Address and Termination Settings	3-3
Manual Gun Controller Addresses	3-3
Manual Gun Controller Termination	3-3
Pump Control Card Addresses	3-4
Power, Ground, and Relay Connections	3-4
Console Power Cable Connections	3-4
Conveyor Interlock and Remote Lockout	3-5
Grounding	3-6
PE (Protective Earth) Grounding	3-6
Electrostatic Grounding	3-6
Gun Current Path	3-7
ESD Ground Procedures and Equipment	3-8
Encoder, Zone, and Part ID Connections	3-8
25-Conductor Cable Connections	3-9
Switching Inputs to Sourcing	3-9
Conveyor Encoder Connections	3-10
Photoeye Connections and Configuration	3-10
Junction Box Power Requirements	3-10
Scanner Cable Connections	3-10
Discrete Scanner Connections	3-10
Analog Scanner Connections	3-11
Customer-Supplied Part ID System Connections	3-12
Ethernet Network Connections	3-13
iControl Console to Network Interface Box	3-14
Ethernet Switch to Ethernet Devices	3-14
MAC Addresses	3-14
Connecting Termination Modules to Ethernet Cables	3-15
Ethernet Termination Standards	3-17
Gun Cable and Feed Tubing Connections	3-18
Odd Number of Guns	3-18
Program and User Data Storage	3-19
Touch Screen Calibration	3-20
System Upgrades	3-20

Troubleshooting	4-1
Error Codes and Alarm Messages	4-1
CAN Network Errors	4-6
Gun Card Troubleshooting	4-7
Gun Card Error Codes and Fault Codes	4-7
Gun Card LEDs	4-9
Prodigy HDLV Pump Troubleshooting	4-11
Pump Controller Error Codes	4-11
Air Flow Re-Zero Procedure	4-12
Re-Zero Procedure	4-12
Remote I/O (Ethernet) Network Troubleshooting	4-14
In/Out Positioner Troubleshooting	4-16
In/Out Positioner Error Code Troubleshooting	4-16
Other In/Out Positioner Troubleshooting	4-19
Reciprocator Troubleshooting	4-23
Reciprocator Error Code Troubleshooting	4-23
Other Reciprocator Troubleshooting	4-26
Other Fault Messages and Conditions	4-29
Photoeye, Encoder, and Interlock Troubleshooting	4-30
Remote Node (FieldBus Controller/Coupler) Troubleshooting ..	4-31
FieldBus Status	4-31
Node Status	4-32
Voltage LEDs	4-32
I/O Errors	4-33
Touch Screen Troubleshooting	4-34
Touch Screen Calibration	4-34
Normal Calibration	4-34
Problems During Calibration	4-34
Calibration with a Mouse	4-34
No Touch Screen Display	4-35
Touch Screen Failure	4-36
Screens Display, but Touch Function Does Not Work	4-36
No Display	4-36
Rotary Knob Troubleshooting	4-37
Testing Ethernet Cables	4-38
Local Test - Patch Cables	4-38
Remote Test - Cable Run	4-38
 Repair	 5-1
Gun Control Card Removal/Installation	5-1
 Parts	 6-1
Introduction	6-1
Console Part Number List	6-2
Console Parts	6-3
Junction Boxes, Extension Boxes, and Control Panels	6-8
Ethernet Components	6-8
Conveyor Encoder	6-8
CAN Cable	6-8
Photocells and Scanners	6-9
Photocell and Scanner Cables	6-9
 Wiring and Pneumatic Diagrams	 7-1

DECLARATION of CONFORMITY

*Nordson Corporation
declare under our sole responsibility that the products*

**Prodigy, Powder Automatic Electrostatic applicators including control cables used
with Prodigy iControl Associated Apparatus.**

to which this declaration relates complies with the following Directives:

- **Machinery Directive 89/37/EEC**
- **EMC Directive 89/336/EEC**
- **ATEX Directive 94/9/EC**

The conformity is under observance of the following standards or standards documents:

EN292	EN50014	EN50081-1
EN1953	EN50050	EN50082-2
IEC 417L	EN50281-1-1	EN55011
EN60204	FM7260	EN50177

Type of protection:

- **II 3 D EEx 2 mj (Type A), Ambient temperature: 20°C to + 40°C**

N° of notified body (ATEX surveillance):

- **1180**

ISO 9000 certificate

DNV



Joseph Schroeder
Engineering Manager,
Finishing Product Development Group

Date: 17 February, 2006



Section 1

Safety

Introduction

Read and follow these safety instructions. Task- and equipment-specific warnings, cautions, and instructions are included in equipment documentation where appropriate.

Make sure all equipment documentation, including these instructions, is accessible to all persons operating or servicing equipment.

Qualified Personnel

Equipment owners are responsible for making sure that Nordson equipment is installed, operated, and serviced by qualified personnel. Qualified personnel are those employees or contractors who are trained to safely perform their assigned tasks. They are familiar with all relevant safety rules and regulations and are physically capable of performing their assigned tasks.

Intended Use

Use of Nordson equipment in ways other than those described in the documentation supplied with the equipment may result in injury to persons or damage to property.

Some examples of unintended use of equipment include

- using incompatible materials
- making unauthorized modifications
- removing or bypassing safety guards or interlocks
- using incompatible or damaged parts
- using unapproved auxiliary equipment
- operating equipment in excess of maximum ratings

Regulations and Approvals

Make sure all equipment is rated and approved for the environment in which it is used. Any approvals obtained for Nordson equipment will be voided if instructions for installation, operation, and service are not followed.

All phases of equipment installation must comply with all federal, state, and local codes.

Personal Safety

To prevent injury follow these instructions.

- Do not operate or service equipment unless you are qualified.
- Do not operate equipment unless safety guards, doors, or covers are intact and automatic interlocks are operating properly. Do not bypass or disarm any safety devices.
- Keep clear of moving equipment. Before adjusting or servicing any moving equipment, shut off the power supply and wait until the equipment comes to a complete stop. Lock out power and secure the equipment to prevent unexpected movement.
- Relieve (bleed off) hydraulic and pneumatic pressure before adjusting or servicing pressurized systems or components. Disconnect, lock out, and tag switches before servicing electrical equipment.
- Obtain and read Material Safety Data Sheets (MSDS) for all materials used. Follow the manufacturer's instructions for safe handling and use of materials, and use recommended personal protection devices.
- To prevent injury, be aware of less-obvious dangers in the workplace that often cannot be completely eliminated, such as hot surfaces, sharp edges, energized electrical circuits, and moving parts that cannot be enclosed or otherwise guarded for practical reasons.

Fire Safety

To avoid a fire or explosion, follow these instructions.

- Do not smoke, weld, grind, or use open flames where flammable materials are being used or stored.
- Provide adequate ventilation to prevent dangerous concentrations of volatile materials or vapors. Refer to local codes or your material MSDS for guidance.
- Do not disconnect live electrical circuits while working with flammable materials. Shut off power at a disconnect switch first to prevent sparking.
- Know where emergency stop buttons, shutoff valves, and fire extinguishers are located. If a fire starts in a spray booth, immediately shut off the spray system and exhaust fans.
- Clean, maintain, test, and repair equipment according to the instructions in your equipment documentation.
- Use only replacement parts that are designed for use with original equipment. Contact your Nordson representative for parts information and advice.

Grounding



WARNING: Operating faulty electrostatic equipment is hazardous and can cause electrocution, fire, or explosion. Make resistance checks part of your periodic maintenance program. If you receive even a slight electrical shock or notice static sparking or arcing, shut down all electrical or electrostatic equipment immediately. Do not restart the equipment until the problem has been identified and corrected.

All work conducted inside the spray booth or within 1 m (3 ft) of booth openings is considered within a Class II, Division 1 or 2 Hazardous location and must comply with NFPA 33, NFPA 70 (NEC articles 500, 502, and 516), and NFPA 77, latest conditions.

- All electrically conductive objects in the spray areas shall be electrically connected to ground with a resistance of not more than 1 megohm as measured with an instrument that applies at least 500 volts to the circuit being evaluated.
- Equipment to be grounded includes, but is not limited to, the floor of the spray area, operator platforms, hoppers, photoeye supports, and blow-off nozzles. Personnel working in the spray area must be grounded.
- There is a possible ignition potential from the charged human body. Personnel standing on a painted surface, such as an operator platform, or wearing non-conductive shoes, are not grounded. Personnel must wear shoes with conductive soles or use a ground strap to maintain a connection to ground when working with or around electrostatic equipment.
- Operators must maintain skin-to-handle contact between their hand and the gun handle to prevent shocks while operating manual electrostatic spray guns. If gloves must be worn, cut away the palm or fingers, wear electrically conductive gloves, or wear a grounding strap connected to the gun handle or other true earth ground.
- Shut off electrostatic power supplies and ground gun electrodes before making adjustments or cleaning powder spray guns.
- Connect all disconnected equipment, ground cables, and wires after servicing equipment.

Refer to the *Installation* section of this manual for more information on grounding.

Action in the Event of a Malfunction

If a system or any equipment in a system malfunctions, shut off the system immediately and perform the following steps:


- Disconnect and lock out electrical power. Close pneumatic shutoff valves and relieve pressures.
- Identify the reason for the malfunction and correct it before restarting the equipment.

Disposal

Dispose of equipment and materials used in operation and servicing according to local codes.

Safety Labels

Table 1-1 contains the text of the safety labels on the iControl console. The safety labels are provided to help you operate and maintain your console safely. See Figure 1-1 for the location of the safety labels.

Item	Part	Description
1.	1034161	 WARNING: Disconnect power before servicing.




Figure 1-1 Safety Labels

Section 2

System Overview

iControl System Manuals

This manual covers the iControl console and system hardware for **iControl with Prodigy Technology** systems, used with Prodigy spray guns only.

iControl manuals are organized as follows:

Operator Interface Manual for all versions of the system, covering configuration, preset setup, and operation using the iControl software:

- 1056418

Operator Card for all versions:

- 1024758

Hardware Manual, covering installation, troubleshooting, repair, and parts:

- Prodigy iControl Hardware: 1056419

A Prodigy iControl system console controls up to 32 automatic guns.




Figure 2-1 Prodigy iControl Console

Console and System Hardware and Software

See Figures 2-3 and 2-2.

A fully equipped console controlling 32 Prodigy automatic spray guns contains the following hardware:

- operator interface consisting of LCD touch-screen display, rotary dial, and interlock keyswitch
- single board computer (SBC), with Ethernet PCI card
- two CompactFlash cards, for system software and user data
- I/O board, two subpanels with backplanes, card cages, and 16 gun control cards (one card controls two guns)
- 24Vdc power supplies
- alarm, remote lockout, and conveyor interlock relays

The system requires the following external hardware:

- photoeye junction box
- zone photoeyes or discrete scanners
- part ID photoeyes or discrete scanners, or inputs from customer part ID system
- conveyor encoder
- conveyor interlock relay
- network interface box
- Prodigy feed center, with four pump panel containing 32 HDLV pumps and 16 control cards (one card controls two pumps)

Options

In/Out Positioners (Horizontal or Vertical)

- analog scanners to measure part dimensions
- scanner junction box
- in/out positioners and control panels
- network interface box, Ethernet cables, and Ethernet PCI card

Reciprocators

- analog scanners to measure part height
- reciprocators
- in/out positioner/reciprocator control panels

2nd Booth Option (2nd booth shares encoder signal, zone and part ID signals, and if in/out positioners and reciprocators are used, scanner signals):

- Ethernet switch installed in scanner junction box




Figure 2-2 iControl Prodigy Console Internal Components

- | | | |
|---|-------------------------------------|--------------------------------|
| 1. Keypad | 5. Power supplies | 9. Relays and fuses |
| 2. 3-Position interlock switch | 6. Card cage with gun control cards | 10. Compact Flash card adapter |
| 3. Computer and LCD display | 7. Gun cable receptacles | 11. I/O board |
| 4. Ethernet PCI card (included with computer) | 8. Power switch | |

Operator Interface

The iControl software provides a graphical user interface that provides screens to configure and control the spray gun triggering and positioning system.

The operator performs all configuration and operation tasks with the touch screen and the **Rotary Dial**. Turning the rotary dial increases or decreases values in selected fields.




Figure 2-3 Master Console Front Panel

- | | |
|------------------------|----------------|
| 1. Interlock keyswitch | 3. Rotary dial |
| 2. LCD touch screen | |

Interlock Keyswitch Functions

In the **Ready** position, the spray guns cannot be triggered unless the conveyor is running. This prevents powder waste and hazardous operating situations.

In the **Bypass** position, you can trigger the guns on and off without running the conveyor. Use the Bypass position to set up and test spray gun settings.

In the **Lockout** position, the guns and the gun movers are disabled. Use this position when working inside the booth.

CAN and Ethernet Networks

Refer to the system diagram in Section 7.

CAN Network: Handles internal communications between the gun control cards, iFlow modules, and the iControl PC, and with other iControl consoles.

Ethernet Network: Handles external communications between the iControl system and remote devices such as optional in/out positioners, reciprocators, and analog scanners.

Digital Inputs

The iControl console includes an interface board that provides optically isolated digital inputs. Included are

- eight inputs for zone detection
- eight inputs for part identification
- one input for a conveyor motion encoder

The encoder, zone and part ID photoeyes or discrete (digital) scanners with or customer part ID inputs are connected to a terminal block in the Photoeye Junction Box (PEJB). A 24Vdc power supply in the PEJB provides power for these devices.

A 25-conductor input cable connects the PEJB to the iControl master console. If the master console cannot be located within direct wiring range (19 ft) of the PEJB, an extension box and extra cable are provided. If the system is equipped with a remote I/O (Ethernet) network, then the 25-conductor cable is routed through a network junction box.

Encoder

The iControl system provides one optically isolated digital input for a conveyor motion encoder. The encoder can be either mechanical or optical and must have a 50% duty cycle.

At an encoder resolution of one inch to one pulse (1:1), the effective distance parts can be tracked by the iControl system is approximately 1333 feet. At a 2:1 resolution ($\frac{1}{2}$ inch per pulse, the effective tracking distance is halved, to approximately 666 feet.

The maximum speed of the encoder input is 10 Hz (10 pulses per second). This may require a trade off between desired conveyor speed and part tracking resolution (the higher the conveyor speed the coarser the tracking resolution).

NOTE: A timer may be used instead of an encoder. Consult with your Nordson representative.

Gun Control Cards

Each gun control card in the card cage provides electrostatic controls for two powder spray guns. The cards provide 0-21 Vdc power to the Prodigy automatic gun voltage multipliers and process feedback from the guns for display on the operator interface.

Prodigy manual spray guns are controlled by the manual gun controllers.

Gun Pump Control

The iControl console and the manual gun controllers control the Prodigy HDLV powder pumps through the CAN network. In the pump cabinet, one pump control card controls two pumps.

Refer to the Prodigy HDLV pump and pump panel manuals for wiring diagrams, parts lists, and other information.

Specifications

General

Electrical Requirements	
Input	Unswitched: (PC) 100-230 Vac, 50/60 Hz, 1 Ø, 120 VA max.
	Switched: 100-230 Vac, 50/60 Hz, 1 Ø, 480VA max.
	Conveyor Interlock and Remote Lockout: 120/230 Vac, 50/60 Hz, 1 Ø, 6 mA
	Alarm Relay contact rating: 120/230 Vac, 1 Ø, 6 A
Output (to spray gun)	0-21 Vdc, 0.60 A
NOTE: The iControl system must be interlocked with the fire detection system so that the spray guns are shut off if a fire is detected inside the spray booth.	
ANSI/ISA S82.02.01	
Pollution Degree	2
Installation (Overvoltage)	Category II
Environmental	
Operating Temperature	32-104 °F (0-40 °C)
Operating Humidity	5-95%, non-condensing
Hazardous Location Rating	North America: Class II Division 2, Groups F & G
	European Union: Ex II 3D

Prodigy Pump and Spray Gun Pattern Air Quality

Air must be clean and dry. Use a regenerative desiccant or refrigerated air dryer capable of producing a 3.4 °C (38 °F) or lower dew point at 7 bar (100 psi) and a filter system with prefilters and coalescent type filters capable of removing oil, water and dirt in the submicron range.

Recommended Air Filter Screen Size:	5 micron or smaller
Maximum Oil Vapor in Air Supply:	0.1 ppm
Maximum Water Vapor in Air Supply:	0.48 grains/ft ³

Moist or contaminated air can cause the HDLV pumps to malfunction; the powder to cake in the reclaim system, or clog the feed tubing, and spray gun powder paths.

Approvals

FM (US / Canada), CE / ATEX
Rated for Class II Division 2 Groups F & G Hazardous Location Area (North America), or Normal Usage Area, Zone 22 (European Union)

Approved Program and User Data Cards

SanDisk, Toshiba, PNY, and Memorex 128 Mb (minimum) CompactFlash cards.

Section 3

Installation



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



WARNING: This equipment can be dangerous unless it is used in accordance with the rules laid down in this manual.

Introduction

iControl systems are configured for each customer's application and requirements. The equipment supplied with the system varies depending on the type of installation (new, upgrade, or retrofit) and the equipment furnished by the customer. Therefore, this section provides only basic installation information. Detailed information is contained in the system wiring diagrams, plan views, and other documentation furnished by Nordson application engineering.

Refer to Section 7 for system diagrams and console, junction box, and control panel drawings.

Once all hardware is installed and wired and the system is powered up, the operator interface is used to configure, setup, and operate the system. Refer to the *iControl Operator Interface* manual for configuration instructions.



WARNING: Use dust-tight conduit connectors or strain reliefs in all iControl console, junction box, and control panel knockouts. Installation must be done according to code and care must be taken to maintain the dust-tight integrity of the enclosures.

Hardware Installation

Refer to the drawings furnished by Nordson application engineering for locations of the consoles, junction boxes, and other system devices.

Bolt the iControl consoles to the floor. The photoeye junction box is typically mounted on the photoeye stand. All other junction boxes are mounted on the booth, operator platforms, or feed center, according to their function.

Refer to your Nordson plan view drawings for locations and mounting details.

CAN Network Connections and Settings

The iControl console communicates with the manual gun controllers and pump control cards through a CAN network. See Figure 3-1 for connections. Make sure each cable shield is connected on one end only.

NOTE: The termination jumper must be installed on W1 pins 1 and 2 on the last pump control card in the last pump cabinet on the feed center.




Figure 3-1 CAN Network Cable Connections

iControl Console CAN Address and Termination Settings

The backplane address dipswitches are set at the factory:

1. Network terminator switch SW1-3 is set to CONTINUOUS for both backplanes.
2. Network address switches SW1-1 and 2 are set to Guns 1-16 for the lower backplane and to 17-32 for the upper backplane (if used).




Figure 3-2 CAN Network Connections, Console Addresses, and Termination

Manual Gun Controller Addresses

The manual gun controller addresses are set through software. Each controller must have a unique address. Up to four manual guns can be included in a system. Refer to the *Prodigy Manual Gun Controller* manual for instructions.

NOTE: For each HDLV pump chosen to supply powder to a manual gun, you must enter the pump calibration numbers into the gun controller. Refer to the *Prodigy Manual Gun Controller* manual for instructions.

Manual Gun Controller Termination

Manual gun controllers are shipped with their CAN termination switch set to ON. For each manual gun controller in the system:

1. Open the controller enclosure and locate SW1 on the controller interface board.
2. Set the TERM switch on SW1 to OFF.

Pump Control Card Addresses

Refer to the *Prodigy HDLV Pump Manifold and Circuit Board* manual for instructions on setting the control card address and gun type switches.

The termination jumper must be installed on W1 pins 1 and 2 on the last pump control card in the last pump cabinet on the feed center.

NOTE: The calibration numbers for the HDLV pumps supplying powder to the automatic guns must be entered into the iControl configuration. Refer to the *iControl Operator Interface* manual for instructions.

Power, Ground, and Relay Connections

The console and junction box power cable ground wires must always be connected to a true earth ground. The special flat braided ESD ground cables provided with the iControl consoles and manual gun controllers must be used to connect them to the booth base if possible. Refer to *Grounding* on page 3-6 for more information.



WARNING: Consoles and all conductive equipment in the spray area MUST be connected to a true earth ground. Mount the junction boxes and control panels to grounded stands or the booth base. Connect the consoles to the booth base with the special flat braided cables provided. Failure to observe this warning could result in damage to sensitive electronic equipment and severe shocks to personnel, or fire or explosion.

Console Power Cable Connections

Table 3-1 lists the connections required for console power. Refer to page 3-10 for optional junction box and control panel power requirements.

Refer to Section 7 for the system diagram, console wiring diagrams, and junction box and control panel drawings. Refer to your system electrical drawings for all other power and ground connections.

Table 3-1 Console Power Cable Connections

Master Console Power Cable Connections		
Wire Color	Connection	Function
Black	L1 (hot)	100-240 Vac power to iControl PC (master console only) (unswitched)
White	L2 (neutral)	
Brown	L1 (hot)	120-240 Vac power to console power supply (switched with booth exhaust fan motor)
Blue	L2 (neutral)	
Green/Yellow	Chassis Ground	
Gray (2)	Remote Lockout: 120 Vac, 1 phase, 6 mA (for 240 Vac, refer to instructions below)	
Yellow (2)	Alarm contacts: 120/230 Vac, 1 phase, 6 A max. Contact is closed with no power to console or when alarm is present. Contact is open with power applied to console and no alarms present.	
Red, Orange	Conveyor Interlock: 120 Vac, 1 phase, 6 mA (for 240 Vac, refer to instructions below)	

Conveyor Interlock and Remote Lockout

The conveyor interlock and remote lockout relays in the iControl console are wired at the factory for 240 Vac. To switch the connections to 120 Vac, see Figure 3-3. Do not remove the 20K resistors.




Figure 3-3 240 Vac (Factory) and 120 Vac (Optional) Conveyor Interlock and Remote Lockout Relay Connections

Grounding

Proper grounding of all conductive components of a powder coating system provides both shock and electrostatic discharge protection for both operators and sensitive electronic equipment. Many system components (booth, collector, color modules, control consoles, and conveyor) are connected both physically and electrically. It is important that the proper grounding methods and equipment are used when installing and operating the system.

PE (Protective Earth) Grounding

PE grounding is required on all conductive metal electrical enclosures in a system. PE grounding is provided by a ground conductor wire bonded to a true earth ground. PE grounding protects operators from electrical shock by providing a path to ground for electrical current if a conductor contacts an electrical enclosure or other conductive component. The ground conductor wire carries the electrical current directly to ground and short circuits the input voltage until a fuse or circuit breaker interrupts the circuit.

The green/yellow ground wires bundled with the AC input power cable are used only for PE grounding and their sole purpose is to protect personnel from a shock. These ground wires do not protect against electrostatic discharge.

Electrostatic Grounding

Electrostatic grounding protects electronic equipment from damage caused by electrostatic discharges (ESD). Some electronic components are so sensitive to ESD that a person can deliver a damaging static discharge without feeling even a mild shock.

Proper electrostatic grounding is mandatory in an electrostatic powder coating system. Powder spray guns generate electrostatic voltages up to 100,000 volts. It does not take long for ungrounded system components to build up an electrical charge strong enough to damage sensitive electronic components when discharged.

Electrostatic discharges occur at very high frequencies, around 100 megahertz. An ordinary ground conductor does not conduct such high frequencies well enough to prevent damage to electronic components. Special flat braided cables are provided with your Nordson powder coating equipment to protect against ESD.

Gun Current Path

Refer to Figure 3-4. All electrical circuits need a complete path for current to make its way back to the source (circle=circuit). Electrostatic spray guns emit current (ions) and therefore require a complete circuit. Some of the current emitted by the spray gun is attracted to the spray booth, but most is attracted to the grounded parts moving through the booth. The current attracted to the parts flows through the part hangers to the conveyor and to the building ground, back to the controller through a ground braid and back to the spray gun through the gun driver board. The current attracted to the booth is returned through the booth ground to the controller and back to the gun.

It is very important to provide a complete circuit for the gun current. A break in the circuit conductors (conveyor, booth, braided ground cables, controller) can cause voltage to build up on the conductors up to the maximum output of the spray gun voltage multiplier (up to 100 kV). The voltage will eventually discharge in a high frequency arc and cause damage to the controller electronics (gun driver board and power supply).




Figure 3-4 Electrostatic Current Path

ESD Ground Procedures and Equipment

The best protection against ESD is to keep the ground braids as short as possible and connect them to a central point on the booth base as shown in the Star diagram. Under normal conditions making Star connections is not a problem, but in some systems, such as roll-on/roll-off booths, the ground braids required for a Star connection are too long to be effective against ESD. In this case, a Daisy Chain ground configuration is acceptable.




Figure 3-5 ESD Grounding Procedures and Equipment

Always use the special flat braided copper ESD ground cables furnished with all Nordson spray gun controllers to ground them. The ESD ground cables should always be attached to the welded booth base, not to a panel, enclosure, or other component bolted to the base. Keep the cables as short as possible. If using a grounding block kit, make sure the block is installed directly to the welded base with the included self-drilling screws.

An ESD grounding block kit is available for connecting the ground braids to the booth base. The kit contains two 6-position grounding blocks, fasteners, terminals, and 15 meters (50 feet) of braided ground cable. If additional kits are required, order:

1067694 Kit, ground bus bar, ESD, 6-position, with hardware

Encoder, Zone, and Part ID Connections

A 25-conductor cable carries conveyor encoder and discrete part ID and zone input signals from the Photoeye Junction Box (PEJB) to the I/O board in the iControl console. If these inputs are shared by a second booth then an additional 25-conductor cable is supplied. Table 3-2 lists the 25-conductor cable connections to be made at the terminal strip.

Section 7 contains a system wiring diagram, console wiring diagram, and diagrams for the junction boxes and control panels listed in Table 3-3.

NOTE: Refer to your system plan views when locating the part ID stand and mounting the photoeyes or scanners.

25-Conductor Cable Connections

Table 3-2 Parallel Cable Connections: I/O Board to Junction Box Terminals
(Inputs to I/O Board are Sinking)

Wire Color	I/O Board Terminal	Junction Box Terminal Number	Function
BLK	1 LO	1	Zone 1
WHT	2 LO	2	Zone 2
GRN	3 LO	3	Zone 3
ORG	4 LO	4	Zone 4
BLU	5 LO	5	Zone 5
WHT/BLK	6 LO	6	Zone 6
RED/BLK	7 LO	7	Zone 7
GRN/BLK	8 LO	8	Zone 8
ORG/BLK	9 LO	9	Part ID bit 1
BLU/BLK	10 LO	10	Part ID bit 2
BLK/WHT	11 LO	11	Part ID bit 3
RED/WHT	12 LO	12	Part ID bit 4
GRN/WHT	13 LO	13	Part ID bit 5
BLU/WHT	14 LO	14	Part ID bit 6
BLK/RED	15 LO	15	Part ID bit 7
WHT/RED	16 LO	16	Part ID bit 8
ORG/RED	17 LO	—	spare
BLU/RED	18 LO	—	spare
RED/GRN	19 LO	—	spare
ORG/GRN	20 LO	20	Encoder A
BLK/WHT/RED	21 LO	—	Spare
WHT/BLK/RED	22 LO	—	spare
RED/BLK/WHT	23 LO	—	spare
GRN/BLK/WHT	N/C	—	—
BLUE from Keyswitch	24 HI	Not Applicable	Conveyor Interlock
WHITE from Keyswitch	24 LO	Not Applicable	Conveyor Interlock
RED	1-23 HI	(+)	VDC

Switching Inputs to Sourcing

Inputs to I/O card in the iControl console are configured as sinking. 24 Vdc is applied to all HI terminals. To switch the inputs to sourcing:

1. Disconnect all wires from the I/O card LO terminals, except terminal 24. Do not remove the blue and white wires from terminals 24 HI and 24 LO.
2. Move the 6-pole jumpers from the HI terminals to the LO terminals.
3. Install the red wire jumpers to connect all 6-pole jumpers together.
4. Connect the red wire from the 25-conductor cable to terminal 1 LO.
5. Connect the remaining wires to the HI terminals.
6. At the PEJB, connect the red wire to the (-) terminal.

Conveyor Encoder Connections

Bring the encoder cable into the Photoeye Junction Box (PEJB) through a dust-tight conduit at one of the unused knockouts in the PEJB. Wire the cable to the encoder and PEJB terminal strip as shown on the PEJB drawing in Section 7.

Photoeye Connections and Configuration

Connect SO cable to the photoeyes and photoeye junction box terminal block as shown on the PEJB drawing. Route the cables through the cord grips installed in the PEJB as shown.

Configure the photoeyes and set their sensitivity as shown on the PEJB drawing.

Junction Box Power Requirements

Table 3-3 Junction Box/Control Panel Power Requirements

Drawing No.	J-Box/Control Panel	Requirement
1035897	Photoeye	120-240 Vac, 1 PH, 50/60 Hz, 2A
1057333	Network Interface	120 Vac, 1 PH, 60 Hz, 11 watts
1055890	In/Out Positioner Scanner	24 Vdc from 30 Watt PEJB 120 Vac (fused), from PEJB (if 2nd booth option)
1055889	In/Out Positioner Control	120 Vac, 1 PH, 60 Hz, 10A
1055883	Analog (Retrofit) In/Out Positioner Control	120 Vac, 1 PH, 60 Hz, 2A
1070103	In/Out Positioner / Reciprocator Control	120 Vac, 1 PH, 60 Hz, 10A 208-575 Vac, 3 PH, 60 Hz (see foldouts Fig. 7-25)

Scanner Cable Connections

See Figure 3-6. The photoeye junction box and scanner junction boxes are shipped with the scanner cables pre-wired to the junction boxes. The scanner controllers are programmed at the factory according to the system order specifications. Refer to your system plan views when locating the part ID stand and scanners or photoeyes. The scanners must be mounted with the cable ends oriented as shown.

Discrete Scanner Connections

- Single Zone Scanner: SCNR1 cables to scanner.
- Dual Zone Scanners: SCNR1 cables to upper scanner, SCNR2 cables to lower scanner.
- Part ID Scanner and Zone Scanner: SCNR1 cables to zone scanner, SCNR2 cables to Part ID scanner.

NOTE: The part ID scanner or photoeyes must be located so that the iControl system receives the part ID before the leading edge of the part breaks the zone scanners or photoeyes.




Figure 3-6 Zone and Part ID Scanner Cable Connections

Analog Scanner Connections

See Figure 3-7. The in/out positioner scanner junction box is typically located on the same stand as the photoeye junction box. One or two scanners can be used to detect the width of the parts. The scanners must be mounted with the cable ends oriented as shown. If using dual scanners, mount them so that they do not see the conveyor. Connect the positioner scanner cables (BSCE, BSCR) from the junction box to the scanners as shown.

If the system also has reciprocators, then analog scanners are used to detect the part height and top and bottom edges. Mount the scanners with the cable ends down and connect the cables (SCNR1) from the PEJB to the scanners.

Scanner Cable Connections *(contd)*

Maximum Analog Scanner Separation:

6 meters (20 ft) if scanner is less than 1.22 meters (4 ft) long

4.6 meters (15 ft) if scanner is greater than 1.22 meters (4 ft) long.

NOTE: If using a single horizontal scanner, the controller must be programmed to ignore the conveyor. This requires software from the scanner manufacturer, a laptop running Windows, and a serial cable to connect the laptop to the scanner controller in the junction box.




Figure 3-7 In/Out Positioner and Reciprocator Analog Scanner Connections

Customer-Supplied Part ID System Connections

Refer to Table 3-2. Use the Part ID terminals on the PEJB to connect a customer-supplied part ID system to the iControl console. The 8 inputs are used based on the settings made in the Photoeye Configuration screen. Refer to the *iControl Operator Interface* manual for configuration instructions.

Ethernet Network Connections

The Ethernet network allows the iControl system to communicate with remote Ethernet devices such as the in/out positioner or reciprocator controllers and the Ethernet couplers that receive signals from the analog scanner controllers.

NOTE: Do not connect any device to this network that is not approved by Nordson Finishing Technical Support or Engineering.

The required field connections are shown in Figure 3-8, along with the connections required for sharing the in/out positioner scanner with a 2nd booth. Refer to Section 7 for junction box and control panel drawings.




Figure 3-8 Remote I/O Network Equipment and Connections (with Connections for 2nd Booth Option)

iControl Console to Network Interface Box

Connect the 3/4 in. flexible conduit to the network interface box if you have not already done so. Plug the Ethernet cable bundled in the conduit to any unused port in the Ethernet switch. The other end of the cable is plugged into the iControl PC Ethernet card.

Ethernet Switch to Ethernet Devices

NOTE: There are two Ethernet cable types, T568-A and T568-B. The type determines the way the cable leads are wired at each end of the cable. Either type of cable can be used in the iControl system. **Each end of the cable must be terminated using the same wiring arrangement.**

Refer to the *Parts* section for 100- or 300-foot T568-B Ethernet CAT 5e cables. Use these cables to connect the Ethernet switch in the network junction box to the Ethernet controllers in the junction boxes and control panels.

1. Measure the lengths needed plus enough slack at each end so that you can pull the cables into the junction boxes and then connect the cables to termination modules or RJ-45 plugs.
2. Cut the cables to length, leaving an RJ-45 plug on one end.
3. Pull the cut ends of the cables through flexible conduit from the network interface box to the junction boxes or control panels.
4. In the network interface box, plug the cables into the Ethernet switch.
5. At the junction boxes or control panels terminate the cables with one of these methods:
 - Each junction box or control panel includes a termination module and patch cord. Install the termination modules on the end of the cables as described in *Connecting Termination Modules to Ethernet Cables* on page 3-15, then use the patch cords to connect the termination modules to the Ethernet controllers.
 - Install RJ-45 plugs on the ends of the cables as shown in *Ethernet Termination Standards* on page 3-17 and plug the cables into the Ethernet controllers.

NOTE: It is a good idea to test all cables with an Ethernet continuity tester before connecting them. Refer to *Troubleshooting* for test procedures.

MAC Addresses

Record the MAC address and device function for each Ethernet controller in the junction boxes and control panels. For the in/out positioners note the location (left front = GM1, right front = GM2, left rear = GM3, right rear = GM4). The MAC addresses are on the controller labels, in the form 0:30:DE:0:33:C8.

You will need the MAC addresses when configuring the network with the iControl operator interface. Refer to the *iControl Operator Interface* manual for instructions.

Connecting Termination Modules to Ethernet Cables

iControl junction boxes and control panels containing Ethernet devices are equipped with T568-B Ethernet termination modules and 2-foot T568-B patch cords. To connect the termination modules to the Ethernet cables coming from the network junction box, you will need a cable jacket stripper, a 110 punch-down tool, and a diagonal cutter.

- cable jacket stripper
- 110 punch-down tool
- diagonal wire cutter

See Figure 3-9.

1. Remove the surface mount box and termination module from the junction box.
2. Remove the cover and bezel from the surface-mount adapter. Use a small flat screwdriver to remove the old-style cover; squeeze the clips on each side of the new-style cover to remove it.
3. Remove the cable entry knockout from the cover.
4. Strip back the cable jacket no less than 50 mm (2 in.). Do not strip the wire insulation.
5. Keeping each pair twisted together, lay the wires one at a time into the module slots and punch them down, using the B color code as shown in the illustrations.

NOTE: A minimum of 6.4 mm ($\frac{1}{4}$ in.) of wire must extend beyond the module slot to ensure a good connection.

6. Clip off the ends of the wires close to the termination module so the ends of the wires cannot contact each other.
7. **Side-connect modules:** Slide the termination module into the adapter, then install the bezel onto the adapter.
Rear-connect modules: Snap the termination module into the bezel, then install the bezel onto the adapter.
8. Secure the cable to the adapter with a cable tie.
9. Snap the adapter cover into place.
10. Locate the assembled surface mount box close enough to the fieldbus device to make the patch cable connection. Secure the adapter to the junction box with the included piece of two-sided adhesive tape.

Connecting Termination Modules to Ethernet Cables (contd)






Figure 3-9 Connecting Ethernet Termination Modules to Ethernet Cable

Ethernet Termination Standards

Either T568-B or T568-A cables will work in the iControl system. Use the wiring diagrams in Figure 3-10 when terminating Ethernet cables. Make sure each end of the cable is terminated using the same type of plug and wiring arrangement.

Type T568-B Wiring Diagram

Pin	Color
1	Orange/White
2	Orange
3	Green/White
4	Blue
5	Blue/White
6	Green
7	Brown/White
8	Brown



Type T568-A Wiring Diagram

Pin	Color
1	Green/White
2	Green
3	Orange/White
4	Blue
5	Blue/White
6	Orange
7	Brown/White
8	Brown





Figure 3-10 Ethernet Termination Standards

Gun Cable and Feed Tubing Connections

See Figure 3-11. Connect the automatic gun cables to the receptacles on the bottom rear panel of the iControl console. Connect gun 1 cable to receptacle 1, gun 2 cable to receptacle 2, and so on.

Connect the 8-mm powder feed tubing from the spray guns to the HDLV pump outlet fittings as described in the pump panel manual.

Connect the pattern air tubing from the spray guns to the pump panel outlet fittings next to the pumps.

Odd Number of Guns

iControl systems are sold configured for an even number of guns. Each gun controller card in the console controls two guns. If you configure the system for an odd number of guns, the fault LED on the card with only one gun connected will light.

NOTE: The unused gun must be the highest even-number gun. For example, if you have an 8-gun system, then number 8 must be the unused gun. The gun card receptacles are labeled on the circuit boards as A (odd number gun) and B (even number gun).

Included in the bag with the console keys is a seal and jumper. The jumper will disable the gun not detected fault LED on the gun card.

Cap the unused cable receptacle with the bulkhead seal, then open the console door and unplug the receptacle harness from the gun card. Install the jumper in the card receptacle.

Refer to the Parts section for seal and jumper part numbers.




Figure 3-11 Seal and Jumper Installation - Example Showing 8 Gun System 7 Guns

Program and User Data Cards

The iControl program and configuration data is stored on one 512 Mb Compact Flash card. All user data and preset settings are stored on another 512 Mb CompactFlash card. These cards function as removable hard drives. The iControl consoles are shipped with these cards installed.




CAUTION: The Compact Flash cards CANNOT be hot-swapped. Shut down the iControl program and operating system, then turn off the iControl console before removing the cards. Removing the cards while power is on could corrupt the data on the cards and damage the cards.



CAUTION: Never turn off console power without first shutting down the iControl program and operating system. Doing so could corrupt the system software. Refer to *Program Shutdown* in the *iControl Operator Interface* manual for the shutdown procedure.

See Figure 3-12. The card adapter is mounted on the inside of the master console door. The inner card (1) is the data card; the outer card (2) is the program card.

NOTE: The old-style adapter had an eject button for each card; the new-style adapter has one button that ejects the program card and exposes the data card. To remove the data card, simply pull it out of the slot.



Card Adapter



New SMC 512 Mb Flash Cards
(etching is on bottom of card)

Figure 3-12 User Data and Program Card Locations

- | | |
|-----------------|--------------------|
| 1. Data card | 3. Eject button(s) |
| 2. Program card | |

The iControl program can be updated by installing a new program card.

In addition to the configuration data, up to 255 presets per gun can be stored on each data card. To copy a data card to a blank card, use the Data Backup function. Refer to *Data Backup* in the *iControl Operator Interface* manual for instructions.

NOTE: Not all CompactFlash cards are the same. For approved cards, order the cards listed in the parts section, or contact your Nordson controls engineer or Nordson Technical Support.

Touch Screen Calibration

The touch screen is calibrated at the factory before the system is shipped. The touch screen calibration values are stored on the program card. If you install a new program card that has never been used before, there will be no calibration file on the card. The system will automatically start the calibration procedure.

Follow the calibration instructions on the screen exactly, using your finger to touch the targets. When you have completed the calibration procedure, touch the **iControl** button to start the iControl software.

Refer to *Troubleshooting* for a complete description of the calibration procedure and instructions on calibration.

System Upgrades

Parts requirements for system upgrades depend on your existing system configuration. Contact your Nordson representative for help in ordering and installing upgrades.

Section 4

Troubleshooting



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



CAUTION: Do not turn off console power without first performing a program shutdown. Doing so could corrupt the iControl program and operating system on the program card. Refer to *Program Shutdown* in the *Configuration* section of the *iControl Operator Interface* manual for the shutdown procedure.

NOTE: If the troubleshooting procedures in this section do not solve your problem, contact the Nordson Finishing Customer Support Center at (800) 433-9319 or your local Nordson representative.

Error Codes and Alarm Messages

Table 4-1 Error Codes and Messages

Code	Message Text	Description	Refer to Page
NA = Not currently applicable			
* - Code may differ on early software releases			
10x	CAN and Node State		
101	CAN bus fault detected	N/A	4-6
102	CAN receive buffer overflow	Host CAN interface receive too much data and could not process it quickly enough	4-6
103	Message timeout	Remote CAN device did not respond to a direct response in the allotted time.	4-6
104	Went offline	Remote CAN device is no longer online	4-6
105	Returned to online	Remote CAN device returned to service	4-6
106	Communication error	Host CAN interface detected a communication error	
107	BUS-OFF	255 bad CAN messages received	
108	Warning Limit exceeded	127 bad CAN messages received	
109	Bit error	Dominant bit not detected in 5 data bits	
110	Form error	Fixed format data field contains illegal bits	
111	Stuffing error	Recessive bit not detected in 5 data bits	
Continued...			

Code	Message Text	Description	Refer to Page
112	Other error	Other errors not listed as Bit, Stuff, or Form	
113	CAN Transmit Buffer overflow	Host CAN interface did not transmit data quickly enough	
20x	Application		
201	Conveyor input not detected	Not implemented, future release	
202	Encoder not detected	Not implemented, future release	
203	Zone photoeye stuck on	Not implemented, future release	
204	Flag photoeye stuck on	Not implemented, future release	
205	Application setup	Not implemented, future release	
206	System in lockout	Not implemented, future release	
30x	Electrostatic Controller (Gun Card)		
301	Micro-Amp fault detected	Microamp value out of range.	4-7
302	Foldback fault detected	Current foldback detected.	4-7
303	Feedback fault detected	Microamp feedback detected.	4-7
304	Open circuit detected	No multiplier load detected.	4-7
305	Short circuit detected	Multiplier drive circuit shorted.	4-7
306	Internal hardware fault detected	Internal DSP fault.	4-8
307	Tribo	Tribomatic gun current feedback low.	4-8
308	Gun not detected	Gun not connected to system.	4-8
5xx	Remote Device Node		
Electrostatic Node (Gun Card)			
531	System Heartbeat lost	Remove device lost heartbeat message.	4-8
532	5/24 Volt power	Remove device power detection failure.	4-8
533	Error writing to internal EEPROM	Error saving data to remote device onboard EEPROM.	4-8
534	Error reading from internal EEPROM	Error reading data from remote device onboard EEPROM.	4-8
535	Node address changed from last powerup	The saved address does not match the current address for the remote device. Sending a reset command will clear this state.	4-8
536	Internal database version changed - resetting to defaults	An update to the database was detected and the current data is no longer valid.	4-8
537	Preset out of range	The preset sent to the remote device was out of range.	4-8
538	Trigger ON message received - controller in lockout	Remote device was commanded to trigger while in lockout.	4-8
Continued...			

Code	Message Text	Description	Refer to Page
Prodigy Pump Node			
571	System Heartbeat lost	Remote device lost heartbeat message.	4-11
572	5/24 Volt power	Remote device power detection failure.	4-11
573	Error writing to internal EEPROM	Error saving data to remote device onboard EEPROM.	4-11
574	Error reading from internal EEPROM	Error reading data from remote device onboard EEPROM.	4-11
575	Node address changed from last powerup	The saved address does not match the current address for the remote device. Sending a reset command will clear this state.	4-11
576	Internal database version changed - resetting to defaults	An update to the database was detected and the current data is no longer valid.	4-11
577	EEPROM validation error*	EEPROM data not valid.	4-11
70x	Prodigy Pump Controller		
701	Pattern servo fault	The solenoid resistance was not detected or incorrect when the device was not triggered.	4-11
702	Pump servo fault	The solenoid resistance was not detected or incorrect when the device was not triggered.	4-11
703	UNDEFINED ERROR1		4-11
704	UNDEFINED ERROR2		4-11
705	Powder low PWM	Air flow less than commanded value.	4-11
706	Pattern low PWM	Air flow less than commanded value.	4-11
707	Powder high PWM	Air flow more than commanded value.	4-12
708	Pattern high PWM	Air flow more than commanded value.	4-12
80x	User Interface		
801	Backup operation failure*	Not implemented, future release	
802	Database compare failure*	Not implemented, future release	
803	Copy program failed to start*	Not implemented, future release	
804	Compare program failed to start*	Not implemented, future release	
805	Gun trigger error*	Not implemented, future release	
806	Flow/pump trigger error*	Not implemented, future release	
Continued...			

Code	Message Text	Description	Refer to Page
90x	Ethernet Networking		
901	I/O error	Ethernet I/O communication failure.	4-14
902	POrt or socket open error	The Ethernet connection failed to open for service.	4-14
903	Serial port already open	The Ethernet connection is already open and received an open command.	4-14
904	TCP/IP connection error	Unable to connect to remote device.	4-14
905	TCP/IP connection was closed by remote peer	Remote device closed the I/O connection.	4-14
906	Socket library error	The socket library returned error status.	4-14
907	TCP Port already bound	Requested TCP port is in use by another application.	4-14
908	Listen failed	The local system cannot detect activity on the Ethernet network.	4-14
909	File descriptors exceeded	Too many connections are open.	4-15
910	No permission to access serial or TCP port	The program requesting the Ethernet resource does not have permission to do so.	4-15
911	TCP Port not available	The requested port is busy or otherwise not available.	4-15
917	Checksum error	Data packets were received with errors.	4-15
918	Invalid frame error	Data packets were received with errors.	4-15
919	Invalid reply error	Data packets were received with errors.	4-15
920	Reply time-out	A reply to a request was not received in time.	4-15
921	Modbus exception response	An illegal Modbus command was detected.	4-15
925	Illegal Function exception response	An illegal function call was detected.	4-15
926	Illegal Data Address exception response	An illegal address was detected.	4-15
927	Illegal Data Value exception response	An illegal data value was detected.	4-15
928	Slave Device Failure exception response	The slave device returned an exception.	4-15
100x, 110x	Positioner		
1001	E-Stop OPEN	The E-Stop circuit is open.	4-16
1002	Encoder failure	The encoder is not responding when motion is commanded or is responding with defective signals.	4-16
1003	Motor Protector	The motor protector is open.	4-17
1004	Motion Controller	The motion controller indicates a failure.	4-17
1005	Forward Contactor	The forward contactor did not engage.	4-17
1006	Reverse Contactor	The reverse contactor did not engage.	4-17
1007	Forward End of Travel Limit	The machine is at the forward end of travel limit.	4-18

Continued...

Code	Message Text	Description	Refer to Page
1008	Reverse End of Travel Limit	The machine is at the reverse end of travel limit.	4-18
1112	Positioner not in ready state for Color Change	The positioner has not reached the proper location for color change.	4-18
200x, 210x	Reciprocator		
2001	E-Stop Open	The E-Stop circuit is open.	4-23
2002	Encoder failure	The encoder is not responding when motion is commanded or is responding with defective signals.	4-23
2003	Motor Protector	The motor protector is open.	4-24
2004	Motion Controller	The motion controller indicates a failure.	4-24
2005	Forward Contactor	The forward contactor did not engage.	4-24
2006	Reverse Contactor	The reverse contactor did not engage.	4-24
2007	Forward End of Travel Limit	The machine is at the forward end of travel limit.	4-25
2008	Reverse End of Travel Limit	The machine is at the reverse end of travel limit.	4-25
2101	Part size less than minimum	The part detected is too small. The reciprocator will attempt to stroke at the minimum length.	4-25
2102	Lead gun not defined - using gun 1	The lead gun on the reciprocator is not defined.	4-25
2103	Trail gun not defined - using gun 1	The trailing gun on the reciprocator is not defined.	4-25
2104	Trail gun less than lead - trail = lead	The trailing gun number is less than the lead gun number.	4-25
2105	Pattern width not set - using 12 inches (305 mm)	The pattern width has not been set using default.	4-25
2106	Vertical scanner not configured - recip mode 1 invalid	A vertical scanner is required for variable stroke operation.	4-25
2107	Speed calculated less than minimum	The speed of the reciprocator is less than the minimum value allowed.	4-26
2108	Speed calculated greater than maximum	The speed of the reciprocator is greater than the maximum value allowed.	4-26
2113	Reciprocator not in ready state for Color Change	The reciprocator is not in the proper position for color change.	4-26
300x	Watchdog		
3100	Positioner Watchdog fault	The remote Ethernet device did not respond with a watchdog signal in 1 second.	4-18
3200	Reciprocator Watchdog fault	The remote Ethernet device did not respond with a watchdog signal in 1 second.	4-26
Continued...			

Code	Message Text	Description	Refer to Page
410x	Color Change		
4109	Clean cycle aborted arch clean operation - waiting on park release	Clean cycle detected an abort - waiting for user to press park to release.	4-18
4110	Clean cycle aborted by user action - park release detected	Clean cycle aborted by user - part release was detected.	4-18
4111	Clean cycle aborted detected machine lockout/watchdog	A machine malfunction aborted the cleaning operation.	4-18

CAN Network Errors

Table 4-2 CAN Network Errors

Error Code	Message	Cause/Correction
101	CAN bus fault detected	Hardware error. Check the CAN cable for shorts. If the cable is good, replace the PC104 CAN card.
102	CAN receive buffer overflow	Host CAN interface received too much data and could not process it quickly enough. Reboot the system.
103	Message timeout	Remote CAN device did not respond to a direct request in the allotted time. Check the gun card or iFlow card.
104	Went offline	Normal operational message. The user will see this message if the booth exhaust fan is shut off, which removes power from gun cards, or if the gun card is disconnected, or if the iFlow module is disconnected from the CAN network.
105	Returned to online	Normal operational message. No action required.
107	Communications errors	These error messages indicate that communications on the iControl CAN bus may be having problems. Troubleshooting should include verification of all CAN cable connections and grounding, and gun cable connections and continuity. CAN errors can also be caused by individual gun cards or the iControl PC to PC104 card interface. These errors do not indicate a specific device failure as all devices are in parallel on the CAN bus.
108		
109		
110		
111		
112		
113		

Gun Card Troubleshooting

Refer to Figure 4-1 and Tables 4-3 and 4-4. Use the fault codes on the Gun Control screens, the fault messages on the Alarm screen, and the LEDs on the gun control cards to diagnose problems with the gun control cards.

Gun Card Error Codes and Fault Codes

These faults, except for E16, will activate the alarm relay.

Table 4-3 Gun Card Error and Fault Codes

Error Code	Message	Fault Code	Meaning/Correction
301	Micro-Amp fault detected	-	Microamp value out of range.
302	Foldback fault detected	E15	Current foldback detected. Unplug the cable from the gun and trigger the gun. <ul style="list-style-type: none"> If the fault changes to E7, check the resistance of the multiplier as described in the gun manual. If the fault code stays E15, check the continuity of the cable as described in the gun manual.
303	Feedback fault detected	E3	Microamp feedback not detected. Check the gun current with no parts in front of the gun. If the current is 105 μ A, check for a short circuit of the current feedback wires in the gun cable: Unplug the cable from the gun and trigger the gun. <ul style="list-style-type: none"> If the fault stays E3, replace the cable. If the fault changes to E7, check the resistance of the multiplier as described in the gun manual.
304	Open circuit detected	E7	Gun cable or multiplier open circuit. If the current display is 1 μ A or less, check the multiplier cable and electrode assembly for loose connections. <ul style="list-style-type: none"> If the connections are secure, check the multiplier with an ohmmeter as described in the gun manual. If the multiplier reading is acceptable, check for a defective cable as described in the gun manual.
305	Short circuit detected	E8	Gun cable or multiplier short circuit. Unplug the cable from the gun and trigger the gun. <ul style="list-style-type: none"> If the fault changes to E7, check the resistance of the multiplier as described in the gun manual. If the fault code stays E8, check the continuity of the cable as described in the gun manual.
Continued...			

Error Code	Message	Fault Code	Meaning/Correction
306	Internal hardware failure	E11	Internal DSP fault in gun control card. 1. Turn off the power to the system. 2. Unplug the cable from the back of the gun. 3. Turn on the power to the system. If the fault code changes to E7 (open circuit), the card is working correctly. Check the gun multiplier. If the fault code remains at E11, replace the gun control card.
307	Tribo	E17	Tribomatic μ A feedback below setpoint. Check the powder flow for poor charging. Check for moisture in the compressed air supply.
308	Gun not detected	E16	Gun not connected to system. Check the gun cable connections and make sure the gun card is seated securely into the backplane. This is a normal indication if power to cards is removed, such as when the booth exhaust fan is shut off.
531	System heartbeat lost	-	Check circuit board connections.
532	5/24 volt power	-	Check circuit board connections.
533	Error writing to internal EEPROM	-	Hardware error. Replace card.
534	Error reading to internal EEPROM	-	Hardware error. Replace card.
535	Node address changed from last power up	-	Saved address does not match current address. Address switches were changed. Informational message only.
536	Internal database version changed - resetting to defaults	-	An update to the database was detected and the current data is no longer valid. Informational message only, operation should not be affected.
537	Preset out of range	-	The preset sent to the remote device was out of range. Check preset settings and reset as required.
538	Trigger ON message received - controller in lockout	-	The card was commanded to trigger but the system is locked out. Trigger ON commands will be ignored until the system is returned to the Run state.

Gun Card LEDs

See Figure 4-1. Use the card LEDs to help diagnose problems.

Table 4-4 Gun Card LEDs

LED	Color	Function	Correction
Fault	Red	Lights when a fault is detected (communication, gun cable, RAM, or hardware).	If two guns are not connected to the card this LED will light. This could be a normal condition if you have an odd number of guns in your system. Make sure the card is seated in the backplane. Open the Alarm screen and clear all faults. Replace the card if the malfunction cannot be corrected.
Status	Green	Flashing (heartbeat) when communicating properly with system.	If the status LED is not flashing, make sure the card is seated in the backplane. Turn console power off and on. Replace the card if the other gun control cards have heartbeats.
Foldback B (even-numbered gun)	Yellow	Lights if over-current protection circuit triggered due to high current draw from gun drive circuit.	Refer to the corrections for Fault Code E15 in Table 4-3.
Foldback A (odd-numbered gun)			
Power	Green	Light when power (5 volts) is applied to the board).	If the card has no power, make sure it is properly seated in the backplane and the locking tab is working correctly. Replace the card if the other gun control cards have power.




Figure 4-1 Gun Control Card LEDs and Switches

- | | | |
|--|----------------------------|----------------------------|
| 1. Reset switch (reboots the on-board processor) | 3. Status LED (green) | 5. Foldback A LED (yellow) |
| 2. Fault LED (red) | 4. Foldback B LED (yellow) | 6. Power LED (green) |

Prodigy HDLV Pump Troubleshooting

For additional troubleshooting and repair information, refer to the following manuals:

1062382 Prodigy HDLV Pump Manifold and Circuit Board
1081195 Prodigy HDLV Pump

Pump Controller Error Codes

Table 4-5 Pump Controller Error Codes

Error Code	Message	Meaning/Correction
571	System heartbeat lost	Check circuit board connections.
572	5/24 volt power	Check circuit board connections.
573	Error writing to internal EEPROM	Hardware error. Replace card.
574	Error reading to internal EEPROM	Hardware error. Replace card.
575	Node address changed from last power up	Saved address does not match current address. Address switches were changed. Informational message only.
576	Internal database version changed - resetting to defaults	An update to the database was detected and the current data is no longer valid. Informational message only, operation should not be affected.
577	Preset out of range	The preset sent to the remote device was out of range. Check preset settings and reset as required.
701	Pattern servo fault	The solenoid resistance was not detected or incorrect when the device was not triggered. When the solenoid is not energized, the resistance of the solenoid is checked by the system. These faults are generated if no resistance is detected, or the correct resistance is not detected. Check the proportional valve wiring connections. Check the solenoid operation. Replace the valve if the solenoid is bad.
702	Pump servo fault	The solenoid resistance was not detected or incorrect when the device was not triggered. When the solenoid is not energized, the resistance of the solenoid is checked by the system. These faults are generated if no resistance is detected, or the correct resistance is not detected. Check the proportional valve wiring connections. Check the solenoid operation. Replace the valve if the solenoid is bad.
705	Powder low PWM	Pump air flow less than commanded value. Check for obstruction in pump air flow control valve. Clean valve as described in pump manifold manual.
706	Partern low PWM	Pattern air flow less than commanded value. Check for obstruction in pattern air flow control valve. Clean valve as described in pump manifold manual.

Error Code	Message	Meaning/Correction
707	Powder high PWM	Powder air flow more than commanded value. Check output of flow regulator (center regulator in pump panel) - should be 85 psi. Check for kinked or blocked powder delivery tubing. Check for blocked pump flow air servo valve.
708	Pattern high PWM	Pattern air flow more than commanded value. Check output of flow regulator (center regulator in pump panel) - should be 85 psi. Check for kinked or blocked powder delivery tubing. Check for blocked pattern flow air servo valve.

Air Flow Re-Zero Procedure

Perform this procedure if the iControl gun control screens are indicating pattern air flow when a spray gun is off and no air is actually flowing. This procedure re-zeros the pump control cards to eliminate false air flow indications.

Before performing a re-zero procedure:

- Make sure the air pressure being supplied to the pump cabinet is higher than the minimum 5.86 bar (85 psi).
- Each pump circuit board in the pump cabinet controls two pumps and the pattern air for two spray guns. Make sure no air is flowing through the pumps, around the pump control manifold gaskets, or from around any of the solenoid valves on the manifold. Re-zeroing boards when leaks are present in the control manifolds will result in additional errors.

Re-Zero Procedure

See Figure 4-2. For each pump board that is being re-zeroed:

1. Disconnect the pattern air tubing controlled by the pump board from the output fittings on the rear panel of the pump cabinet.
2. Plug the output fittings.
3. Record the board number and address settings of SW1 for each pump board.
4. Set each address switch to zero.
5. Turn off the power to the pump cabinet, wait 5 seconds, then turn the power back on.
6. Press and hold the TEST button on each pump board until the red fault light turns on. Release the TEST button and wait for the red fault light to turn off.

7. Move the SW1 address switches back to their original positions.
8. Turn off the power to the pump cabinet, wait 5 seconds, then turn the power back on.
9. Remove the plugs from the pattern air output fittings and re-connect the pattern air tubing.
10. At the iControl console, check each gun control screen that was previously indicating air flow when the gun was off. No air flow should be indicated.




Figure 4-2 Dual Pump Control Board

Remote I/O (Ethernet) Network Troubleshooting

All Remote I/O Network faults will activate the alarm relay. Use the fault messages on the Alarm screen along with this table to diagnose and correct Ethernet network problems. You can also use the Network Status and Node Configuration screens, and the Remote Node Troubleshooting tables on page 4-31 to diagnose problems with the remote nodes.

Table 4-6 Ethernet Network Troubleshooting

Error Code	Message/Condition	Correction
901	I/O error	Check Ethernet wiring. Remote node could be disconnected from network or turned off.
902	Port or socket open error	Programming error. Contact Nordson technical support.
903	Serial port already open	Programming error. Contact Nordson technical support.
904	TCP/IP connection error	Check Ethernet wiring. Remote node could be disconnected from network or turned off.
905	TCP/IP Connection closed by remote peer fault (any remote node fault)	<p>Ethernet network communication with the remote node has been lost. This fault may be a normal response to removing electrical power from the remote node. If the remote node is an in/out positioner or reciprocator and communication is lost while operating in Auto mode, the machine will move to the Park position.</p> <p>Check the Network Node Status screen. If communication is lost the node icon should turn red. If no nodes are red, check the Network Node Configuration screen to find the device associated with the faulted node IP address.</p> <p>If multiple node faults are displayed:</p> <p>Check the electrical power supply to all faulted nodes.</p> <p>Check the Ethernet switch in the network interface box for electrical power and proper operation. The switch power LED should be lit and the network connection LEDs should be flashing. Replace the switch if necessary.</p> <p>Check the network cable and connections between the Ethernet switch and the iControl console. Refer to <i>Testing Ethernet Cables</i> in this section.</p> <p>Check the Ethernet card on the iControl PC for proper operation. The ACT LED indicates network traffic when lit. The LNK LED to the right of the RJ45 connector indicates network status (green: 10 Mbs, amber: 100 Mbs, off: no connection). Replace the card if necessary, using only an identical or Nordson supplied replacement.</p> <p>If a single node fault is displayed:</p> <p>Check the electrical power to the remote node controller or coupler.</p> <p>Check network cables and connections between the remote node and the Ethernet switch (in the network interface box). Refer to <i>Testing Ethernet Cables</i> in this section.</p>
906	Socket library error	Programming error. Contact Nordson technical support.
907	TCP port already bound	Programming error. Contact Nordson technical support.
908	Listen failed	Programming error. Contact Nordson technical support.

Continued...

Error Code	Message/Condition	Correction
909	File descriptors exceeded	Programming error. Contact Nordson technical support.
910	No permission to access serial or TCP port	Programming error. Contact Nordson technical support.
911	TCP port not available	Programming error. Contact Nordson technical support.
917	Checksum error	Noise in network. Check for loose connections or Ethernet cables routed parallel to high voltage or VFDs.
918	Invalid frame error	Noise in network. Check for loose connections or Ethernet cables routed parallel to high voltage or VFDs.
919	Invalid reply error	Noise in network. Check for loose connections or Ethernet cables routed parallel to high voltage or VFDs.
920	Reply time-out	Noise in network. Check for loose connections or Ethernet cables routed parallel to high voltage or VFDs.
921	Modbus exception response	Programming error or remote hardware error. Check Fieldbus controller functions. Refer to Remote Node Troubleshooting in this section.
925	Illegal Function exception response	Programming error or remote hardware error. Check Fieldbus controller functions. Refer to Remote Node Troubleshooting in this section.
926	Illegal Data Address exception response	Programming error or remote hardware error. Check Fieldbus controller functions. Refer to Remote Node Troubleshooting in this section.
927	Illegal Data Value exception response	Programming error or remote hardware error. Check Fieldbus controller functions. Refer to Remote Node Troubleshooting in this section.
928	Slave Device Failure exception response	Programming error or remote hardware error. Check Fieldbus controller functions. Refer to Remote Node Troubleshooting in this section.
-	Watchdog Fault (any remote node controller fault)	<p>Control program in remote node controller is not running, or controller has no program installed.</p> <p>NOTE: This fault may be a normal response to removing electrical power from the remote node.</p> <p>Check the remote node controller mode selection switch. The switch should be in the run (up) position.</p> <p>Replace the remote node controller. The replacement must be pre-programmed or a program must be downloaded and installed in the field.</p> <p>Contact Nordson Finishing Customer Support for details.</p>
-	Operation was successful	Normal operation. No action required.
-	Illegal argument error	Programming error. Contact Nordson technical support.
-	Illegal state error	Programming error. Contact Nordson technical support.
-	Evaluation expired	Programming error. Contact Nordson technical support.
-	I/O error class	Programming error. Contact Nordson technical support.
	Fieldbus protocol error class	Programming error. Contact Nordson technical support.

In/Out Positioner Troubleshooting

Use the fault messages on the Alarm screen with this table to diagnose and correct in/out positioner or reciprocator problems. Refer to Remote I/O Network Troubleshooting on page 4-14 if the fault messages indicate a communications problem (Watchdog fault or TCP/IP communications fault).

Each fault message displayed on the iControl screen is accompanied by a device and number identifier. The identifier indicates the faulted machine (for example, In/Out Positioner #1, Reciprocator #2). When the fault condition is corrected or cleared, the fault message will indicate a returned-to-normal status.

For all in/out positioner faults, the alarm relay contacts open to signal an alarm condition. You can use the alarm relay to activate an external alarm. Refer to Console Power Cable Connections in the Installation section for more information.

In/Out Positioner Error Code Troubleshooting

Table 4-7 In/Out Positioner Error Code Troubleshooting

Error Code	Message	Correction
1001	E-Stop Open	In/out positioner or reciprocator E-Stop button pressed. Determine why E-Stop button was pressed and correct if necessary. Reset E-stop button when clear to do so.
1002	Encoder Failure Fault	In/out positioner or reciprocator not moving. Mechanical, motor, or motor controller failure. Change in/out positioner or reciprocator operating mode to Manual and check for proper forward and reverse (up and down) motion. If only one direction of movement, check motor control circuits. If no motion, check the following: Check the positioner carriage to make sure it moves properly. Make sure that <ul style="list-style-type: none"> the anti-tip device is adjusted properly a carriage wheel bearing has not failed no obstructions are preventing motion. Check the pulleys, belts, or other mechanical link connecting the gear reducer to the gun moving carriage. If the gear reducer is not rotating but the motor is, replace the reducer. If the drive motor is not rotating, check the motor circuit protection, motor wiring, motor controller, and motor control circuits. This fault must be reset from the iControl alarm screen.
Continued...		

Error Code	Message	Correction
1003	Motor Protector	<p>Circuit protector limiting current to the in/out positioner or reciprocator motor has failed.</p> <p>Check mechanical components of in/out positioner for proper operation. Lubricate, repair, or replace components as needed.</p> <p>Check motor electrical circuit between protector and motor. Repair or replace wiring, terminals, or motor control components as needed.</p> <p>Reset circuit protector after corrections have been made.</p>
1004	Motion Controller Fault	<p>Motor speed controller "ready for operation" feedback signal has failed.</p> <p>Check the status display on the motor speed controller for fault indications. Status can only be displayed while power is applied. Cycling power to the controller will generally reset the fault condition. Determine the probable cause based on the controller fault status information.</p> <p>Correct the problem causing the fault or replace the controller if necessary.</p>
1005	Forward Contactor	<p>Auxiliary contact on the motor forward contactor did not close when the in/out positioner was commanded to move forward.</p> <p>Check forward contactor for proper operation. Repair or replace contactor as needed.</p> <p>Check control circuit and devices that energize the contactor for proper operation. Repair or replace components as needed.</p> <p>This fault must be reset from the iControl alarm screen.</p>
1006	Reverse Contactor Fault	<p>Auxiliary contact on the motor reverse contactor did not close when the in/out positioner was commanded to move in reverse.</p> <p>Check reverse contactor for proper operation. Repair or replace contactor as needed.</p> <p>Check control circuit and devices that energize the contactor for proper operation. Repair or replace components as needed.</p> <p>This fault must be reset from the iControl alarm screen.</p>
		<p>The in/out positioner or reciprocator position feedback encoder is not putting out pulses.</p> <p>NOTE: If an encoder fails, an in/out positioner will move to the reverse limit position. A reciprocator will stop.</p> <p>Check all encoder mechanical and electrical connections.</p> <p>Make sure the encoder is powered.</p> <p>Check pulse output from the encoder. Replace encoder if necessary.</p> <p>This fault must be reset from the iControl alarm screen.</p>

Continued...

Error Code	Message	Correction
1007 1008	Forward or Reverse End-of-Travel Limit fault	<p>In/out positioner color change cycle takes too long (Automatic color change system).</p> <p>During an automatic color change cycle the positioner is commanded to make both forward and reverse moves.</p> <p>This fault occurs if the positioner did not reach the limit in a set amount of time (20 seconds for forward and 75 seconds for reverse).</p> <p>For a 1007 Forward fault:</p> <p>Check for an obstruction to forward motion. Check the operation of the forward limit switch.</p> <p>For a 1008 Reverse fault:</p> <p>Check for an obstruction to reverse motion. Check the operation of the reverse limit switch.</p> <p>If there is no obstruction and the reverse limit switch is good, increase the motion speed slightly.</p>
1112	Positioner not in ready state for color change Positioner code: 1112	<p>In/out positioner not in Manual or Auto mode.</p> <p>Color change cycle cannot start unless in/out positioner is in Manual or Auto mode. Set in/out positioner mode to Manual or Auto.</p>
3100	Positioner Watchdog fault	<p>The positioner controller did not respond with a watchdog signal in 1 second.</p> <p>Check the Ethernet cable connections and the positioner controller.</p>
4109	Clean cycle aborted Arch clean operation waiting on Park release (Euro color change only)	<p>During a SpeedKing booth cleaning cycle, an in/out positioner has moved off its reverse limit switch or the limit switch has failed.</p> <p>All in/out positioner reverse limit switches must be engaged for iControl system to send "OK for Cleaning Arch" signal.</p> <p>Check in/out positioners for position, check limit switches and replace failed switch.</p>
4110	Clean cycle aborted by user action - Park release detected (Euro color change only)	<p>Park button touched causing color change cycle to abort.</p> <p>Touching the Park button to abort the color change cycle is a normal function. If the button was mistakenly touched before the cycle ended, the cycle must be restarted from the beginning.</p>
4111	Clean cycle aborted detected machine lockout/watchdog fault (Euro color change only)	<p>Communication with in/out positioner or reciprocator controller lost during color change cycle.</p> <p>Check the iControl alarm log for Watchdog or TCP/IP faults. Refer to Remote I/O Network Troubleshooting on page 4-14.</p>

Other In/Out Positioner Troubleshooting

Table 4-8 Other In/Out Positioner Troubleshooting

Problem	Cause	Correction
No movement from in/out positioner in response to move command	A fault has occurred preventing operation.	Check the iControl alarm log. Identify the fault and review the fault troubleshooting information in this table.
	Controller configuration jumpers not in place.	Refer to in/out positioner or in/out positioner/reciprocator control panel drawings in Section 7 for function identification and jumper placement instructions.
	Configuration lockout applied to in/out positioner.	Check the In/Out Positioner control screen for the lockout indicator. Lockout is applied from the Configuration screens.
	iControl lockout applied to guns, in/out positioners, and reciprocators.	This is a normal condition unless a failure has occurred. Refer to <i>Photoeye, Encoder, and Interlock Troubleshooting</i> in this section.
	Remote disable applied to in/out positioner controller. No status display on iControl screens.	If Nordson USA ColorMax system: Disable action is applied by a remote system control panel keyswitch. In the Disable position, the keyswitch opens the disable input circuit at the in/out positioner controller. No corrective action is required unless the keyswitch Normal position does not allow motion. Refer to your system drawings for circuit details. If not Nordson USA ColorMax system: Apply jumper to force On the remote disable input. Refer to system drawings for jumper application.
No in/out positioner response when Auto mode selected	A fault has occurred preventing Auto operation.	Check iControl alarm screen. Identify the fault and correct. Review the related faults and corrections listed in this table.
	iControl in/out positioner configuration settings have not been completed.	Refer to Network Configuration and In/Out Positioner Configuration in the iControl Operator Interface manual. Make sure all required settings have been made and are correct. Refer to the in/out positioner/reciprocator control panel drawings and make sure all connections have been made correctly.
Continued...		

Problem	Cause	Correction
Auto mode is selected, homing has completed, but no auto positioning response from in/out positioner	Auto hold action has been applied to the in/out positioner.	<p>The in/out positioner is forced to the Retract position (refer to in/out positioner configuration setting).</p> <p>This is a normal and temporary occurrence when the iControl system does not know the status of the parts on the conveyor between the in/out positioner scanner and the in/out positioner. This condition occurs when the iControl console is powered up or rebooted and part tracking (shift register) information is lost.</p> <p>Auto positioning will commence when parts identified by the in/out positioner scanners arrive at the in/out positioner.</p> <p>Manual positioning is allowed during this period.</p>
	Booth interlock has opened (booth exhaust fan shut down).	<p>The booth exhaust fan has been turned off. The in/out positioner moves to the Park position (refer to in/out positioner configuration settings) if the Auto mode is selected.</p> <p>The in/out positioners can be operated manually while the booth fan is off.</p>
	In/Out Positioner scanner not responding to parts passing by on the conveyor.	<p>Conveyor encoder not sending pulses to the iControl system. Refer to <i>Photoeye, Encoder, and Conveyor Interlock Troubleshooting</i> on page 4-30.</p> <p>In/Out Positioner scanners not detecting parts:</p> <p>Check scanner input values on the Input Status screen. Refer to the <i>Monitoring Operation</i> section of the iControl Operator Interface manual.</p> <p>Check for scanner remote node communication failure on the Network Node Status screen and Node Configuration screens. Refer to <i>Remote I/O Network Troubleshooting</i> on page 4-14.</p> <p>Check for electrical power at the scanner controllers.</p> <p>Check for a voltage signal, 0-10 Vdc = length of scanner (0 = maximum), from the scanner controller to the analog input module. Refer to the In/Out Positioner Scanner Junction Box drawings in this manual.</p> <p>If a voltage signal is read at the analog input module, and there is no problem with the Ethernet network connections to the controller node, then replace the analog input module.</p>
	In/Out Positioner preset set to Fixed.	Normal operating scenario. Position change will only occur when a new part appears at the in/out positioner.

Continued...

Problem	Cause	Correction
Auto mode is selected, in/out positioner stays at the reverse limit position	Refer to Problem "Auto mode is selected, homing has completed, but no auto positioning response from in/out positioner."	
	Park/Clean and Retract position values set too high. Set the Park/Cle	<p>an and Retract position values to less than reverse limit switch position value. If the values are greater, the in/out positioner will stop at the reverse limit switch and generate a fault condition during normal operation.</p> <p>NOTE: If the in/out positioner is an analog version, then the Reverse Limit value must equal the position at the reverse limit switch.</p>
In/Out Positioner "jumps" back to a stop after moving to a new position	In/Out Positioner Hysteresis value too small.	<p>Open In/Out Positioner Configuration screen and increase the Hysteresis value.</p> <p>The hysteresis value is the allowable over- or under-shoot distance from the target position. If the in/out positioner is within this distance of the desired position when it stops, the iControl system will not move it again to the target position. If the value is not large enough, the in/out positioner will over- or under-shoot its destination and then "jump" back to it (called hunting).</p> <p>A typical setting is 0.5 - 0.7 inches depending on the in/out positioner speed setting.</p>
In/Out Positioner actual travel distance does not match value shown on iControl screens	In/Out Positioner position calibration not completed, or in/out positioner forward or reverse limit switch moved since last position calibration.	<p>In/Out Positioner calibration involves moving the in/out positioner to a stop at the forward limit switch and then within 60 seconds moving it to the reverse limit switch. This sets zero at the forward limit switch and a reverse limit reference at the reverse limit switch.</p> <p>Calibration is performed during in/out positioner configuration, but can be performed at any time while in Manual mode.</p> <p>If the physical position of either limit switch has been changed, then positioning will be incorrect. You must recalibrate the in/out positioner if you move the limit switches.</p> <p>NOTE: The first time Auto mode is selected after in/out positioner power up, the in/out positioner moves to the reverse limit switch (home) and acquires a reverse reference value. This value is used to reset the in/out positioner position for Auto operations.</p>
Continued...		

Problem	Cause	Correction
In/Out Positioner actual travel distance does not match value shown on iControl screens (continued)	Incorrect encoder resolution entered on in/out positioner configuration screen.	<p>NOTE: Encoder resolution can only be entered or changed by a Nordson representative.</p> <p>Verify encoder resolution (number of pulses output for one inch of travel) and enter that value on the in/out positioner configuration screen.</p> <p>If the number is not know and cannot be mechanically calculated, then a trial and error method can be attempted. Perform this procedure from the in/out positioner configuration screen:</p> <ol style="list-style-type: none"> 1. Manually move the in/out positioner to the forward limit (zero position). 2. Reverse the in/out positioner slightly off the limit, record the displayed position value, and apply reference marks to the in/out positioner and base. 3. Manually move the in/out positioner in reverse, almost but not all the way to the reverse limit (the greater the distance the more accurate the calculated resolution will be). 4. Use your reference marks to measure the distance moved and compare the measured distance to the displayed position value. 5. The ratio of these two values is used to calculate a new encoder resolution. If the displayed position value is greater than the measured distance, then increase the encoder resolution. If the displayed position value is less than the measure value, then decrease the resolution.
	Mechanical failure in connection of in/out positioner encoder to machine motion.	Check the mechanical components and connections linking the encoder rotation to the movement of the in/out positioner.

Reciprocator Troubleshooting

Use the fault messages on the Alarm screen with this table to diagnose and correct reciprocator problems. Refer to Remote I/O Network Troubleshooting on page 4-14 if the fault messages indicate a communications problem (Watchdog fault or TCP/IP communications fault).

Each fault message displayed on the iControl screen is accompanied by a device and number identifier. The identifier indicates the faulted machine (for example, In/Out Positioner #1, Reciprocator #2). When the fault condition is corrected or cleared, the fault message will indicate a returned-to-normal status.

For all in/out positioner faults, the alarm relay contacts open to signal an alarm condition. You can use the alarm relay to activate an external alarm. Refer to Console Power Cable Connections in the Installation section for more information.

Reciprocator Error Code Troubleshooting

Table 4-9 Reciprocator Error Code Troubleshooting

Error Code	Message	Correction
2001	E-Stop Open	In/out positioner or reciprocator E-Stop button pressed. Determine why E-Stop button was pressed and correct if necessary. Reset E-stop button when clear to do so.
2002	Encoder Failure Fault	In/out positioner or reciprocator not moving. Mechanical, motor, or motor controller failure. Change in/out positioner or reciprocator operating mode to Manual and check for proper forward and reverse (up and down) motion. If only one direction of movement, check motor control circuits. If no motion, check the following: Check the positioner carriage to make sure it moves properly. Make sure that <ul style="list-style-type: none"> the anti-tip device is adjusted properly a carriage wheel bearing has not failed no obstructions are preventing motion. Check the pulleys, belts, or other mechanical link connecting the gear reducer to the gun moving carriage. If the gear reducer is not rotating but the motor is, replace the reducer. If the drive motor is not rotating, check the motor circuit protection, motor wiring, motor controller, and motor control circuits. This fault must be reset from the iControl alarm screen.
Continued...		

Error Code	Message	Correction
2003	Motor Protector	<p>Circuit protector limiting current to the in/out positioner or reciprocator motor has failed.</p> <p>Check mechanical components of in/out positioner for proper operation. Lubricate, repair, or replace components as needed.</p> <p>Check motor electrical circuit between protector and motor. Repair or replace wiring, terminals, or motor control components as needed.</p> <p>Reset circuit protector after corrections have been made.</p>
2004	Motion Controller Fault	<p>Motor speed controller “ready for operation” feedback signal has failed.</p> <p>Check the status display on the motor speed controller for fault indications. Status can only be displayed while power is applied. Cycling power to the controller will generally reset the fault condition. Determine the probable cause based on the controller fault status information.</p> <p>Correct the problem causing the fault or replace the controller if necessary.</p>
2005	Forward Contactor	<p>Auxiliary contact on the motor forward contactor did not close when the in/out positioner was commanded to move forward.</p> <p>Check forward contactor for proper operation. Repair or replace contactor as needed.</p> <p>Check control circuit and devices that energize the contactor for proper operation. Repair or replace components as needed.</p> <p>This fault must be reset from the iControl alarm screen.</p>
2006	Reverse Contactor Fault	<p>Auxiliary contact on the motor reverse contactor did not close when the in/out positioner was commanded to move in reverse.</p> <p>Check reverse contactor for proper operation. Repair or replace contactor as needed.</p> <p>Check control circuit and devices that energize the contactor for proper operation. Repair or replace components as needed.</p> <p>This fault must be reset from the iControl alarm screen.</p>
		<p>The in/out positioner or reciprocator position feedback encoder is not putting out pulses.</p> <p>NOTE: If an encoder fails, an in/out positioner will move to the reverse limit position. A reciprocator will stop.</p> <p>Check all encoder mechanical and electrical connections.</p> <p>Make sure the encoder is powered.</p> <p>Check pulse output from the encoder. Replace encoder if necessary.</p> <p>This fault must be reset from the iControl alarm screen.</p>
Continued...		

Error Code	Message	Correction
2007 2008	Forward or Reverse End-of-Travel Limit fault	<p>Auto mode is selected and the reciprocator has engaged the forward (upper) or reverse (lower) end-of-travel limit sensor. Select Manual mode and move the reciprocator off the limit, then re-select Auto mode.</p> <p>Check the configured soft top and bottom limits. Make sure they do not allow travel to the limit sensors.</p> <p>Adjust the configured reciprocator Turn-Around Offset (Nordson CSR only) to ensure that the limit sensors are not engaged.</p> <p>Check reciprocator encoder wiring. If signals switched position tracking will be reversed. Typically only seen on initial startup or if encoder is replaced.</p> <p>Reciprocator encoder has failed. Refer to Encoder Failure fault.</p>
		<p>Gun carriage has fallen to the reverse limit as a result of a mechanical failure.</p> <p>Check belts, pulleys, bearings, etc. for proper operation. Refer to reciprocator manual.</p> <p>This fault must be reset from the iControl Alarm screen.</p>
		<p>Gun carriage has slowly drifted or was moved to the top or bottom of stroke.</p> <p>Incorrect counterweight to neutralize the weight of the guns and gun carriage. Refer to reciprocator manual.</p> <p>This fault must be reset from the iControl Alarm screen.</p>
2101	Part size less than minimum	<p>Default or preset settings define a stroke length less than the minimum 4 in.</p> <p>Change default or preset settings, or if parts are small consider turning off reciprocators for batch.</p>
2102	Lead gun not defined - using gun 1	<p>Lead gun number not entered in reciprocator configuration. Enter number for lead gun in reciprocator configuration.</p>
2103	Trail gun not defined - using gun 1	<p>Trail gun number not entered in reciprocator configuration. Enter number for trail gun in reciprocator configuration.</p>
2104	Trail gun less than lead - trail = lead	<p>Lead and trail gun numbers not entered correctly in reciprocator configuration.</p> <p>Correct gun number entries in reciprocator configuration. Lead gun number must be lower than trail gun number.</p>
2105	Pattern width not set - using 12 inches	<p>No value for pattern width entered in reciprocator configuration. Enter value for pattern width in reciprocator configuration.</p>
2106	Vertical scanner not configured - reciprocator mode 1 invalid	<p>Reciprocator set for variable stroke mode, no part size data available.</p> <p>A part size, as seen by a vertical scanner or customer PLC, is required for variable mode. If no part size data is available, set reciprocator to a fixed mode.</p>
Continued...		

Error Code	Message	Correction
2107	Speed calculated less than minimum	Default or preset settings for variable mode resulting in speed less than minimum. Minimum speed is 15 ft/min. Change default or preset settings. Part may be too small to use variable mode, change to a fixed mode.
2108	Speed calculated greater than maximum	Default or preset settings for variable mode or fixed with conveyor synchronization resulting in speed faster than maximum. Change the default or preset settings or reduce the conveyor speed.
1112	Positioner not in ready state for color change	In/out positioner not in Manual or Auto mode. Color change cycle cannot start unless in/out positioner is in Manual or Auto mode. Set in/out positioner mode to Manual or Auto.
2113	Reciprocator not in ready state for color change	Reciprocator not in Auto mode. Color change cycle cannot start unless reciprocator is in Auto mode. Set reciprocator mode to Auto.
3200	Reciprocator Watchdog fault	The reciprocator controller did not respond with a watchdog signal in 1 second. Check the Ethernet cable connections and the reciprocator controller.

Other Reciprocator Troubleshooting

Table 4-10 Other Reciprocator Troubleshooting

Problem	Cause	Correction
No movement from reciprocator in response to move command	A fault has occurred preventing operation.	Check the iControl alarm log. Identify the fault and review the fault troubleshooting information in this table.
	Controller configuration jumpers not in place.	Refer to in/out positioner/reciprocator control panel drawings in Section 7 for function identification and jumper placement instructions.
	Configuration lockout applied to reciprocator.	Check the Reciprocator control screen for the lockout indicator. Lockout is applied from the Configuration screens.
	iControl lockout applied to guns, in/out positioners, and reciprocators.	This is a normal condition unless a failure has occurred. Refer to <i>Photoeye, Encoder, and Interlock Troubleshooting</i> in this section.
Continued...		

Problem	Cause	Correction
No movement from reciprocator in response to move command (<i>continued</i>)	Remote disable applied to reciprocator controller. No status display on iControl screens.	<p>If Nordson USA ColorMax system:</p> <p>Disable action is applied by a remote system control panel keyswitch. In the Disable position, the keyswitch opens the disable input circuit at the controller.</p> <p>No corrective action is required unless the keyswitch Normal position does not allow motion. Refer to your system drawings for circuit details.</p> <p>If not Nordson USA ColorMax system:</p> <p>Apply jumper to force On the remote disable input. Refer to system drawings for jumper application.</p>
No reciprocator response when Auto mode selected	A fault has occurred preventing Auto operation.	<p>Check iControl alarm screen.</p> <p>Identify the fault and correct. Review the related faults and corrections listed in this table.</p>
	iControl reciprocator configuration settings have not been completed.	<p>Refer to <i>Network Configuration</i> and <i>Reciprocator Configuration</i> in the iControl Operator Interface manual. Make sure all required settings have been made and are correct.</p> <p>Refer to the in/out positioner/reciprocator control panel drawings in Section 7 of this manual and make sure all connections have been made correctly.</p>
Reciprocator changes direction before or after the programmed turn-around position in Auto mode	Turn-around offset not set correctly.	An error close to $\pm 1/2$ in. of the set turn-around position is normal. Before making adjustments to the offset setting, make sure the encoder resolution is correct. Refer to <i>Reciprocator Configuration</i> in the iControl Operator Interface manual.
	Incorrect reciprocator encoder resolution entered.	The accuracy of the displayed position versus the actual position of the reciprocator is determined by the configured encoder resolution. Check the encoder resolution value.
Reciprocator does not display 0.0 position after the homing process	Reciprocator has overtraveled the position slightly before coming to a stop	This is normal. The position displayed after homing is the actual position. During homing, the 0.0 position is set at the forward limit, then the reciprocator moves down 1 inch before stopping. The stop action produces the overtravel.
Continued...		

Problem	Cause	Correction
Reciprocator measured travel position does not match the value shown on the reciprocator control panel or configuration screen	Reciprocator not homed.	Touch the Home button and wait for the homing sequence to finish, then check the position accuracy. The displayed position will not be correct until the reciprocator is homed.
	Incorrect reciprocator encoder value entered.	The accuracy of the displayed position versus the actual position of the reciprocator is determined by the configured encoder resolution. Check the encoder resolution value.
	Belt drive sprocket slipping.	Make sure the drive belt sprocket is securely connected to the gear reducer output shaft.
Reciprocator does not move in response to move command	Refer to condition "No movement from reciprocator in response to move command."	
	Mechanical failure, drive belt not engaging drive sprocket, or drive sprocket slipping.	The position value changes but the reciprocator does not move. This can occur because the encoder is connected directly to the gear reducer output shaft. Check the drive belt and sprocket.
	Incorrect reciprocator speed controller parameters.	Speed controller parameters must be set to specified values in order to respond correctly to signals from reciprocator controller. Refer to the In/Out Positioner/Reciprocator Control Panel drawings in Section 7 of this manual.
No reciprocator response when Auto mode selected	Refer to condition "No reciprocator response when Auto mode selected."	
	Auto cycle delay in progress	A 5 second delay occurs when Auto mode is selected. During the delay a warning beeper should sound.
	An end-of-travel limit switch is engaged.	Check the iControl Alarm log. Identify the fault and review the fault troubleshooting information.
	Invalid reciprocator stroke settings.	Speed controller parameters must be set to accept commands from the reciprocator controller. Refer to the in/out positioner/reciprocator control panel drawings in Section 7 of this manual.
Reciprocator "jumps" back to a stop after moving to a new position	Reciprocator Hysteresis value too small.	<p>Open the Reciprocator Configuration screen and increase the Hysteresis value.</p> <p>The hysteresis value is the allowable over- or under-shoot distance from the target position. If the reciprocator is within this distance of the desired position when it stops, the iControl system will not move it again to the target position. If the value is not large enough, the reciprocator will over- or under-shoot its destination and then "jump" back to it (called hunting).</p> <p>A typical setting is 0.5 - 0.7 inches depending on the reciprocator speed setting.</p>

Other Fault Messages and Conditions

Table 4-11 Other Fault Messages and Conditions

Message or Condition	Cause/Correction
Message: Too many (few) control nodes found	Number of gun cards/pump cards does not match number of guns setting in Guns Configuration screen (System Configuration). This could be a normal condition if you have an odd number of guns in your system. The red Fault LED on the gun card will light if two guns are not connected to the card.
Message: Gun not detected	Check gun cable connections. If cables are all connected properly, open iControl enclosure door and check gun control card connections. This could be a normal condition if you have an odd number of guns in your system.
Message: Failure reading database	No data or configuration displays on screens. User data card missing, defective, or wrong size. Replace card. Compact Flash adapter failure. Replace adapter.
Condition: iControl screen partially boots up. Screen is blank except for possible text display, or screen displays "Hit ESC for .altboot..."	Program card is missing, blank, or defective. Replace card. Program card in wrong adapter slot. Insert program card in outer slot. Compact Flash adapter failure. Replace adapter. No power to Compact Flash adapter. Check power cable and connection to adapter. Check ribbon cable connections to Compact Flash adapter and PC. Replace ribbon cable if necessary. (Standard 40-pin IDE cable, not available from Nordson.)
Condition: Pickoff value is reset to smaller number after entry	The maximum pickoff length is 4096 inches (104038.4 mm). With the keypad you can enter a number larger than the maximum, but when you save your entry the value will be automatically reduced to the maximum value.
Condition: Inconsistent lead and lag timing for auto gun triggering or moving	Conveyor encoder pulse rate is too fast. Maximum is 10 Hz (10 pulses/second). Some pulses are not being detected. Reduce the conveyor speed or change the encoder-to-conveyor linkage to reduce the pulse frequency.
Condition: Lockout message does not display when keyswitch turned to lockout position, or lockout cannot be canceled by turning keyswitch to another position	Booth exhaust fan is off (turning off switched power to the console), or remote lockout is on. If the exhaust fan is turned off before turning the switch to Lockout, then lockout cannot be activated. If the fan is turned off after the switch is turned to Lockout, then lockout cannot be canceled. Turn fan on to correct. If the remote lockout is on, turn it off. Remote lockout is activated by a customer-supplied switching device connected to the remote lockout relay in the console.
Condition: iControl screen is locked up (no response)	Cycle console power. If condition persists, program card is corrupted. Obtain and install another program card. Refer to Touch Screen Calibration when installing new program cards.

Photoeye, Encoder, and Interlock Troubleshooting

Use the I/O board LEDs and the relay LEDs in the master console to troubleshoot problems with the photoeye, encoder, interlock, and alarm circuits.

Table 4-12 Photoeye, Encoder, and Interlock Troubleshooting

Inputs	I/O Board Terminals	Troubleshooting
Zone Photoeyes	1 - 8	Photoeyes are set for breaklight. When a part passes in front of the zone photoeyes, the LEDs for the zone photoeyes should light. If they do not, check the photoeye wiring and photoeyes.
Flag Photoeyes or scanners or Inputs from customer Part ID system	9 -16	Photoeyes and scanners are set for breaklight. When a flag passes in front of the photoeyes, the LEDs for those photoeyes blocked by the flag, or the LEDs receiving a signal from the customer part ID system should light. If they do not check the wiring and photoeyes or customer part ID system.
Encoder	20	The LED should flash at the same rate as the encoder signal. If it is not flashing when the conveyor is moving check the encoder wiring and encoder.
Conveyor Interlock	24	The LED should light as long as the conveyor is on or the keyswitch is in the bypass position. If it is not on check the conveyor interlock wiring. Without this signal the spray guns will not be triggered.
Relays (DIN rail)	-	The conveyor interlock relay LED lights when the conveyor is running. The remote lockout relay LED is lit as long as it is receiving a signal (lockout on). The alarm relay LED stays lit until an alarm occurs, then goes out.
All	1-24	<p>Input LEDs should indicate as described above. If none of the LEDs will turn on, then check the following screens:</p> <p>Zone and Part ID Inputs: Open the Input Status screen. Inputs should display as lighted indicators.</p> <p>Encoder: On the Main screen, if the encoder is providing a signal then the conveyor speed should be greater than zero.</p> <p>Conveyor Input: On the Main screen, if the conveyor is running then the conveyor indicator should be green.</p> <p>If the input indicators on the Main and Input Status screens are lit but the I/O board LEDs are not, then:</p> <p>Check the dipswitch and jumper settings on the PC104 I/O board (see Figure 7-4 for the settings). If settings are correct, replace the PC104 I/O board, ribbon cable, and I/O board. A new cable is shipped with the I/O board.</p> <p>WARNING: Always turn console power off before changing jumper and dipswitch settings on circuit boards. If ribbon cable is not keyed, make sure the colored trace in the ribbon cable is aligned with pin 1 at both connectors.</p> <p>If the conveyor interlock LED (24) on the I/O board is operating correctly and all or some of LEDs 1-20 are responding erratically, then check the I/O board inputs common voltage. For sinking inputs, +24 Vdc is applied to all HI terminals on the board as inputs common.</p>

Remote Node (FieldBus Controller/Coupler) Troubleshooting

Use the following tables and the LEDs on the FieldBus devices in the in/out positioner scanner junction box and in/out positioner / reciprocator control panels for assistance in troubleshooting them. Unless instructed otherwise, contact Nordson Finishing Technical Support for assistance.

FieldBus Status

Table 4-13 FieldBus Controller Status LEDs

LED	Meaning	Troubleshooting
ON		
Green	Fieldbus initialization is correct.	Normal operation
Off	Fieldbus initialization is not correct, no function or self test.	Check the supply voltage (24V and 0V), check the IP configuration.
LINK		
Green	Link to the remote i/o network exists.	Normal operation
Off	No link to the remote i/o network.	Check Ethernet connections and cables.
TxD/RxD		
Green	Data exchange taking place.	Normal operation
Off	No data exchange.	Make sure the iControl console is powered on. Make sure the remote node has been configured by checking the Network Status screen and Node Configuration screen. Check the iControl Alarm screen for remove node fault messages.
ERROR		
Red	Error on the fieldbus.	Check wiring.
Off	No error, normal operation.	

Node Status

Table 4-14 FieldBus Controller Node Status LEDs

LED	Meaning	Troubleshooting
I/O		
Green	Fieldbus device operating normally.	Normal operation
Red	During startup: Internal bus being initialized, LED flashes fast for 1-2 seconds.	Normal operation
Red	After startup: Three consecutive flashing sequences with pauses between each indicate errors.	Refer to the fault codes, arguments, and description in Table 4-16, I/O Errors.
Orange	Failure of input or output module connected to controller.	Check I/O modules, replace if necessary.

Voltage LEDs

The two green LEDs in the FieldBus supply section display the supply voltage. The (A) LED indicates the 24 V supply; the (B) LED indicates the supply to the field side (power jumper contacts).

Table 4-15 FieldBus Controller Voltage LEDs

LED	Meaning	Troubleshooting
A		
Green	Operating voltage exists.	Normal operation
Off	No operating voltage.	Check the supply voltage (24 V and 0 V)
B		
Green	Operating voltage for power jumper contacts exists.	Normal operation
Off	No operating voltage for power jumper contacts.	Check the supply voltage (24 V and 0 V)

I/O Errors

If a fault is detected, the I/O LED blinks in three consecutive flash sequences: first a series of short flashes, then a pause, then the error code number, another pause, then the error code argument.

Table 4-16 FieldBus Controller I/O Fault LEDs

Fault Argument	Fault Description
Fault Code 1: Hardware and configuration fault	
0	EEPROM check sum fault/check sum fault in the parameter area of the flash memory.
1	Overflow of the internal buffer memory for the inline code.
2	Unknown data type.
3	Module type of the flash program memory could not be determined/is incorrect.
4	Fault when writing in the flash memory.
5	Fault when deleting in the flash memory.
6	Changed I/O module configuration determined after autoreset.
Fault Code 2: Fault in the programmed configuration	
0	Incorrect table entry.
Fault Code 3: Internal bus command fault	
0	No error argument.
Fault Code 4: Internal bus data fault	
0	Data fault on internal bus or internal bus interruption on coupler.
n* (n>0)	Internal bus interrupted after I/O module n.
Fault Code 5: Fault during register communication	
n*	Internal bus fault during register communication after I/O module n.
Fault Code 6: FieldBus specific error	
1	No reply from the BootP server.
2	Ethernet controller not recognized.
3	Invalid MAC ID.
4	TCP/IP initialization error.
Fault Code 7: I/O module not supported	
n*	I/O module at position n is not supported.
Fault Code 8: Not used	
Fault Code 9: CPU-TRAP error	
1	Illegal opcode.
2	Stack overflow.
3	Stack underflow.
4	NMI

Touch Screen Troubleshooting

Touch Screen Calibration

The touch screen is calibrated at the factory. If you change a program card, or the iControl PC, or have problems touching screen components accurately, you will have to recalibrate the screen.

Normal Calibration

NOTE: If you install a program card that was previously used on another iControl console, you **MUST** perform the Calibration with a Mouse procedure to calibrate the touch screen.

The touch screen calibration values are stored on the program card. If you install a new program card, one that has never been used before, there will be no calibration file on the card. The system will automatically start the calibration procedure.

Follow the calibration instructions on the screen exactly, using your finger to touch the targets. When you have completed the calibration procedure, touch the **iControl** button to start the iControl software.

You can calibrate the touch screen at any time. To start a normal calibration, start the Program Shutdown procedure. When the operating system shutdown prompt appears on the screen, touch the Cancel button, then touch the CAL button.

Problems During Calibration

If you do not follow the calibration instructions exactly: You will not be able to touch the center **Completion** button and exit the calibration procedure. If this happens, stop and wait until the procedure times out. You should then be able to repeat the procedure and complete it correctly. When you have completed the calibration procedure, touch the **iControl** button to start the iControl software.

If console power is shut off during the calibration procedure: The calibration file on the program card will be corrupted. On power up, you will not be able to touch the CAL button to start the calibration procedure. If this happens, perform the Calibration with a Mouse procedure

Calibration with a Mouse



WARNING: Do not spray powder while the console door is open. Shut off the booth exhaust fan to remove switched power from the console and prevent spray gun operation while performing this procedure. Failure to observe this warning could create a hazardous condition and could result in personal injury or property damage.

Use this procedure to recalibrate the touch screen if you cannot touch the CAL button or the buttons on the iControl screens, or if you install a program card previously used in another iControl console.

NOTE: You must shut off console power before connecting or disconnecting a mouse or keyboard from the iControl PC.

1. Turn off console power.
2. Open the iControl cabinet door and connect a mouse with a PS2 connector to the MOUSE port on left side of the iControl PC.
3. Turn on power and allow the operating system to load. The CAL button is displayed on the touch screen before the iControl software loads.
4. Use the mouse to move the cursor to the CAL button and click on it. The touch screen calibration procedure will start.

NOTE: If you miss the CAL button, allow the iControl software to load, then, if possible, open the System Configuration screen and touch the Program Shutdown button. When the operating system shutdown prompt appears on the screen, touch the Cancel button, then touch the CAL button. If you cannot touch any buttons on the screen, then you will have to cycle console power and try again.

5. When the calibration procedure starts, USE YOUR FINGER, NOT THE MOUSE, to touch the calibration targets, following the instructions on the screen carefully. When you have completed the calibration procedure, touch the iControl button to start the iControl software.
6. Test the touch screen calibration, then perform a program shutdown, turn off console power, and disconnect the mouse.

No Touch Screen Display

Check the following:

- Check the power LED on the front bezel below the screen. If LED is not lit then PC is not powered up.
- Make sure console power switch is on.
- Open the console door and make sure the PC power switch is on.

Have an electrician check these:

- Console fuses on the DIN rail, at the incoming power terminals.
- Unswitched power connections to the fuse blocks.
- Power supply to the console.

Touch Screen Failure



WARNING: Do not spray powder with the iControl console door open unless the console opening, the door, and all externally connected devices are out of the hazardous area surrounding any opening of the spray booth. The hazardous area extends 3 feet outward from an opening and continues in a 3 foot arc from the edge of an opening. Failure to observe this warning could create a hazardous condition and could result in personal injury or property damage.

Screens Display, but Touch Function Does Not Work

If the mouse pointer on the screen does not move to wherever you touch the screen, touching buttons does not work, and the touch screen cannot be calibrated, then the touch screen has failed. You must replace the iControl PC.

Temporary Fix: Shut off console power and connect a mouse with a PS2 connector to the MOUSE port of the left side of the iControl PC. Turn on console power and allow the system to boot up. You should now be able to use the mouse to point and click on screen buttons and data fields. Replace the iControl PC as soon as possible.

No Display

If the PC has power but nothing displays on the screen, then the screen has failed. You must replace the iControl PC.

Temporary Fix: Shut off console power and connect a VGA monitor, keyboard, and mouse to the PC ports. Turn console power on. If the boot screens and iControl screens display on the VGA monitor, you can use the mouse to click on buttons and select fields and use the keyboard to enter and change values. Replace the iControl PC as soon as possible.

Rotary Knob Troubleshooting

If rotating the knob on the keypad panel does not change the selected data field value, the signal from the knob is not being received by the iControl PC. If this happens, check the wiring connections from the keypad panel to the iControl PC. If the connections are good, replace the keypad panel.



WARNING: Do not spray powder with the iControl console door open unless the console opening, the door, and all externally connected devices are out of the hazardous area surrounding any opening of the spray booth. The hazardous area extends 3 feet outward from an opening and continues in a 3 foot arc from the edge of an opening. Failure to observe this warning could create a hazardous condition and could result in personal injury or property damage.

Temporary Fix: Perform a program shutdown and turn off console power. Connect a standard PC keyboard with a PS2 connector to the KEYBOARD port on the left side of the iControl PC. Turn on power and use the numeric keys to enter values in selected data fields, or use the up and down arrow keys to change field values. Replace the keypad as soon as possible.

Testing Ethernet Cables

A typical Ethernet cable test device consists of two separate units: a main unit and a remote unit. Use the main unit alone to test patch cables and both units to test cables after pulling them through conduit and connecting them to the termination modules.

Patch cables: These are short network cables used within electrical panels to make connections between Fieldbus controllers or couplers and field-terminated cable runs. Patch cables are factory assembled with male RJ45 connectors at each end.

Cable runs: These are longer network cables that run through conduit to connect Fieldbus controllers or couplers to a common network interface device. Only one end of the cable has a male RJ45 connection. The other end must be field-terminated to a termination module.

Refer to *Ethernet Network Installation* in the *Installation* section for more information about Ethernet cables and installation.

Local Test - Patch Cables

1. Connect both male RJ45 connectors to the main unit.
2. Turn the unit on. A red LED will blink indicating a test in progress.
3. Watch the cable test LEDs. If all are green, then the cable is good. If one or more flash red, then the cable is faulty and must be replaced.

Remote Test - Cable Run

1. Connect one end of a previously tested patch cable into the termination module connected to the cable run. This provides you with two RJ45 male connectors on the cable run to connect to the test unit.
2. Plug the other end of the patch cable into the remote unit.
3. Plug the RJ45 male connector at the network interface end of the cable run into the main unit of the cable tester.
4. Turn the main unit on.
5. Watch the cable pair LEDs on the remote unit.
 - If all LEDs are green, then the cable run is good.
 - If one or more LEDs flash red, then either the termination module connections are miswired or incomplete, or the cable is faulty.

Make sure the cable connections to the termination module are correct. Check each connection. If you suspect a bad connection, you can pull the lead out of the module and punch it down again closer to the jacket.

If the termination module connections are good, then the cable is faulty and must be replaced.

Section 5

Repair



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



CAUTION: Do not turn off console power without first performing a program shutdown. Doing so could corrupt the iControl program and operating system on the program card. Refer to *Program Shutdown* in the *Configuration* section of the *iControl Operator Interface* manual for the shutdown procedure.



WARNING: Hazardous voltages exist within the iControl console. Unless power must be on to test circuits, always shut off and lock out power before opening the console to make repairs. All repairs should be made by a qualified electrician. Failure to observe this warning could result in personal injury or death.

Repair consists of removing malfunctioning components and replacing them with new ones. There are no components inside the cabinet that can be repaired by the customer.

Refer to the wiring diagrams in Section 7 for connections.



WARNING: Whenever replacing a component that interfaces with the exterior of the cabinet, such as a gun harness receptacle, make sure that the dust-tight integrity of the cabinet is intact by installing the correct gaskets and seals. Failure to maintain the dust-tight integrity of the cabinet could invalidate agency approvals and create a hazardous condition.

Gun Control Card Removal/Installation



WARNING: Shut off console power before removing and installing gun control cards. Failure to observe this warning could result in damage to the cards, and could result in personal injury or even death.



CAUTION: Do not turn off console power without first performing a program shutdown. Doing so could corrupt the iControl program and operating system on the program card. Refer to *Program Shutdown* in the *Configuration* section of the *iControl Operator Interface* manual for the shutdown procedure.




CAUTION: The gun control cards are electrostatic sensitive devices (ESD). To prevent damage to the cards when handling them, wear a grounding wrist strap connected to the iControl enclosure or other ground. Handle the cards only by their top and bottom edges.

See Figure 5-3. Gun control cards (2) are installed in the card cage from left to right. Each card controls two guns: the bottom receptacle on the card is the odd gun number; the top receptacle the even gun number.

To remove a card, unplug the gun harnesses from the card receptacles (3 and 4), pull down the locking tab (5), then pull the card out of the card cage.

To install a new card, slide the card into the slots in the card cage and seat the card's finger board firmly into the connector slot on the backplane (6). Push the locking tab up to lock the card into the card cage. Connect the gun harnesses to the card receptacles.



1401330A

Figure 5-3 Gun Control Card Replacement

- | | | |
|-----------------------|---------------------|----------------|
| 1. Card cage (slot 1) | 3. Gun 2 receptacle | 5. Locking tab |
| 2. Gun control card | 4. Gun 1 receptacle | 6. Backplane |

Section 6

Parts

Introduction

To order parts, call the Nordson Finishing Customer Support Center or your local Nordson representative.

Finishing Customer Support Center
Telephone: (800) 433-9319
Facsimile: (888) 229-4580
Email: finishing_csc@nordson.com

Console Part Number List

Part	Description	Note
1068999	Controller, Prodigy, iControl, 4 gun	
1078253	Controller, Prodigy, iControl, 4 gun, w/ac	
1054778	Controller, Prodigy, iControl, 6 gun	
1078254	Controller, Prodigy, iControl, 6 gun, w/ac	
1054777	Controller, Prodigy, iControl, 8 gun	
1078255	Controller, Prodigy, iControl, 8 gun, w/ac	
1054776	Controller, Prodigy, iControl, 10 gun	
1078241	Controller, Prodigy, iControl, 10 gun, w/ac	
1054775	Controller, Prodigy, iControl, 12 gun	
1078242	Controller, Prodigy, iControl, 12 gun, w/ac	
1054774	Controller, Prodigy, iControl, 14 gun	
1078243	Controller, Prodigy, iControl, 14 gun, w/ac	
1054773	Controller, Prodigy, iControl, 16 gun	
1078244	Controller, Prodigy, iControl, 16 gun, w/ac	
1054772	Controller, Prodigy, iControl, 18 gun	
1078245	Controller, Prodigy, iControl, 18 gun, w/ac	
1054771	Controller, Prodigy, iControl, 20 gun	
1078246	Controller, Prodigy, iControl, 20 gun, w/ac	
1054770	Controller, Prodigy, iControl, 22 gun	
1078247	Controller, Prodigy, iControl, 22 gun, w/ac	
1054759	Controller, Prodigy, iControl, 24 gun	
1078248	Controller, Prodigy, iControl, 24 gun, w/ac	
1054758	Controller, Prodigy, iControl, 26 gun	
1078249	Controller, Prodigy, iControl, 26 gun, w/ac	
1054757	Controller, Prodigy, iControl, 28 gun	
1078250	Controller, Prodigy, iControl, 28 gun, w/ac	
1054756	Controller, Prodigy, iControl, 30 gun	
1078251	Controller, Prodigy, iControl, 30 gun, w/ac	
1054751	Controller, Prodigy, iControl, 32 gun	
1078252	Controller, Prodigy, iControl, 32 gun, w/ac	

Console Parts

Figures 6-1 through 6-4 show the replaceable parts for the iControl console. Contact your Nordson representative or Nordson Customer Support for help in obtaining unlisted parts.

Refer to Section 7 for electrical diagrams and junction box drawings.

See Figure 6-1 for the parts listed in this table:

Item	Part	Description	Quantity	Note
1	1077555	CONTROL UNIT, PC, panel mount, w/Ethernet	1	A
2	1051544	• INTERFACE CARD, PC104 CAN	1	
3	1051545	• CARD, I/O, PC104	1	
4	1076186	• CARD, PCI Ethernet, iControl, Prodigy	1	
5	1000595	CONTACT BLOCK, 1-N.O. and 1-N.C. contact	1	
6	1000594	SWITCH, keylock, 3-position	1	
7	1032267	PANEL, keypad, iControl	1	
8	1032274	MODULE, 24-channel opto isolated	1	
9	1032390	JUMPER, comb type, 6 pole, 10 mm	AR	
NS	1055881	CABLE, CAT5 Ethernet, T568B colors, 30 ft	1	
10	1036629	ADAPTER, CompactFlash, dual	1	B
10A	1051542	CABLE, IDE, 80-conductor	1	
10B	1051543	CABLE, power supply, Compact Flash adapter	1	
11	1034281	MEMORY, CompactFlash	1	
12	1034283	MEMORY, programmed, iControl	1	
13	288806	CONTACT BLOCK, 2-N.O. contacts	1	
14	334806	SWITCH, round, 2-position, 90 degree	1	
NOTE A: For refurbished control unit, order part number 1071310.				
B: Includes adapter, mounting plate, power supply adapter cable, and power supply cable, item 11B. To replace adapter only, order 1072833.				
AR: As Required				
				<i>Continued...</i>




Figure 6-1 Console Parts (1 of 4) (PC shown without cover)

Console Parts *(contd)*

See Figure 6-2 for the parts listed in this table.

Item	Part	Description	Quantity	Note
16	1068695	CONTROL RELAY, 115VAC/DC, 250V/6A, DIN-MT	2	
17	1068696	CONTROL RELAY, 24VDC, 250V/6A, DIN-MT	1	
18	939683	FUSE, 6.30, fast-acting, 250V, 5 x 2	4	
19	939306	FUSE, 3.15, fast-acting, 250V, 5x20	2	
20	320586	RESISTOR, MF, 20K, 1W, 5 AXL	2	
21	334805	FILTER, line, RFI, power, 10A	2	

Continued...




Figure 6-2 Console Parts (2 of 4)

See Figure 6-3 for the parts listed in this table.

Item	Part	Description	Quantity	Note
22	1023939	PCA, backplane, iControl	2	
23	1023877	PCA, dual gun driver, iControl	AR	A
23A	1095361	JUMPER, gun ID, odd number	AR	B
24	185067	SUPPRESSOR, ferrite, 7 mm diameter	2	
25	334817	POWER SUPPLY, 60 watt, w/cover	2	
NS	-----	• FUSE, 3.15A, 250V	AR	
26	334803	POWER SUPPLY, 24V, 250 watt w/fan	2	
NS	-----	• FUSE, 6.3A	AR	

NOTE A: One card controls the electrostatics for 2 automatic spray guns.

B: Use to prevent fault LED from lighting when odd number of guns are connected. Plug into gun card receptacle in place of receptacle harness for unused receptacle. One jumper is shipped with each console.

AR: As Required

Continued...




Figure 6-3 Console Parts (3 of 4)

Console Parts *(contd)*

See Figure 6-4.

Item	Part	Description	Quantity	Note
27	1031501	RECEPTACLE, 8-position, gun, 70 in.	AR	A
27A	1023695	SEAL, bulkhead, 7/8-16 thread	AR	B
28	984526	NUT, lock, 1/2 in. conduit	AR	
29	939122	SEAL, conduit fitting, 1/2 in.	AR	
30	334800	PLUG, 1/2 in.	AR	

NOTE A: One receptacle is required for each automatic spray gun.

B: Use to cap unused receptacles. One seal is shipped with each console.

AR: As Required




Figure 6-4 Console Parts (4 of 4)

Junction Boxes, Extension Boxes, and Control Panels

Part	Description	Note
1035897	JUNCTION BOX, photoeye, 30 watt, iControl	A
1035899	JUNCTION BOX, photoeye extension, iControl	A
1055890	JUNCTION BOX, scanner, in/out positioner, iControl	A
1057333	INTERFACE BOX, Ethernet network, iControl	A
1055889	CONTROL PANEL, in/out positioner, iControl	A, B
-----	CONTROL PANEL, analog positioner, iControl	A, B
-----	CONTROL PANEL, in/out positioner/reciprocator, iControl	A, B
-----	CONTROL PANEL, in/out positioner, iControl (plug-in)	A, C
-----	CONTROL PANEL, in/out positioner/reciprocator, iControl (plug-in)	A, C
-----	CONTROL PANEL, top down positioner, iControl	
-----	CONTROL PANEL, bottom up positioner, iControl	
NOTE A: Refer to Section 7, Wiring and Pneumatic Diagrams, for repair parts. B: Use with Nutro-built (VO618N, VRnnRD models) positioners and reciprocators. C: Use with Nordson positioners and reciprocators.		

Ethernet Components

Part	Description	Note
1058222	CABLE, CAT 5 Ethernet, T568B colors, 100 ft	A
1058223	CABLE, CAT 5 Ethernet, T568B colors, 300 ft	A
1058224	MODULE, termination, CAT 5, T568B colors	
NOTE A: Cables have male connectors at each end. Refer to Section 3, Installation, for use.		

Conveyor Encoder

Part	Description	Note
1074261	ENCODER, 24 PPR, w/cable	

CAN Cable

Part	Description	Note
1057592	JACKETED CABLE, twisted pair, shielded, 24 AWG, 120 ohm	A
NOTE A: Order length desired in increments of one foot.		

Photocells and Scanners

Part	Description	Note
1037969	PHOTOCELL, wire goods	
131473	SENSOR, opposed mode emitter (Banner SM31E)	
131486	SENSOR, opposed mode receiver (Banner SM31R)	
170730	PHOTOCELL, retroreflective	
321158	CONTROLLER, analog, mini-array	
321159	CONTROLLER, discrete, mini-array	
321160	SENSOR, light emitter, 6 in., 3/4 in.beam spacing, 8 beam	
321161	SENSOR, light receiver, 6 in., 3/4 in.beam spacing, 8 beam	
321162	SENSOR, light emitter, 12 in., 3/4 in.beam spacing, 16 beam	
321163	SENSOR, light receiver, 12 in., 3/4 in.beam spacing, 16 beam	
321164	SENSOR, light emitter, 18 in., 3/4 in. beam spacing, 24 beam	
321165	SENSOR, light receiver, 18 in., 3/4 in. beam spacing, 24 beam	
339739	SENSOR, light emitter, 24 in., 3/4 in. beam spacing, 32 beam	
339740	SENSOR, light receiver, 24 in., 3/4 in. beam spacing, 32 beam	
339741	SENSOR, light emitter, 30 in., 3/4 in. beam spacing, 40 beam	
339742	SENSOR, light receiver, 30 in., 3/4 in. beam spacing, 40 beam	
339743	SENSOR, light emitter, 36 in., 3/4 in. beam spacing, 48 beam	
339744	SENSOR, light receiver, 36 in., 3/4 in. beam spacing, 48 beam	
339745	SENSOR, light emitter, 42 in., 3/4 in. beam spacing, 56 beam	
339746	SENSOR, light receiver, 42 in., 3/4 in. beam spacing, 56 beam	
339747	SENSOR, light emitter, 48 in., 3/4 in. beam spacing, 64 beam	
339748	SENSOR, light receiver, 48 in., 3/4 in. beam spacing, 64 beam	
339749	SENSOR, light emitter, 60 in., 3/4 in. beam spacing, 80 beam	
339750	SENSOR, light receiver, 60 in., 3/4 in. beam spacing, 80 beam	
339751	SENSOR, light emitter, 72 in., 3/4 in. beam spacing, 96 beam	
339752	SENSOR, light receiver, 72 in., 3/4 in. beam spacing, 96 beam	

Photocell and Scanner Cables

Part	Description	Note
176429	SOW cable, 18-4	
321155	CABLE, scanner, 15 ft.	
321156	CABLE, scanner, 25 ft.	
321157	CABLE, scanner, 50 ft.	
343207	CABLE, scanner rated, 15 ft.	
347230	CABLE, input, 5 wire, 6 meter, male	

Section 7

Wiring and Pneumatic Diagrams

Diagram (Drawing Number)	Sheets
System Diagram	1
iControl Console Wiring Diagram (1055199)	5
Prodigy Manual Gun Controller Junction Box (1057458)	1
Photoeye Junction Box (1035897)	3
Extension Junction Box (1035899)	1
Network Interface Box (1057333)	1
In/Out Positioner Scanner Control Panel (1058890)	2
iControl In/Out Positioner Control Panel (1058889)	5
iControl In/Out Positioner / Reciprocator Control Panel (1070103)	6
iControl In/Out Positioner Control Panel (Plug-In) (1098087) (for Nordson positioners)	6
iControl In/Out Positioner/Reciprocator Control Panel (Plug-In) (1097160) (for Nordson positioners and reciprocators)	7
iControl Top Down Positioner Control Panel (1092923)	5
iControl Bottom Up Positioner Control Panel (1092924)	5




Figure 7-1 Prodigy iControl System Diagram