

Encore® Powder Feed Center

Customer Product Manual

Document Number 1602966-10

– English –

Issued 02/25

**For parts and technical support, call the Industrial Coating
Solutions Customer Support Center at (800) 433-9319 or
contact your local Nordson representative.**

This document is subject to change without notice.
Check <http://emanuals.nordson.com> for the latest version.



Contact Us

Nordson Corporation welcomes requests for information, comments, and inquiries about its products. General information about Nordson can be found on the Internet using the following address:

<http://www.nordson.com>

<http://www.nordson.com/en/global-directory>

Notice

This is a Nordson Corporation publication which is protected by copyright. Original copyright date 2014. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Nordson Corporation. The information contained in this publication is subject to change without notice.

– Original document –

Trademarks

Encore, HDLV, Prodigy, iControl, Nordson and the Nordson logo are registered trademarks of Nordson Corporation. All other trademarks are the property of their respective owners.

Table of Contents

Safety	1-1
Introduction	1-1
Qualified Personnel	1-1
Intended Use	1-1
Regulations and Approvals	1-1
Personal Safety	1-2
Fire Safety	1-2
Grounding	1-3
Action in the Event of a Malfunction	1-3
Disposal	1-3
Description	2-1
Introduction	2-1
Components List	2-2
Standard Components	2-2
Optional Component List	2-3
Feed Center Control Panel	2-4
Lance Assemblies	2-5
Lift Assembly	2-5
Lance Lift Operation	2-7
Level Sensor Modules	2-8
Lance Mounted Level Sensor Function	2-8
Purge Manifolds	2-10
Clamping Cylinder Operation	2-10
Sieve	2-12
Pneumatic Panel Components	2-13
Control Manifold Functions	2-14
Optional HD Tube Assembly	2-15
Optional Powder Hoppers	2-16
Specifications	2-17
Size and Weight	2-17
Electrical Requirements	2-18
Air Requirements	2-18
Exhaust Air Flow	2-18
Exhaust Air Velocity	2-18
Compressed Air Supply	2-18
Air Pressures	2-19
Installation	3-1
Unpacking	3-1
Preparing for Installation	3-1
Extraction Duct Connection	3-1
Lift Cylinder Installation	3-2
Electrical Connections	3-4
External Powder Hose and Air Connections	3-4
Powder Pump Installation and Connections	3-6
Pump Installation	3-6
Pump Flow and Atomizing Air Tubing	3-6
Powder Feed Hose Connections	3-6
Hose and Tubing Counterweighting	3-6
Lance Fluidizing Air Connection	3-7
Reclaim and Virgin Powder Feed Options	3-8
Lift Cylinder Proximity Switch Adjustment	3-11
Level Sensor Position Adjustment	3-12
Damper Adjustment	3-13

Setup	4-1
Feed Center Function Settings	4-1
Changing Function Values	4-3
Level Sensor Programming	4-4
One Button Level Sensor Probe Programming	4-4
LED Functions	4-4
Empty (No Powder) Programming	4-5
Full Programming	4-5
Locking and Unlocking the Level Sensor	4-5
Operational Faults (Red LED Flashing)	4-6
Two Button Level Sensor Probe Programming	4-6
LED Functions	4-6
Empty (No Powder) Programming	4-7
Full Programming	4-7
Locking and Unlocking the Level Sensor	4-7
Operational Faults	4-7
Air Pressure Settings	4-8
Operation	5-1
Controls	5-1
Feed Center Operation	5-2
Sieve Operation	5-2
Reclaim and Virgin Pump Selector Switch Operation	5-2
Reclaim Transfer Pump Operation	5-2
Virgin Transfer Pump Operation	5-2
Transfer Pump Manual Purging	5-3
Powder Level Sensor Operation	5-3
Hopper Operation	5-3
Box Operation	5-3
Silencing the Low Powder Alarm	5-3
Startup	5-3
Color Change Operation	5-5
Color Change Procedure	5-6
Shutdown	5-6
Maintenance	6-1
Daily Maintenance	6-1
Periodic Maintenance	6-2
Troubleshooting	7-1
Troubleshooting Chart	7-1
Repair	8-1
Purge Manifold Assembly Repairs	8-1
Quad Ring Replacement	8-1
Latch Pawl Replacement	8-2
Latch Replacement	8-3
Latch Removal	8-3
Latch Installation	8-4
Latch Pawl Adjustment	8-5
Clamping Cylinder Replacement	8-6
Lift Cylinder Replacement	8-9
Lift Cylinder Removal	8-9
Lift Cylinder Installation	8-11
Cylinder Cushion Stop Adjustment	8-12
Lance Assembly/Purge Manifold Alignment	8-12
Feed Hopper Fluidizing Plate Replacement	8-15
75-lb Feed Hopper Fluidizing Plate Replacement	8-15
50-lb Feed Hopper Fluidizing Plate Replacement	8-16
Vibratory Table Motor Weight Adjustment	8-17
60Hz Motor Weight Adjustment	8-18
50Hz Motor Weight Adjustment	8-20

Parts	9-1
Introduction	9-1
Using the Illustrated Parts List	9-1
Powder Feed Center Parts	9-2
Lift Assembly Parts	9-4
Lance Assembly Parts	9-6
Basic Lance Parts	9-6
Fluidizing Latch Block Kits	9-7
Lance Port Plug Module	9-8
Level Sensor Module	9-9
Prodigy/Encore HD Siphon Tube Module	9-10
Purge Manifold and Pneumatics	9-11
Purge Manifold Assembly	9-11
Purge Valve Assembly - One Lance Configuration	9-13
Purge Valve Assembly - Two Lance Configuration	9-14
Purge Valve Assembly - Three Lance Configuration	9-15
Purge Valve Module Parts	9-16
Pneumatic Module Parts	9-17
Hopper Platform and Vibrator Parts	9-19
Pneumatic Damper Parts	9-21
Sieve and Mounting Parts	9-22
Replacement Parts for Non-CE/ATEX Sieve 1	9-22
Screens	9-22
Vibrator Motors	9-22
Miscellaneous Parts	9-22
Replacement Parts for Non-CE/ATEX Sieve 2	9-23
Screens	9-23
Vibrator Motors	9-23
Miscellaneous Parts	9-23
Powder Hose and Air Tubing Bulkhead Fittings	9-25
Other Service Parts	9-26
Powder Transfer Tubing and Grommets	9-26
Air Tubing and Fittings	9-26
Miscellaneous Parts	9-26
Fittings for Transfer Pump Air	9-26
Options	10-1
Introduction	10-1
75-lb Feed Hopper	10-2
50-lb Feed Hopper	10-3
Vibrasonic Sieve Screen	10-4
System Components	10-4
Installation	10-5
Vibrasonic Transducer and Sieve Screen Installation	10-5
Controller and Cable Installation	10-5
Operation	10-6
Troubleshooting	10-6
Fault Conditions	10-6
Electrical Troubleshooting Procedures	10-7
VIBRASONICS/POWER Indicator Troubleshooting	10-8
Vibrasonic System Parts	10-9
Pneumatic and Electrical Diagrams	11-1

Change Record

[illegible]

Section 1

Safety

Introduction

Read and follow these safety instructions. Task- and equipment-specific warnings, cautions, and instructions are included in equipment documentation where appropriate.

Make sure all equipment documentation, including these instructions, is accessible to persons operating or servicing equipment.

Qualified Personnel

Equipment owners are responsible for making sure that Nordson equipment is installed, operated, and serviced by qualified personnel. Qualified personnel are those employees or contractors who are trained to safely perform their assigned tasks. They are familiar with all relevant safety rules and regulations and are physically capable of performing their assigned tasks.

Intended Use

Use of Nordson equipment in ways other than those described in the documentation supplied with the equipment may result in injury to persons or damage to property.

Some examples of unintended use of equipment include:

- using incompatible materials
- making unauthorized modifications
- removing or bypassing safety guards or interlocks
- using incompatible or damaged parts
- using unapproved auxiliary equipment
- operating equipment in excess of maximum ratings

Regulations and Approvals

Make sure all equipment is rated and approved for the environment in which it is used. Any approvals obtained for Nordson equipment will be voided if instructions for installation, operation, and service are not followed.

All phases of equipment installation must comply with all federal, state, and local codes.

Personal Safety

To prevent injury follow these instructions.

- Do not operate or service equipment unless you are qualified.
- Do not operate equipment unless safety guards, doors, or covers are intact and automatic interlocks are operating properly. Do not bypass or disarm any safety devices.
- Keep clear of moving equipment. Before adjusting or servicing any moving equipment, shut off the power supply and wait until the equipment comes to a complete stop. Lock out power and secure the equipment to prevent unexpected movement.
- Relieve (bleed off) hydraulic and pneumatic pressure before adjusting or servicing pressurized systems or components. Disconnect, lock out, and tag switches before servicing electrical equipment.
- Obtain and read Material Safety Data Sheets (SDS) for all materials used. Follow the manufacturer's instructions for safe handling and use of materials, and use recommended personal protection devices.
- To prevent injury, be aware of less-obvious dangers in the workplace that often cannot be completely eliminated, such as hot surfaces, sharp edges, energized electrical circuits, and moving parts that cannot be enclosed or otherwise guarded for practical reasons.

Fire Safety

To avoid a fire or explosion, follow these instructions.

- Ground all conductive equipment. Use only grounded air and fluid hoses. Check equipment and workpiece grounding devices regularly. Resistance to ground must not exceed one megohm.
- Shut down all equipment immediately if you notice static sparking or arcing. Do not restart the equipment until the cause has been identified and corrected.
- Do not smoke, weld, grind, or use open flames where flammable materials are being used or stored. Do not heat materials to temperatures above those recommended by the manufacturer. Make sure heat monitoring and limiting devices are working properly.
- Provide adequate ventilation to prevent dangerous concentrations of volatile particles or vapors. Refer to local codes or your material SDS for guidance.
- Do not disconnect live electrical circuits when working with flammable materials. Shut off power at a disconnect switch first to prevent sparking.
- Know where emergency stop buttons, shutoff valves, and fire extinguishers are located. If a fire starts in a spray booth, immediately shut off the spray system and exhaust fans.
- Shut off electrostatic power and ground the charging system before adjusting, cleaning, or repairing electrostatic equipment.
- Clean, maintain, test, and repair equipment according to the instructions in your equipment documentation.
- Use only replacement parts that are designed for use with original equipment. Contact your Nordson representative for parts information and advice.

Grounding



WARNING: Operating faulty electrostatic equipment is hazardous and can cause electrocution, fire, or explosion. Make resistance checks part of your periodic maintenance program. If you receive even a slight electrical shock or notice static sparking or arcing, shut down all electrical or electrostatic equipment immediately. Do not restart the equipment until the problem has been identified and corrected.

Grounding inside and around the booth openings must comply with NFPA requirements for Class II, Division 1 or 2 Hazardous Locations. Refer to NFPA 33, NFPA 70 (NEC articles 500, 502, and 516), and NFPA 77, latest conditions.

- All electrically conductive objects in the spray areas shall be electrically connected to ground with a resistance of not more than 1 megohm as measured with an instrument that applies at least 500 volts to the circuit being evaluated.
- Equipment to be grounded includes, but is not limited to, the floor of the spray area, operator platforms, hoppers, photoeye supports, and blow-off nozzles. Personnel working in the spray area must be grounded.
- There is a possible ignition potential from the charged human body. Personnel standing on a painted surface, such as an operator platform, or wearing non-conductive shoes, are not grounded. Personnel must wear shoes with conductive soles or use a ground strap to maintain a connection to ground when working with or around electrostatic equipment.
- Operators must maintain skin-to-handle contact between their hand and the gun handle to prevent shocks while operating manual electrostatic spray guns. If gloves must be worn, cut away the palm or fingers, wear electrically conductive gloves, or wear a grounding strap connected to the gun handle or other true earth ground.
- Shut off electrostatic power supplies and ground gun electrodes before making adjustments or cleaning powder spray guns.
- Connect all disconnected equipment, ground cables, and wires after servicing equipment.

Action in the Event of a Malfunction

If a system or any equipment in a system malfunctions, shut off the system immediately and perform the following steps:

- Disconnect and lock out system electrical power. Close hydraulic and pneumatic shutoff valves and relieve pressures.
- Identify the reason for the malfunction and correct it before restarting the system.

Disposal

Dispose of equipment and materials used in operation and servicing according to local codes.

Section 2

Description

Introduction

The Encore™ powder feed center conditions and supplies powder for up to 27 Venturi pumps. It contains a sieve, hopper table, lance and lift assembly, Venturi-type in-line powder pumps, level sensors, purge manifold, and electrical and pneumatic controls.

The feed center provides quick color changes and automatic purge cleaning. Powder is drawn from a box or fluidized hopper powder source by the lance-mounted, in-line powder pumps. The powder is then delivered through feed hoses to the spray guns. The feed center can be equipped with up to 27 Venturi pumps, and is furnished with a vibratory table to aid in the fluidization of powder in boxes.

The feed center controls are designed to accommodate one to two HDLV reclaim pumps to transport over-sprayed powder from the powder recovery system to the feed center, and an optional HDLV® virgin pump to transport virgin powder to the system as needed.




Figure 2-1 Encore Feed Center (Typical)

Introduction (contd)

Both HDLV transfer pumps deliver the powder to the vibratory sieve, where it is conditioned before delivery to the powder spray guns. Ultrasonic sieve screens are available as an option.

The color change operation is partially automatic. At the start of a color change, the lances are raised out of the powder source so it can be removed from the feed center. Then, when the operator initiates the gun purge, the lances are automatically lowered onto a purge manifold assembly and clamped in place. High-pressure purge air is then pulsed through the lances, in-line powder feed pumps, hoses, and guns to clean them of powder. The reclaim and virgin HDLV transfer pumps are purged manually when the operator is ready.

The Encore Powder Feed Center requires a remote air extraction system that provides a constant airflow through the feed center enclosure, preventing powder from escaping into the spray room. The typical ColorMax® 2 extraction system includes an afterfilter assembly consisting of an exhaust fan, primary cartridge filters, pulse valves and controls, and final filters, plus the ductwork to connect the afterfilter to the booth cyclone and feed center. Afterfilters are available in 9000, 11250, and 15750 CFM capacities.

A 10 inch duct with a transition section and a pneumatically-operated damper is provided with the feed center.

Components List

Standard Components

See Figure 2-1. The feed center consists of the following components:

- Enclosure
- Control cabinet for pneumatic and electrical controls
- Flush mount lighting
- Lance lift assembly with locking lift cylinder
- 1–3 lance assemblies, each holding 1–9 in-line pumps (27 pumps total)
- Lance-mounted fluidizing bars for use with powder boxes
- Lance-mounted level sensors for feed hopper and box
- Lance-mounted suction tube holders for Prodigy® or Encore® manual guns
- High pressure purge manifolds, one per lance, with air cylinder clamping mechanism
- Square or rectangular fluidized feed hoppers
- Vibratory table for powder boxes
- Vibratory sieve

Optional Component List

Optional components include:

- Ultrasonic sieve screens
- HDLV virgin powder bulk feed system




Figure 2-2 Major Components (Typical)

- | | | |
|--------------------|--------------------|----------------------------------|
| 1. Enclosure | 6. Lift cylinder | 11. Vibratory table |
| 2. Sieve | 7. Lift assembly | 12. Blow-off gun |
| 3. Damper assembly | 8. Lance assembly | 13. Fluidizing air regulators |
| 4. Pneumatic panel | 9. Level sensor | 14. Purge ports – transfer hoses |
| 5. Control panel | 10. Purge manifold | |

NOTE: Refer to the *Operation* section for a description of the feed center controls.

Feed Center Control Panel




Figure 2-3 Control Panel Functions

Table 2-1 Feed Center Controls

Item	Description	Part	Description
1	Damper Selection Left: Manual Mode (open for high flow) Right: Auto Mode (damper is set to low flow until a color change is started. Then the damper is automatically opened for high flow.)	7	Vibratory Table Motor Control Left: Off Right: On
2	Bulk Feed Pump Control Left: Off Right: On	8	Purge Selection Left: Internal Gun Purge Center: Off Right: Pump Purge
3	Reclaim Pump Control Left: Off Right: On	9	Lance Position Control Left: Down Center: Neutral (stop) Right: Up
4	Sieve Control Left: Off Right: On	10	Powder Source Selection Left: Hopper Right: Box
5	Color Change Enable Left: Off Right: On	11	Color Change Indicator (Green) Off: Disable Blinking: In cycle On: Complete
6	Emergency Stop Pressed In: Stop Rotate and Pull Out: Start		

Lance Assemblies

One, two, or three lance assemblies are attached to the lift assembly. Up to nine in-line powder pumps can be mounted on each lance assembly. The pumps are installed in the lance ports, and held into place with a retaining rod. If a lance pump port is not used, it is plugged with a plug module.




Figure 2-4 Lance Assembly

1. Fluidizing latch block assembly 2. Fluidizing bars

Lift Assembly

The lift assembly uses a locking air cylinder to raise and lower the lance assemblies in and out of the feed hoppers or powder boxes:

- If a feed hopper is selected as the powder source, the lance is lowered until it is a set distance above the fluidizing plate, as determined by the position of a proximity sensor on the lift cylinder.
- If a powder box is selected, the lance is lowered until the level sensor on the lance contacts the powder, and then lowered gradually as the powder is used.

The cylinder motion and locking action are controlled by three solenoid valves that are part of the control manifold on the roof of the feed center.

The lift cylinder has a spring-actuated locking mechanism released by air pressure. The cylinder is locked when the air line is vented; unlocked when pressurized. The cylinder also uses a balancing air circuit, which applies air pressure to both sides of the piston to prevent lurching when restarting motion after a locked stop.

Lift Assembly (contd)

When the cylinder moves the lance up, the lance down circuit is vented, allowing the lance up circuit air to push the piston up. When the cylinder moves the lance down, the lance up circuit is vented, allowing the lance down circuit air to push the piston down.

The flow control valves installed in the cylinder air ports control the travel speed of the piston rod. Three proximity sensors mounted on the cylinder sense when the cylinder piston is in the hopper, box empty, or purge positions.




Figure 2-5 Lance Lift Assembly

- | | | |
|------------------------|---------------------------|-------------------|
| 1. Flow control valves | 4. Locking mechanism | 7. Carriage stop |
| 2. Proximity | 5. Support block | 8. Linear V-guide |
| 3. Lift Cylinder | 6. Lift plate with wheels | |

Lance Lift Operation

See Figure 2-5.

Static State

- Lance lock solenoid valve non-energized, air line to lock vented, cylinder rod locked by spring force.
- Lance down and lance up solenoid valves non-energized, air lines to up and down flow control valves pressurized, lance up and lance down regulators supplying balanced pressure to both sides of the lift cylinder piston.

Dynamic State UP

- Lance lock solenoid valve energized, lock air line pressurized, cylinder rod unlocked.
- Lance up solenoid valve energized, venting line to lance down regulator and top of piston. Pressure to lance up regulator and bottom of piston forces piston up.

Dynamic State DOWN

- Lance lock solenoid valve energized, lock air line pressurized, cylinder rod unlocked.
- Lance down solenoid valve energized, venting line to lance up regulator and bottom of piston. Pressure to lance down regulator and top of piston forces piston down.

Level Sensor Modules

Lance Mounted Level Sensor Function

When the powder source switch is set to **Hopper**, the lance is lowered down into the powder in the hopper to the position determined by the hopper proximity switch on the lift cylinder. The hopper level sensor is positioned to maintain the desired level of powder in the hopper, turning on and off the virgin transfer pump as the powder level rises and falls. If the level sensor detects a low powder condition for greater than 3 minutes (field adjustable), the low powder alarm is turned on.

When the powder source switch is set to **Box**, the lance is lowered until the box level sensor contacts the powder. When the powder level falls below the level sensor, the lance is lowered further into the box. The box proximity sensor on the lift cylinder prevents the lance from crashing into the bottom of the box.

To adjust the position of each level sensor for the application, loosen the clamp screw (4) with a hex key.




Figure 2-6 Level Sensor Modules

- | | |
|-----------------|----------------|
| 1. Level sensor | 3. Clamp |
| 2. Bracket | 4. Clamp screw |

Purge Manifolds

During a color change procedure, the purge manifolds blow powder out of the lances, in-line pumps, powder feed hoses, and spray guns. When the operator activates the gun purge mode during a color change procedure, the lance assemblies are lowered onto the purge manifolds (7). The latch cylinder (3) is extended, causing the latches (5) to clamp the lances to the purge manifolds. Compressed air is then pulsed through the lances, in-line pumps, feed hoses, and spray guns, one manifold at a time. The purge sequence is controlled by the feed center PLC. Air is supplied by the purge valves mounted on the back of the feed center.

The latch assemblies can be adjusted to change the clamping force exerted on the lance assemblies, depending on the purge air pressure. Refer to the Repair Section page 8-1 for adjustment procedures.

Clamping Cylinder Operation

Extend (Clamp): The air line to the regulator and extend flow control valve (4) at the fixed end of the cylinder is pressurized with regulated air, forcing the cylinder piston and rod out of the cylinder. The retract air line is vented.

Retract (Unclamp): The air line to the retract flow control valve (1) at the rod end of the cylinder is pressurized with line air pressure, forcing the cylinder piston and rod into the cylinder. The extend air line is vented.




Figure 2-7 Purge Manifold Assembly (3 lance assembly shown with cylinder and latches in clamping position)

- | | | |
|-------------------------------|------------------------------|-------------------|
| 1. Retract flow control valve | 4. Extend flow control valve | 7. Purge Manifold |
| 2. Piston proximity | 5. Latches | |
| 3. Latch cylinder | 6. Lance guides | |

Sieve

The vibratory sieve is mounted onto a bracket assembly (5).

The deck (3), screen (10), and screen gasket (11) are clamped to the pan by two latches (6). Screens are available in different mesh (micron) sizes. When the latches are released, the sieve pan can be rotated so that the discharge chute (8) deposits the screened powder into the powder source, or when purging, so the chute is pointing toward the exhaust duct intake.

For hard-to-screen powders, a Vibrasonic system with an ultrasonic screen is available. Refer to Operation for more information.




Figure 2-8 Level Sensor Modules

- | | | |
|-----------------------|------------------------------|-------------------|
| 1. Deck plug | 5. Mounting bracket assembly | 9. Sieve ring |
| 2. Powder inlet stubs | 6. Deck latches | 10. Sieve screen |
| 3. Sieve deck | 7. Vibration isolators | 11. Screen gasket |
| 4. Vibrator motor | 8. Sieve pan discharge chute | 12. Ground clip |

Pneumatic Panel Components

Refer to Figure 2-10 for an explanation of the 9-station control manifold functions. Refer to Figure 11-1 for the feed center pneumatic diagram.




Figure 2-9 Pneumatic Components

- | | | |
|------------------------------|--------------------------------|---------------------|
| 1. Purge air regulator/gauge | 4. Lance UP regulator/gauge | 7. Control manifold |
| 2. Air manifold | 5. Lance DOWN regulator/gauge | |
| 3. Interlock valve | 6. Purge clamp regulator/gauge | |

NOTE: Refer to Setup, and Operation, for air pressure and control settings and usage.

Control Manifold Functions

The control manifold controls most of the pneumatic equipment in the feed center. It is connected to the feed center control panel by a single cable.




Figure 2-10 Control Manifold Functions

Valve No.	Solenoid Designation	Function
1	SOL 325/0	Lance Up (vented when energized, allowing Lance Up)
2	SOL 325/1	Lance Down (vented when energized, allowing Lance Down)
3	SOL 326	Lance Lock (energized to unlock cylinder, vented to lock cylinder)
4	SOL 331	Purge Clamp (extend/retract)
5	SOL 342	HDLV Virgin Pump Purge
6	SOL 338	HDLV Virgin Pump On
7	SOL 340	HDLV Reclaim Pump Purge
8	SOL 336	HDLV Reclaim Pump On
9	SOL 329	Damper (open/closed)

Optional HD Tube Assembly

The optional Prodigy/ Encore HD siphon tube provides powder to a Prodigy or Encore HD manual gun. The siphon tube bracket (3) is secured to the lance arm with the existing lance fasteners. The quick-disconnect fitting on the top of the siphon tube (1) accommodates 8-mm tubing.

NOTE: This option can only be used with fluidized hoppers




Figure 2-11 Siphon Tube Assembly (Optional)

1. Siphon tube

2. Spring clips

3. Bracket

Optional Powder Hoppers

The feed center can accommodate rectangular 75-lb (34 kg) and square 50-lb (22.7 kg) fluidizing hoppers and different sizes of powder boxes.

The fluidizing hoppers are equipped with replaceable fluidizing plates and 10-mm tube fittings in the plenum. An optional cart is available for the 75-lb hopper.

Refer to the Options section of this manual for the square and rectangular hopper part numbers and repair parts.

NOTE: This option can only be used with fluidized hoppers




Figure 2-12 Optional Fluidizing Feed Hoppers

Specifications

Size and Weight




Figure 2-13 Feed Center Dimensions

Electrical Requirements

200V, 3 phase, 50 Hz, 6.6 amps
 200V, 3 phase, 60 Hz, 6.6 amps
 230V, 3 phase, 60 Hz, 6.1 amps
 380V, 3 phase, 50 Hz, 3.6 amps
 380V, 3 phase, 60 Hz, 3.6 amps
 415V, 3 phase, 50 Hz, 3.5 amps
 460V, 3 phase, 60 Hz, 3.5 amps
 575V, 3 phase, 60 Hz, 2.5 amps

Air Requirements

Exhaust Air Flow

Mode	Function
Color change mode	3058 - 3228m ³ /hr (1800 - 1900 CMF)
Paint mode	3039 - 2209m ³ /hr (1200 - 1300 CMF)

Exhaust Air Velocity

CFM	Duct Size	Air Flow Velocity
1200	10 in.	2201 ft/minute
1300	10 in.	2385 ft/minute
1800	10 in.	3202 ft/minute
1900	10 in.	3485 ft/minute

Compressed Air Supply

Air input: 1 in. BSPT with NPT adapter

Air consumption at 6.9 bar (100 psi):

- 76 m³/hr (45 SCFM) – Normal operation
- [611 m³/hr (360 SCFM) – Maximum (instantaneous flow rate during purge sequence)]

The air must be clean and dry. Use a dedicated, refrigerated or regenerative-desiccant air dryer that can produce a 3 °C (38 °F) or lower dewpoint at 6.9 bar (100 psi), and filter/separators with automatic drains.

Air Pressures

Function	Recommended Pressures
Lift Cylinder Up	1 Lance: 4.1 bar (60 psi) 2 Lances: 4.8 bar (70 psi) 3 Lances: 5.5 bar (80 psi)
Lift Cylinder Down	3.4 bar (50 psi)
Lift Cylinder Flow Control Valves	6 seconds full travel both directions
Purge Air	6.2 bar (90 psi)
Lance Purge Clamp Cylinder	3.4–4.1 bar (50–60 psi)
Clamp Cylinder Flow Control Valves	3 seconds full travel both directions
Feed Hopper Fluidizing	0.3–0.7 bar (5–10 psi) (see Note)
Lance Fluidizing	0.3–0.7 bar (5–10 psi) (see Note)
NOTE: Adjust fluidizing air as needed. Powder should be gently boiling, without geysering	

Compressed Air Supply

Available Sieve Screens

381 mm (15 inch) Sieve:

864 Micron, 20 mesh without ultrasonics

381 Micron, 40 mesh without ultrasonics

234 Micron, 60 mesh, without ultrasonics

178 Micron, 80 mesh with ultrasonics

140 Micron, 100 mesh with ultrasonics

Section 3

Installation



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

NOTE: The feed center is typically shipped by truck or in a container. All internal air and electrical connections are made at the factory. If it is included as part of a ColorMax Engineered System with an integral utility deck, all air and electrical connections to the components on the deck are also complete. Refer to your system drawings for final connections.

Unpacking

Upon receipt, unpack the feed center carefully to avoid damage. Report any damage immediately to the shipper and to your Nordson representative. Save packing materials for possible later use, or dispose of properly according to local regulations.

Preparing for Installation

Position the feed center on a level floor, or the booth utility deck, according to the system layout drawing supplied by Nordson application engineering.

To ensure easy maintenance, provide a clear operating and access zone of at least 1m (3ft) wherever possible.

Extraction Duct Connection

Connect ductwork from the afterfilter/fan section to the 10 in. diameter vertical duct at the back of the feed center.

Lift Cylinder Installation

See Figure 3-1. The lift cylinder may be removed for shipping. Follow this procedure to install it if necessary.

1. Remove the lift cylinder packaging and inspect it for damage. Three proximity switches should be installed in the grooves along the cylinder body.
2. Unsnap the clevis pin clip from the clevis and remove the pin.
3. Remove the four M8 x 75 screws from the bottom of each side of the bearing block and lift off the bearing caps.
4. Remove the bearings from the bearing caps. Install the bearings on the cylinder trunnions, with the bearing flanges toward the cylinder.
5. Install the cylinder through the square opening in the roof of the feed center, then carefully guide the bearings into the bearing block.
6. Install the bearing caps on top of the bearings, and secure the caps with the four M8 x 75 screws.
7. Connect the clevis to the lance carriage with the clevis pin and snap the pin clip around the clevis.
8. Connect air tubing to the cylinder:
 - 6-mm tubing from the down regulator to the upper flow control valve.
 - 6-mm tubing from the up regulator to the lower flow control valve.
 - 6-mm tubing from solenoid #3 SOL326 to the cylinder lock.
9. If removed, install the proximity switches on the cylinder as shown.
 - LS306: Hopper position
 - LS307: Box position
 - LS308: Purge position
10. When the feed center installation is complete, adjust the proximity switch positions as described in *Lift Cylinder Proximity Switch Adjustment*.




Figure 3-1 Lift Cylinder Installation

Electrical Connections

CAUTION: Equipment damage may occur if the electrical panel is connected to any line voltage other than that stated on the identification plate.

WARNING: Power to the feed center must be supplied from a locking disconnect switch or breaker. Failure to observe this warning may result in a severe shock during installation or repair.

Make sure that all customer-supplied electrical cables are correctly rated and suitable for the ambient temperature of the installation area. Provide adequate fuse/circuit protection from the power supply. Refer to the wiring diagrams and system drawings supplied by Nordson application engineering for more information.

See Figure 3-2. The feed center is shipped with cables for power, E-stop, and control connections to the main system electrical panel. If the feed center is shipped mounted on a utility deck, all electrical connections to the main system electrical panel are made at the factory. If the feed center is shipped separately for floor installation, refer to your system wiring diagrams for connection information. The wiring diagrams for the feed center control panel are included at the back of this manual.

Before starting the feed center, turn on the feed center power and refer to the Setup procedures to program the controls for the application. This should be performed only by a Nordson field engineer, or a qualified customer controls engineer.

External Powder Hose and Air Connections

Air Connection: NPT (National Pipe Thread)

The feed center is supplied with a 1-in. NPT female adapter located at the main supply air valve. Leave this adapter in place if you are using NPT fittings to connect to your main air supply.

Air Connection: ISO 7/1 Rc1 (BSPT 1 inch)

Remove the 1-in. NPT adapter from the main supply air valve if you are using ISO7/1 Rc1 fittings to connect to your main air supply.

Clean, dry, compressed air should be supplied from a refrigerated or desiccant air dryer and filter/separators. Refer to Specifications for compressed air specifications.

Refer to the pneumatic diagram on the 11 x 17 foldouts at the end of this manual for more information.

Pump Flow and Atomizing Air Connections: Route 8-mm black (flow) and blue (atomizing) air tubing from the iControl control console to the air manifolds on the back of the feed center. Refer to your system drawings for the correct connections.




Figure 3-2 Electrical and Pneumatic Connections to Feed Center

Powder Pump Installation and Connections

Pump Installation

See Figure 3-3 and Figure 3-4. Typically, the pumps are installed at the factory. If not, install the powder pumps into the lance ports, with all the pump air fittings pointing in the same direction. Install the retaining rods into the brackets to lock the pumps in place. The pump connections are application specific; refer to your system drawings for the correct connections.

Pump Flow and Atomizing Air Tubing

See Figure 3-3 and Figure 3-4. If the pumps are installed at the factory, the flow (black) and atomizing (blue) air tubing is also installed from the pumps to the air manifolds on the back wall of the feed center. If not, the pumps are numbered and the tubing must be connected from the pumps to the appropriate fittings in the air manifolds on the back wall of the feed center.

Powder Feed Hose Connections

See Figure 3-3 and Figure 3-4. Label and route the powder feed hoses (5) from the spray guns through the multi-tube PVC grommets (7) on the back wall of the feed center and connect the hoses to the appropriate pump outlet fittings (1). Refer to your system drawings for the correct connections.

Hose and Tubing Counterweighting

See Figure 3-4. Allow enough slack in the hoses (5) and air tubing (3, 4) to allow the lance assembly to travel through its full range of movement without stretching or kinking the hoses or tubing. Bundle the hoses and tubing with the provided Velcro straps (10) to prevent kinking or damage, then attach the strap to the counterweight assembly (6).

The counterweight assembly is shipped with six weights. Use two weights for each lance assembly.



Figure 3-3 Pump, Air Tubing, and Powder Feed Hose Installation

Lance Fluidizing Air Connection

See Figure 3-4. If not done, connect 6-mm blue air tubing (9) from the fluidizing air regulator on the side wall of the feed center through the multi-tube connector and connect the tubing to the fitting on the lance, as shown.




Figure 3-4 Pump, Powder Feed Hose, and Air Tubing connections to Lance Assembly

- | | | |
|---------------------------------|-----------------------------|-------------------|
| 1. Pumps | 5. Power feed hose | 9. Fluidizing air |
| 2. Retaining Rod | 6. Counterweight assembly | 10. Velcro strap |
| 3. Flow-rate air tubing (black) | 7. Powder hose grommet | |
| 4. Atomizing air tubing (blue) | 8. Air multi-tube connector | |

Reclaim and Virgin Powder Feed Options

Bulk feed systems are optional. Most systems will use at least one HDLV reclaim pump. Dual reclaim systems are often specified for coating wire goods or for use with high gun counts.

Figure 3-5 and Figure 3-6 illustrate typical connections and equipment required for reclaim and virgin powder feed systems. Refer to your system drawings for additional information and installation information.

Reclaim Powder Systems: The pump panel and HDLV transfer pump are mounted on the cyclone stand. The purge valve is plumbed into an air drop and the shuttle valve is mounted next to the purge valve. When the operator turns on the reclaim pump, air flows from a solenoid-operated valve through 8-mm tubing to the pump operating air regulator. 6-mm tubing supplies regulated air to the transfer pan fluidizing air regulator and line pressure to the manual purge pushbutton valve. This valve allows the operator to purge the reclaim pump as needed.

During a color change cycle, the operator disconnects the reclaim transfer hose from the sieve deck and connects it to one of the purge ports on the side of the feed center. The operator then turns the purge switch to the Pump Purge position. A signal from the feed center opens a solenoid valve in the control manifold, sending pilot air to the reclaim pump purge valve.

The valve opens and allows air at line pressure to flow through the pump and the 16-mm suction and delivery powder tubing to clean them. The purged powder is dumped into the feed center exhaust duct to the afterfilter.

Virgin Powder Feed System: A typical bulk feed system includes a HDLV transfer pump and pump panel as well a process valve to control system operation. The process valve is connected directly to the main air manifold on the feed center.

When a hopper is selected as the powder source and the lance level sensor tells the system that the powder level is low, pilot air flows from the control manifold through 6-mm tubing to the process valve, which opens and supplies air at line pressure to the virgin powder system and turns on the pump. Powder is pumped out of the bulk powder container to the feed center hopper. The pump panel has regulators to control air pressure to the pump and air pressure to an auxiliary function, such as a vibrator motor.

During a color change cycle, the operator disconnects the virgin transfer hose and suction hose from the sieve deck and connects it to one of the purge ports on the side of the feed center. The operator then turn the purge switch to the Pump Purge position. A signal from the feed center opens a solenoid valve in the control manifold, sending pilot air through 6-mm tubing to the virgin pump purge valve. The valve opens and allows air at line pressure to flow through the pump and the 16-mm suction and delivery powder tubing to clean them. The purged powder is dumped into the feed center exhaust duct to the afterfilter.




Figure 3-6 Dual Reclaim Pump Connections and Equipment

Lift Cylinder Proximity Switch Adjustment

There are three proximity switches on the lift cylinder. They sense the position of the cylinder piston, and therefore the bottom of the lance, in relation to the hopper fluidizing plate, the bottom of a powder box, and the purge manifold. Each switch has an LED that turns on when the switch is closed through the use of a magnet embedded in the cylinder piston.




Figure 3-7 Proximity Switches and Settings (Typical Lift Cylinder Shown)

NOTE: The lance assembly will stop at the Box or Hopper switch, depending on the powder source selected. To override the switch, continue to hold the Lance Control switch in the down position for 3 seconds after it stops.

LS308 Purge Switch (Bottom Switch): Lower the lance down onto the stop bolt. Slide the switch up and down while watching the LED. Mark the positions at which the switch LED turns on in both directions, then secure the switch midway between the on positions.

LS307 Box Switch (Middle Switch): Position an empty powder box on the table. Lower the lance assembly down until it is at the recommended height above the bottom of the box. Slide the switch up or down until the switch LED turns on. Mark the positions at which the switch LED turns on in both directions, then secure the switch midway between the on positions.

LS306 Hopper Switch (Top Switch): Position an empty hopper on the table. Lower the lance assembly down until it is at the recommended height above the fluidizing plate. Slide the switch up or down until the switch LED turns on. Mark the positions at which the switch LED turns on in both directions, then secure the switch midway between the on positions.

Level Sensor Position Adjustment

Adjust the level sensor position by loosening the clamp screw with a hex wrench and sliding the sensor up and down.

Hopper Level Sensor: Adjust the level sensor so that when the lance proximity sensor stops the lance, the bottom of the level sensor is at the position where you want the virgin transfer pump delay to start. This position must take into account both the delay time and the usage rate, since the powder level will continue to fall until the delay timer runs out and the virgin pump is turned on.

Box Level Sensor: Adjust the level sensor so that the fluidizing bars and lance are submerged in the powder when the level sensor contacts it. Each time the powder level falls below the level sensor, the lance will be moved down until the sensor is again in contact with the powder. The box proximity sensor stops the lance before it contacts the bottom of the box.





Figure 3-8 Level Sensor Position Adjustments

- | | | |
|---------------------------------|---------------------------------------|------------------------------|
| 1. Clamp Screw | 4. Powder used during delay | 7. Total lance travel length |
| 2. Hopper proximity switch stop | 5. Delay runs out, virgin pump starts | 8. Box proximity switch stop |
| 3. Low powder delay start | 6. Box level sensor stop | |


Damper Adjustment

The two-position damper is used to adjust the air flow that is drawn through the feed center extraction duct.

See Figure 3-9. When the damper selector switch is set to the automatic position, the damper will automatically move to the high flow setting during color change mode, and to the low flow setting during paint mode. When the selector switch is set to the manual position, the damper will move to the high flow position and remain there until the selector is moved back to the automatic position.



Damper Selection - Manual Position



Damper Selection - Automatic Position

Figure 3-9 Damper Selection Switch Settings

The feed center air flow settings must be adjusted in the field during system installation due to variations in system duct length and geometry. Use a hot wire-type anemometer to adjust the damper settings. A reading should be taken in the longest straight section of the 10 in. ductwork in order to obtain the least influence from air turbulence.

NOTE: A qualified technician with experience in accurate duct flow measurement techniques should perform this task.

See Table 3-2 for exhaust air flow settings.

Table 3-2 Exhaust Air Flow Settings

Mode	Air Flow Range
Color change mode	3058 - 3228 m ³ /hr (1800 - 1900 CFM)
Paint mode	2039 - 2209 m ³ /hr (1200 - 1300 CFM)

See Figure 3-10. The damper is equipped with adjustable stops for high and low flow settings (3, 4). These stops limit the movement of the crank arm that is attached to the butterfly valve.

The crank arm is set at the factory to allow the butterfly valve to move from completely closed to approximately half-way open. Depending on the system ductwork, this may need to be adjusted to achieve the desired flow range.

Damper Adjustment (contd)

The crank arm can be moved in relation to the butterfly valve. To do this, loosen the crank arm set screw (1), adjust for the new position, and

re-tighten the set screw. An indicator mark inscribed on the end of the butterfly valve shaft indicates the butterfly valve position (2).

NOTE: All crank arm adjustments must be done with the afterfilter fan in the OFF position.

Figure 3-10 shows the damper in the factory-set low flow, or closed, position. The butterfly valve position is indicated by the indicator mark (2), which is shown in a horizontal position.




Figure 3-10 Damper Setting, Factory-Set Low Flow Position

- | | |
|---------------------------------------|------------------------------|
| 1. Crank arm set screw | 3. High flow adjustable stop |
| 2. Butterfly valve position indicator | 4. Low flow adjustable stop |

Figure 3-11 shows the damper in the factory-set high flow position. The damper can be seen approximately half-way open, and the butterfly valve position indicator mirrors the angle of the damper, showing that it is open.



Figure 3-11 Damper Setting, Factory-Set High Flow Position

Figure 3-12 shows the damper in an adjusted low flow position, which has been set slightly higher than the factory setting. The crank arm has been adjusted in relation to the butterfly, which is noted by the indicator line being at an angle similar to the new damper position.



Figure 3-12 Damper Setting, Adjusted Low Flow Position

Figure 3-13 shows the damper in an adjusted high flow position. Note that the indicator is now almost vertical, as is the new damper position.



Figure 3-13 Damper Setting, Adjusted High Flow Position

Section 4

Setup






WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Feed Center Function Settings

The feed center functions are controlled by a PLC inside the feed center control panel, on the front of the feed center. The following function values are programmed into the controller at the factory and can be adjusted as needed for the application.

Problem	Possible Cause	Corrective Action	Default
	SCREEN 1 Welcome Screen	Displays current version and date	
	SCREEN 2 Virgin Powder Transfer Delay	Sets the time to wait after the powder level falls below the level sensor before turning on the virgin transfer pump. The virgin pump and sieve must be on. This delay prevents frequent pump starts and stops (chattering).	40.00 seconds
	SCREEN 3 Low Powder Alarm Delay	Sets the time to wait after the powder level in the feed hopper falls below the level sensor before turning on the alarm buzzer. The virgin transfer pump must be on. If powder is detected before the timer runs out, the timer is canceled. The buzzer can be silenced by switching Gun Purge on momentarily.	3.00 minutes

Problem	Possible Cause	Corrective Action	Default
	SCREEN 4 HDLV Pump Purge Pulse Cycle Rate	Sets the on/off cycle rate for the reclaim and virgin HDLV transfer pump purge cycle. The purge cycle is active while the pump purge duration timer is running.	0.25 seconds
	SCREEN 5 HDLV Pump Purge Duration	Sets the duration for the reclaim and virgin HDLV transfer pump purge cycle. The purge cycle stops when the duration timer runs out.	45.00 seconds
	SCREEN 6 - Gun Purge Pulse "ON" Duration - Gun Purge Pulse "OFF" Duration - Gun Purge Duration Per Bank	- Sets the pulse duration of the internal gun purge during the gun purge cycle. The cycle is active while the gun purge duration timer is running. - Sets the duration of the delay between internal gun purge pulses during the gun purge cycle. The cycle is active while the gun purge duration timer is running. - Sets the duration for the purge cycle for each purge bank. The purge cycle stops when the duration timer runs out.	0.50 seconds 1.30 seconds 45.00 seconds
	SCREEN 7 Gun Purge Bank Quantity	Configures the gun purge bank quantity per system. The maximum number of gun purge banks is three.	2

Changing Function Values

Swing down the control panel door to access the PLC.

NOTE: These instructions are also reproduced on a label on the inside the control panel door.



Figure 4-1 Feed Center PLC Interface

1. Press the **ESC** key to begin search mode.
2. Find the function screen to be changed by pressing the UP (..) or **DOWN** (T) arrow keys.
3. While on the selected screen, press and hold the **ESC** key. A cursor will appear.
4. Use the **LEFT** (◀) and **RIGHT** (▶) arrow keys to position the cursor on the value to be changed.
5. Press the **OK** key to highlight the value.
6. Use the **LEFT** (◀) and **RIGHT** (▶) arrow keys to select the correct units (xx:xx) column, and then the **UP** (..) and **DOWN** (T) arrow keys to change the value.
7. Press the **OK** key to enter the value.
8. Make additional changes to the same page by moving the cursor as described in steps 4–7.
9. When data changes to the page are complete, press the **ESC** key twice.

Level Sensor Programming

The level sensor probe tells the feed center PLC what the powder level is in the powder source. Follow these procedures to program the level sensor probe to recognize the level of powder in the feed source.

There are two different kinds of sensor probes, identified by the number of programming buttons on the probe.

Turn on the afterfilter exhaust fan and thoroughly fluidize the powder in the hopper or box before you program the level sensor probe.

One Button Level Sensor Probe Programming




Figure 4-2 Programming the One Button Level Sensor Probe

LED Functions

LED Color	Status	Meaning
Green	Lit continuously	Ready for operation (power is on)
Yellow	Lit continuously	Output has switched (powder is detected; full condition)
Yellow and Red	Flashing quickly	Short circuit of the switching output
Red	Lit temporarily	Normal function check; level sensor probe is approaching the full state
	Lit continuously	Level sensor probe is dirty or out of adjustment.

Empty (No Powder) Programming

NOTE: Programming the level sensor for Empty overwrites the values set for Full. If you program the level sensor for Empty, be sure to also program it for Full.

1. Lower the lance assembly until the powder covers at least 25 mm (1 in.) of the level sensor probe.
2. Raise the lance assembly so that the bottom of the level sensor probe is at least 25 mm (1 in.) away from the surface of the powder.
3. See Figure 4-2. Press the programming button until the green LED flashes slowly, then release it. When the green LED stops flashing and the yellow LED turns off, the level sensor is programmed for Empty.

The green LED will flash slowly for 5 seconds, then start flashing quickly. If you are still pressing the programming button when the green LED starts to flash quickly, you will be programming the level sensor for Full instead of Empty. Repeat the procedure from the beginning to program the level sensor for Empty, releasing the button while the green LED is flashing slowly.

Full Programming

NOTE: You can program the level sensor for Full as often as desired without overwriting the Empty value.

Lower the lance assembly until the powder covers at least 25 mm (1 in.) of the level sensor probe.

See Figure 4-2. Press the programming button until the green LED flashes quickly, then release the button.

The green LED flashes slowly at first, then after five seconds it flashes quickly. When both the green and yellow LEDs are lit continuously, the full adjustment is complete.

Locking and Unlocking the Level Sensor

The level sensor can be locked to protect it from unauthorized adjustment.

NOTE: The level sensor is shipped unlocked.

Task	Procedure
Locking	Press the programming button for 10 seconds. The green LED will flash slowly for five seconds, then it will flash quickly. When the green LED turns off, the level sensor probe is locked. When the green LED turns back on continuously, the level sensor probe is ready for operation.
Unlocking	Press the programming button for 10 seconds. After 10 seconds, all LEDs turn off, indicating that the level sensor probe is unlocked.

Operational Faults (Red LED Flashing)

If either Empty or Full programming cannot be completed, the red LED flashes quickly.

Task	Procedure
Clearing a Fault	Clear the fault by either: • pressing the programming button once, or • cycling feed center power.
Correcting Faults	• Check for and correct any of these possible causes for the fault: • The difference between Empty and Full is not great enough. Reprogram the level sensor. • Empty programming done while the probe was in the powder, or Full programming done while the probe was out of the powder. • During Empty programming, the distance between the probe and the powder was too short.

Two Button Level Sensor Probe Programming

When you program the level sensor probe, the powder feed center exhaust fan must be on and the powder in the hopper must be thoroughly fluidized.




Figure 4-3 Programming the Two Button Level Sensor Probe

LED Functions

LED Color	Status	Meaning
Green	On	Material not detected
Yellow	On	Material detected

Empty (No Powder) Programming

1. Lower the lance assembly until the powder covers at least 25 mm (1 in.) of the level sensor probe.
2. Raise the lance assembly so that the bottom of the level sensor probe is at least 25 mm (1 in.) away from the surface of the powder.
3. See Figure 4-3 Press the OUT OFF programming button until the LED ring slowly flashes yellow.
4. Release the button and the yellow light will go off. Empty programming is complete.

Full Programming

1. Lower the lance assembly until the powder covers at least 25 mm (1 in.) of the level sensor probe.
2. See Figure 4-3. Press the OUT ON programming button until the LED ring switches from flashing slowly to flashing quickly.
3. Release the button and the LED ring lights yellow continuously. Full programming is complete.

Locking and Unlocking the Level Sensor

The level sensor can be locked to protect it from unauthorized adjustment.

NOTE: The level sensor is shipped unlocked.

Task	Procedures
Locking	Simultaneously press the two programming buttons for 10 seconds in the operating mode. When the LED ring light changes its status for a brief moment, release the buttons. The level sensor is now locked.
Unlocking	Simultaneously press the two programming buttons for 10 seconds in the operating mode. When the LED ring light changes its status for a brief moment, release the buttons. The level sensor is now unlocked.

Operational Faults

If the sensor deviates from normal operation, check for and correct any of these possible causes:

- The difference between Empty and Full is not great enough. Reprogram the level sensor.
- Empty programming was done while the probe was in the powder, or Full programming was done while the probe was out of the powder.
- During Empty programming, the distance between the probe and the powder was too short.

Air Pressure Settings




Figure 4-4 Pneumatic Controls (door removed)

Refer to Pneumatic and Electrical Diagrams for feed center pneumatic diagrams.

Item	Function	Recommended Pressure
1	Lift Cylinder Down	3.4 bar (50 psi) 0.34 Mpa
2	Lift Cylinder Up	1 Lance: 4.1 bar (60 psi) 0.41 Mpa 2 Lances: 4.8 bar (70 psi) 0.48 Mpa 3 Lances: 5.5 bar (80 psi) 0.55 Mpa
–	Lift Cylinder Flow Control Valves	6 seconds full travel both directions
3	Purge Air	6.2 bar (90 psi) 0.62 Mpa
4	Lance Purge Clamp	3.4–4.1 bar (50–60 psi) 0.34–0.41 Mpa
–	Clamp Cylinder Flow Control Valves	3 seconds full travel both directions
5	Feed Hopper Fluidizing	0.3–0.7 bar (5–10 psi) (see Note) 0.03–0.06 Mpa
6	Lance Fluidizing	0.3–0.7 bar (5–10 psi) (see Note) 0.03–0.06 Mpa
NOTE: Adjust fluidizing air as needed. Powder should be gently boiling, without geysering		

Section 5

Operation

Controls




Figure 5-1 Feed Center Controls

Problem	Function
1. Damper Selection	Left: Manual mode – Damper is open for high flow. Right: Auto mode – Damper is partially closed during normal operation, open during color change.
2. Bulk Feed Pump	Turns the virgin powder transfer pump on and off. Used when system is equipped with a bulk feed system. When on, the pump is turned on and off automatically as needed to satisfy the level sensor on the lance assembly.
3. Reclaim Powder Transfer Pump	Turns the reclaim powder transfer pump on and off. When on, the pump operates continually
4. Sieve Control	Turns sieve vibrator motor on and off.
5. Color Change Enable	Starts color change sequence. If operator platform is equipped with an Ancillary Equipment Clean Cycle button, lances are automatically raised out of the hopper or box. If not, then it starts external gun blow off.
6. Emergency Stop	Shuts down powder coating system
7. Table Vibrator	Turns table vibrator motor on and off.
8. Purge Selection	Left: Start internal gun purge cycle. Center: Off Right: Start transfer pump purge cycle.
Continued...	

Problem	Function
9. Lance Lift	Raises and lowers lance assembly.
10. Powder Source Select	Selects hopper or box, controls where lances stop when lowered into powder.
11. Color Change Indicator Light (Green)	Off: Color change cycle is disabled Blinking: In color change cycle. On: Color change automatic operations complete

Feed Center Operation

Refer to Figure 5-1 for the feed center operator controls, and the Setup section for the PLC function settings.

Sieve Operation

See Figure 5-1. Powder is supplied to the feed center by HDLV reclaim and virgin powder transfer pumps. The powder is screened before flowing into the feed hopper. The sieve is turned on and off with the Sieve Control switch (4).

When the sieve is turned off, the reclaim and virgin powder transfer pumps are disabled.

Reclaim and Virgin Pump Selector Switch Operation

See Figure 5-1. The operation of the Reclaim and Virgin powder transfer pumps are controlled by separate selector switches (2, 3). Turning the switches to ON (I) enables the transfer pumps.

If the reclaim or virgin transfer pump selector switches are in the ON position when the feed center is turned on, or after a color change cycle is completed, then the pumps will be forced off. To re-enable the pumps, toggle the selector switches off then on.

The virgin transfer pump is disabled when the sieve is turned off.

Reclaim Transfer Pump Operation

The reclaim pump operates continuously as long as it is turned on.

Virgin Transfer Pump Operation

The virgin transfer pump operation is controlled by a level sensor on the lance. If the powder level in the feed hopper falls below the level sensor, a delay timer (Screen 2, Virgin Powder Transfer Delay) is started. When the delay timer runs out, the virgin powder transfer pump is started. The pump runs until the powder in the feed hopper reaches the level sensor, then turns off.

If the level sensor detects a low level of powder for too long (Low Powder Alarm Delay, Screen 3), a buzzer is turned on to warn the operator that the feed hopper powder supply has not been replenished.

The buzzer can be silenced by:

- filling the feed hopper until the powder contacts the level sensor.
- momentarily turning on gun purge.
- turning the virgin transfer pump off.

Transfer Pump Manual Purging

If a transfer pump becomes clogged during operation, purging the pump may clear it.

See Figure 5-1. Turn the Purge Control selector switch (8) to the Pump Purge position while the pump is on. Purge air is applied to the pump as long as the switch is in the purge position.

Powder Level Sensor Operation

Hopper Operation

See Figure 5-1. When the Powder Source selector switch (10) is set to Hopper, the lance is moved down into the hopper until the hopper proximity sensor on the lift cylinder is activated and stops the lance above the fluidizing plate. When the level of powder falls below the level sensor, a delay timer (field-adjustable) is started.

When the delay timer runs out, the virgin transfer pump is turned on to refill the hopper. When the level sensor detects powder, the virgin transfer pump is turned off. If the level sensor detects no powder for greater than 3 minutes (field-adjustable), the low powder alarm is turned on. Refer to Feed Center Function Settings, for instructions on setting the timers.

Box Operation

When the Powder Source selector switch (10) is set to Box, the system lowers the lance assembly into the box until the level sensor “sees” powder. As the powder is used, the level sensor automatically lowers the lance into the box until the box proximity sensor on the lift cylinder is activated and stops the lance. If the level sensor detects no powder for greater than 3 minutes (field-adjustable), the low powder alarm is turned on.

Silencing the Low Powder Alarm

Turn the Purge Selector switch (8) to Gun Purge momentarily to silence the low powder alarm buzzer.

Startup



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Make sure all settings in the Setup section of this manual have been completed before starting up the system for the first time.

1. Turn on the afterfilter exhaust fan.
2. Turn on power and air to the feed center, if not already on.
3. Make sure compressed air is being supplied to the feed center at above 5.5 bar (80 psi) and that air pressures are adjusted properly. See Figure 5-2 for regulator locations.

Table 5-1 Feed Center Air Pressure Settings

Air Pressure	Typical Settings
Lance Fluidizing (typical)	0.3 bar (5 psi) 0.03 Mpa
Feed Hopper Fluidizing (typical)	0.3 bar (5 psi) 0.03 Mpa
Purge	5.5 bar (80 psi) 0.55 Mpa
Purge Clamp	3.4–4.1 bar (50–60 psi) 0.34–0.41 Mpa
Lance Cylinder:	4.1 bar (60 psi) 0.41 Mpa
Up, 1 Lance	4.8 bar (70 psi) 0.48 Mpa
Up, 2 Lances	5.5 bar (80 psi) 0.55 Mpa
Up, 3 Lances Down	3.4 bar (50 psi) 0.34 Mpa

4. Move a feed hopper or box into the feed center, and position it below the lance assembly, adjusting the table stops as necessary. Select Hopper or Box with the Powder Source Selector switch on the control panel.
5. If using a feed hopper:
 - a. Connect the fluidizing tubing to the fitting on the feed hopper plenum.
 - b. Fill the hopper 2/3 full of powder. Do not overfill; the powder expands when fluidizing air is turned on.
 - c. Gradually increase the feed hopper fluidizing air pressure until the powder is gently boiling.
 - d. Lower the lance assembly into the hopper with the Lance Control switch. The lance stops automatically above the fluidizing plate.
6. If using a powder box:
 - a. Turn on the vibratory table.
 - b. Lower the lance assembly into the box with the Lance Control Selector switch (left for down) until the fluidizing bars and end of the level sensor are covered by powder.
 - c. Gradually increase the lance fluidizing air pressure until the powder is gently boiling.
7. Make sure the sieve discharge pan is positioned so that the discharge tube directs the screened powder into the feed hopper or box. Loosen the deck clamps to rotate the pan, then re-clamp the deck.
8. If used, make sure the reclaim and virgin powder transfer hoses are connected to the tubing stubs on the sieve deck. Turn on the reclaim transfer pump and enable the virgin transfer pump.
9. Turn on the sieve.
10. Turn on the spray guns and start spraying powder. Make sure everything is working correctly before starting production.

Color Change Operation

Refer to Figure 5-1 for the feed center operator controls. A color change sequence is started by turning the Color Change Enable selector to ON. The sequence is finished or aborted by turning the selector to OFF.




Figure 5-2 Color Change Sequence

Color Change Procedure

Refer to the Color Change Procedure included with your system manual for instructions on color changing a powder coating system with a ColorMax booth and this Encore Venturi Feed Center.

During a color change sequence, the lances are withdrawn from the powder source, then lowered onto the purge manifold. High pressure air is directed through the lances, pumps, feed hoses, and guns, purging them of powder. The reclaim and virgin transfer pumps are also purged. The operator cleans the sieve, lances, and the interior of the booth, and readies the feed center for the next color. Meanwhile, another operator cleans the booth and cyclone.

The recommended sequence of steps is provided in the color change charts furnished by Nordson, but can be modified as desired depending on the customer needs and requirements.

Shutdown

1. Move the system offline, if applicable.
2. Clean the system by performing the color change process, but do not install a new powder source or turn the pumps, sieve, or vibratory table on.
3. If you will be shutting down the powder feed center for maintenance, repair, or an extended period of time, perform these steps:
4. Press the SYSTEM STOP button on the system control panel.
5. Turn the electrical disconnect switch on the powder feed center control panel to the OFF position.

Section 6

Maintenance



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

NOTE: Maintenance procedures given here are for the feed center only. Refer to your system component manuals for maintenance procedures for all other system equipment.

Daily Maintenance

NOTE: You may need to perform these procedures more or less often, depending on your application requirements.

Table 6-1 Daily Maintenance Procedures

Component	Maintenance Procedure
Sieve	Disassemble and clean the sieve pan and screen. Inspect the sieve screen and replace it if powder is fused to it or it is damaged. If applicable, make sure the ground clip is installed around the screen gasket so it grounds the screen to the pan and deck. More information on sieve styles is available in the Parts section, beginning on page 6-1.
Purge Manifold Assembly	Raise the lance assembly and blow off the purge manifolds, latches, yokes, and air cylinder. Make sure all quad ring seals are in place on the purge manifolds.
Lance Assemblies	Blow off the lance assemblies and check all powder hose and air tubing connections.
In-Line Pumps	Disassemble the pumps and blow off the parts with low-pressure compressed air. Replace any worn parts. Refer to the Encore In-Line Pump manual, part number 1095928, for repair procedures and replacement parts.
Cables, Tubing, and Feed Hoses	Check all external cables, powder hoses, and air tubing for damage. Repair or replace as necessary.
HDLV Transfer Pumps	Purge the pumps. Inspect the pinch valve body for signs of powder leakage. If powder is present in the pinch valve section, replace the pinch valves. Refer to the Prodigy HDLV High-Capacity pump manual, part number 1092270, for repair procedures and replacement parts.
Powder Supply	Check the powder supply level regularly and add powder as necessary.
Compressed Air Supply	Check the compressed air dryers and filters. Drain filters if needed. Perform maintenance as necessary.
Enclosure	Clean the interior and exterior of the feed center. Check all equipment ground connections.

Periodic Maintenance

NOTE: You may need to perform these procedures more or less often, depending on your application requirements.

Table 6-1 Periodic Maintenance Procedures

Component	Maintenance Procedure
Air Flow	Take regular air flow readings at the face of the feed center. A properly functioning powder feed center should provide a face velocity of approximately 2.8 m ³ /min (100 ft ³ /min). A lower reading indicates clogged ducts or afterfilter cartridge filters.
Compressed Air System	Open the drop leg and use a clean, white cloth to check for contaminants. Correct any problems immediately. Drain the air filters and change the elements as necessary.
Electrical System	Tighten all electrical connections and inspect for loose or broken wires. Check the electrical system for electrical safety every 12 months. The system must comply with all local, state, and federal codes.
System Grounds	Check all equipment grounds. Electrical equipment must be grounded according to code. For maximum transfer efficiency and safety, electrostatic equipment must be grounded to provide a complete circuit from the spray guns through the workplace hangers, conveyors, and booth back to the gun controllers. Refer to the Safety section "Grounding" on page 1-3 of this manual and to publication number TCTT-06-3881 on the Nordson emanuals web site (http://emanuals.nordson.com/finishing) for more information on powder coating system grounding.
Air Tubing	Pressurize the system and listen for air leaks. Replace or repair any leaking tubing or fittings.

Section 7

Troubleshooting



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

If you cannot solve your problem with the information in this manual or related equipment manuals, contact the Nordson Industrial Coating Systems Customer Support Center at (800) 433-9319 or your local Nordson representative.

Refer also to the wiring diagrams and schematics at the end of this manual.

Troubleshooting Chart

Problem	Possible Cause	Corrective Action
1. Powder not contained within feed center enclosure, afterfilter fan not running.	E-Stop button pressed	Reset the E-Stop.
	Final filters clogged	Check the final filters. The fan is shut off automatically if the pressure across the filters reaches 3 in. w.c. If the filters are clogged, check the cartridge filter media and gaskets for leaks. Replace damaged cartridge filters. Replace the final filters.
	Fan start/stop button or wiring defective	Check the fan motor control circuits (main system electrical panel).
	Fan motor overload tripped	Overload occurs when the motor operates at a greater amperage than designed for. Make sure the overload is set to the proper limit. Make sure nothing is stopping the motor and fan from turning. Check the fuses. Failure of one of three fuses in a 3-phase motor circuit can cause the overload to trip. Check the motor and electrical connections. Reset the overload.
	Fan motor fuse failure	Check the motor and electrical circuits. Replace the fuses.
	Fan motor failure	Replace the motor.

Problem	Possible Cause	Corrective Action
2. Powder escaping from enclosure openings.	Afterfilter cartridge filters clogged; pulsing not cleaning filters	Pulse the cartridge filters to blow off powder. Check the pulse air pressure. Check the cartridge filter pulse sequence: • If the Off duration is too short, the pulse manifold may not build up enough pressure to blow off the cartridge filters. • If the On duration is too short, not enough air is released to blow off the filters. • If the On duration is too long, the pulse manifold may not be able to build up enough air pressure. Replace the cartridge filters if pulsing does not correct the problem.
	Pulse pressure too low	Increase the pulse pressure to the recommended level.
	Pulse valve failed	Replace the pulse valve.
	Cartridge filters leaking	Check the cartridge filter gaskets and media for damage. Tighten the mounting nut to compress the gaskets. Replace filters as necessary.
	Cross drafts interfering with exhaust fan draw	Check for cross drafts at the enclosure opening. Eliminate or divert drafts.
	Fan rotation backward	Reverse the motor rotation.
3. No feed hopper fluidizing air	Access panels not sealed	Tighten all access panels. Check and replace the panel gaskets as necessary.
	Afterfilter fan not running, interlock valve closed	Start the afterfilter exhaust fan. Check feed center E-Stop. Check valve connections.
	Fan interlock circuit or solenoid valve circuit defective	Check the fan interlock wiring between the feed center panel and main system panel. Check the wiring from the feed center panel to the solenoid valve assembly on top of the feed center air drop.
	Fluidizing air regulator defective	Check the fluidizing air regulator.
<i>Continued...</i>		

Problem	Possible Cause	Corrective Action
4. Powder in feed hopper not fluidizing, or clouds of powder erupting from surface	Fluidizing air pressure too low or too high	Increase the fluidizing air pressure until the powder is gently boiling. Decrease the pressure if clouds of powder are erupting from the surface.
	Moist or oil-contaminated powder	Check the air supply for water or oil. Check the filters, separators, and air dryer. Replace the powder in the feed source if it is contaminated. Refer to the next possible cause.
	Fluidizing plate gasket leaking, or fluidizing plate plugged, cracked, or installed incorrectly	Check for air leaks around the fluidizing plate gasket. If leaks are found, replace the gasket. Inspect the fluidizing plate for stains, discoloration, polished surfaces, or cracks. Replace it if contaminated, plugged, or damaged. The plate should be installed with the smooth surface up (in contact with the powder).
	Incorrect ratio of reclaimed to virgin powder	Increase or decrease the transfer rate. The powder supply should be no more than three parts reclaim to one part virgin powder.
	Uneven distribution of powder in feed source	Check the powder and the fluidizing plate for contamination as previously described.
5. Powder in box not fluidizing, or clouds of powder erupting from surface	Lance fluidizing air pressure too low or too high	Increase the lance fluidizing air pressure until the powder is gently boiling. Decrease the pressure if clouds of powder are erupting from the surface.
	Moist or oil-contaminated powder	Check the air supply for water or oil. Check the filters, separators, and air dryer. Replace the box if the powder is contaminated. Refer to the next possible cause.
	Fluidizing bar assembly leaking or damaged	Raise the lance assembly and check the fluidizing bars.
	Vibratory table motor defective	Check the vibrator motor. Refer to Problem 6 for motor troubleshooting procedures.
6. Sieve or vibratory table turned ON, but no vibration	E-Stop button pressed	Reset the E-Stop button.
	Afterfilter exhaust fan not running	Start the exhaust fan.
	Sieve switch or wiring defective	Check the switch and wiring. Replace the switch or repair the wiring as needed.
	Sieve motor overload	Overload occurs when motor operates at higher amperage than designed for. Make sure nothing is preventing motor vibration. Check the motor and electrical connections. Check the motor internal weights for proper adjustment. Make sure the overload protector is set to the proper limit. Reset the overload.
	Sieve motor failed	Replace the sieve motor.
7. Powder buildup on sieve screen	Screen not cleaned frequently enough	Clean the sieve mesh at more frequent intervals. Upgrade to Vibrasonic sieve screen if necessary.
	Screen mesh size too small for powder being used	Use a sieve screen with a larger mesh size. Upgrade to Vibrasonic sieve screen if necessary.
Continued...		

Problem	Possible Cause	Corrective Action
8. Excessive sieve noise	Sieve deck or discharge pan not secure	Tighten the clamps securing the sieve deck.
	Knobs or clamps not tightened; vibration isolators loose or damaged; screen gasket damaged	Make sure the clamps are tight. Check the isolators for looseness or damage. Tighten the isolator mounting screws. Check the screen gasket and replace it if damaged.
9. Contaminants in feed hopper powder	Sieve screen torn	Replace the screen.
	Sieve screen not thoroughly cleaned before installation	Remove and clean the sieve screen
10. Reclaim or virgin transfer pump turned on, but pump does not run	E-Stop button pressed	Reset the E-Stop button.
	Afterfilter exhaust fan not running, or fan interlock circuit defective	Turn on the exhaust fan. Check the fan interlock wiring between the feed center panel and the main system panel.
	Sieve motor not running	During normal operation, the reclaim and virgin pumps will not run unless the sieve is on. Turn on the sieve.
	Reclaim or Virgin switch or wiring is defective	Circuits are disabled if the switches are in the On position when feed center power is turned on, or when the Color Change Stop button is pressed. To reset the circuits, turn the Reclaim or Virgin switch Off then On.
	No air supply to control manifold, or solenoid valve not opening (reclaim SOL 336, virgin SOL 338)	Check the air supply to the control manifold on the roof of the feed center. Check for air output from solenoid valve. Check the control manifold cable wiring. Repair or replace as needed.
	Problem with transfer pump controls or pump	Check the pump and controls. Refer to High Capacity HDLV pump manual 1092270 and Pump Station manual 1073134.
	Level sensor failed or wiring defective	Check the solenoid valve in the control manifold. Make sure the manual operator on the valve is not in override position.
11. Reclaim or virgin transfer pump turned off but continues to run	Solenoid valve in manual override (reclaim SOL 336, virgin SOL 338)	Check the solenoid valve in the control manifold. Make sure the manual operator on the valve is not in override position.
	Solenoid valve failed open	Replace the valve.
12. Virgin transfer pump is turned on but pump not running	Level sensor on feed hopper is detecting powder in hopper	The pump will not turn on until the powder level falls below the level sensor and the delay timer runs out
	Refer to Problem 10 for other causes	
Continued...		

Problem	Possible Cause	Corrective Action
13. Virgin transfer pump does not stop automatically	No powder supply at bulk feed system	Check the virgin powder supply.
	Feed hopper level sensor not adjusted properly	Level sensor stops pump when it detects powder. Sensor indicating light should be yellow when powder is detected. Adjust the level sensor if it is not detecting powder. Refer to level sensor documentation.
	Level sensor failed or wiring defective	Check level sensor and wiring. Repair or replace as needed
14. Reclaim and/or virgin transfer pump purge cycle does not start when Purge switch turned to Pump Purge position	Reclaim and virgin transfer pumps not turned on	Pumps must be on before purge can start. Turn on pump to be purged
	Switch or wiring defective	No signal from switch to controller. Turning the switch to Pump Purge position should turn on signal. Check switch and wiring, repair or replace as needed.
	Control manifold purge solenoid valves or wiring defective	Check for air output from solenoid valve SOL 340 (reclaim), SOL 342 (virgin). Refer to the Description section for the solenoid valve location. Check air supply to control manifold. Check cable wiring. Repair or replace as needed.
	Purge air process valve or pilot air tubing defective	Check pilot air tubing. Make sure air signal is reaching process valve in pump station. Check process valve operation. Check air supply to process valve. Repair or replace as needed. Refer to pump station manual 1073134.
15. Feed center low powder level alarm buzzer on	Alarm buzzer delay timer has run out, level sensor not detecting powder	Alarm buzzer timer starts when the transfer pump turns on. If the timer runs out and the level sensor has still not detected powder, then the alarm buzzer is turned on. The timer default is 3 minutes. To turn off the buzzer, turn the Purge switch to Gun Purge momentarily.
	Problem with powder supply or virgin transfer pump	Refer to problems related to powder, sieve, or pump.
16. Color change does not start when Color Change switch turned on, light off	E-Stop button pressed	Reset E-Stop button.
	Afterfilter exhaust fan not running, or fan interlock circuit defective	Turn on exhaust fan. Check fan interlock wiring between feed center panel and main system panel.
	Color Change switch or wiring defective	No signal from switch to controller. Check switch and wiring, repair or replace as needed.
	PLC not initiating color change sequence.	Check PLC operation. Contact your Nordson representative or technical support center for help.
<i>Continued...</i>		

Problem	Possible Cause	Corrective Action
17. Color change does not start with Color Change switch turned on, light on	Parts still in booth	iControl system tracks parts through booth and will delay color change start until parts clear booth. Booth length is configurable through iControl Configuration. Refer to iControl Operator Interface manual for more information.
	iControl gun positioners not in manual or auto mode	Set the gun positioners to either manual or auto mode.
	iControl gun positioner controller did not receive Color Change start signal from feed center	The feed center passes signals for color change to the gun positioner controller which then communicates with the iControl system. Check the wiring and connections between the feed center control panel and the gun positioner controller.
	Reciprocator not in auto mode	Reciprocator must be in auto mode for color change cycle to start. Set the reciprocator to auto mode.
18. Color change cycle started, gun positioner stopped at forward limit switch	Oscillator not at bottom of stroke (USA only)	Oscillator must be at bottom of stroke for spray guns to be in position for gun blowoff. Blowoff will not start until bottom of stroke sensor is on and remains on. Check oscillator position.
	ColorMax not selected on iControl gun positioner configuration screen (USA only)	Check gun positioner configuration.
	Oscillator not stopped	Oscillator gets stop command from gun positioner controller. Refer to your system electrical drawings. Contact Nordson technical support. USA only – Oscillator bottom of stroke sensor not sending signal to main system panel. Sensor detects rotating lever arm. Make sure sensor is positioned to detect arm and check wiring and connections to sensor.
	Reciprocator not at Park position	Reciprocator must be at Park position for spray guns to be in position for gun blowoff. Blowoff will not start until Park position is achieved. Check reciprocator position. Make sure Park position is configured within stroke range. Refer to iControl Operator Interface manual for reciprocator configuration settings.
19. Color change cycle started, blowoff air does not turn on	No air supply to solenoid valve or process valve, failed valve, or bad electrical connection	Solenoid valve in the main system panel is activated by a signal from the gun positioner control panel. Solenoid valve sends air signal to large pilot valve that provides air to the blowoff nozzles. Make sure main system panel air supply is on. Check solenoid valve output. If solenoid coil is energized but no air flows from valve, replace valve. Check air tubing to pilot valve. Check process valve operation. Check the wiring and connections between the gun positioner controller and solenoid valve.

Section 8

Repair



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

Purge Manifold Assembly Repairs

Quad Ring Replacement

When replacing the purge manifold quad rings, make sure the lower portion of the ring is pressed into the pocket formed by the manifold block and the seal retainer plate. Use your fingernail or a tool to work the ring into the pocket. Be careful not to damage the rings when installing them.




Figure 8-1 Purge Manifold Quad Ring Replacement

1. Quad ring

2. Seal retainer plate

3. Manifold block

Latch Pawl Replacement

See Figure 8-1. To remove a latch pawl from a latch:

1. Raise the lance assembly all the way up.
2. Press the E-Stop button on the feed center control panel to shut off the power and air. This relieves the air pressure and mechanically locks the lift cylinder in position.
3. Remove the hopper/box table from the enclosure:
 - a. Remove the nuts (2) from the isolation mounts (1).
 - a. If using a vibrator motor, loosen the motor cable cord grip and pull the cable slack through the grip.
 - a. Lift the table up off the mounts and move it enough to gain access to the purge manifold assembly.




Figure 8-2 Pawl Replacement

1. Isolation mount
2. Nut

3. Pawl mount
4. Pawl

4. Remove the Philips-head screw securing the pawl (4) to the pawl mount (3).
5. Position the new pawl on the latch with the top surface of the pawl flush with the top surface of the latch lever.
6. Secure the pawl to the latch with the screw. Tighten the screw securely.
7. Re-install the hopper/box table on the isolation mounts, and then, if used, pull the vibrator motor cable back into the control cabinet. Leave enough slack in the cable to avoid any strain on it, then tighten the cord grip.

Latch Replacement

Latch Removal

To remove a latch from the purge manifold:

1. Perform steps 1–3 in Latch Pawl Replacement.
2. Disconnect the air lines from the purge manifold clamping cylinder.
3. See Figure 8-2. Grasp the cylinder clevis and pull the cylinder shaft out to the fully extended position to extend the latches and provide access to the latch set screws (3).




Figure 8-3 Latch Replacement

- | | | |
|---------------|------------------|-------------------|
| 1. Pawl | 4. Pawl mount | 7. Mounting block |
| 2. Latch body | 5. Socket screws | |
| 3. Set Screw | 6. Hex shaft | |
4. Loosen the set screw (3) securing the latch to the hex shaft (6), then remove the four button-head socket screws (5) securing the latch body (2) to the mounting block (7).
 5. Remove other latches as needed if the broken latch is not the last latch on the shaft. Slide the latch(es) off the end of the hex shaft.

Latch Installation

1. Make sure the clamping cylinder and the new latch are fully extended and that the top surface of the latch pawl (1) is flush with the top surface of the pawl mount (4). Adjust the pawl position if necessary by loosening the Philips-head screw in the pawl recess.
2. Slide the new latch on the hex shaft so that the bottom of the latch body is parallel to the surface of the mounting block.
3. Position the latch body over the tapped holes in the mounting block and install the four socket screws.
4. See Figure 8-3. If all latches have been removed from the hex shaft, push or pull on the hex shaft (4) to center the lever (2) in the yoke (1) before you tighten the set screw to secure the latch to the hex shaft.




Figure 8-4 Pawl Replacement

1. Yoke

2. Lever

3. Hex shaft

5. After all latches have been re-installed, check the latch movement by extending and retracting the clamping cylinder by hand. The pawl should move freely side-to-side and not bind on the sides of the latch body when the latch is extended and retracted.

If the pawl binds against the sides of the body, loosen the four latch mounting screws, then push outwards on the sides of the latch body while re-tightening the screws.

Latch Pawl Adjustment

Figure 8-5 shows a latch extended until it is over-center. The latch pawl (2) is normally installed with the top surface flush with the top surface of the pawl mount (1). With the lance clamped down, the latch should not go over-center (fully extended). The latch pins (3) should not be up against the ends of their slots.

If the latch does go over-center, the latch pins make a clicking noise when they hit the ends of the slots.

To reduce latch travel and increase clamping force, loosen the Philips-head screw in the pawl recess and move the pawl down one notch. This adjustment may also be required with higher purge air pressures to increase the clamping force.

To reduce clamping force, the pawl can be moved up one notch. However, do not do so if this allows the latch to go over-center when the lance is clamped down.




Figure 8-5 Pawl Adjustment - Latch Shown Over-Center

1. Pawl Mount

2. Pawl

3. Pins

Clamping Cylinder Replacement

1. Perform steps 1-3 in Latch Pawl Replacement.
2. See Figure 8-6. Disconnect the air tubing from the cylinder flow control valves.
3. Retract the cylinder to gain access to the lever hardware.
4. Remove the clamp screws (5) on each lever assembly (4), then remove the cylinder assembly (10), and lever assembly (4) from the manifold shaft (11).
5. Discard the old cylinder assembly (10) and lever assemblies (4).
6. Remove the proximity switches (6, 7) from the new cylinder assembly (10).
7. Center the new cylinder assembly (10) inside cylinder adapter spacer (12) with the latches in fully open position and the cylinder fully retracted.

NOTE: Indentations in the lever assemblies (4) must be located facing inwards.

8. Using an M5 Allen wrench, attach the lever assemblies (4) to the manifold shaft (11) ensuring that lever assemblies (4) remain centered and the latches will remain open.

NOTE: It may be necessary to re-clock the rod or slightly extend the cylinder to ensure lever assemblies (4) attach properly with latches fully open.

9. Install proximity switches as follows:

- Extend (Engaged): LS403 – Install on rod end.
- Retract (Released): LS404 – Install on fixed end.

NOTE: Refer to the electrical schematic.

10. Push the cylinder rod into the cylinder assembly until it is fully retracted. Verify that when the cylinder is retracted, the latches are fully open. Material may be ground off of black delrin spacer if needed to adjust length.
11. Verify that when the cylinder is extended, the levers are making contact with the clevises and the latches are fully closed.




Figure 8-6 Clamping Cylinder Replacement

- | | | |
|------------------|-------------------------------------|------------------------------|
| 1. Clevises | 5. Lever clamp screws | 9. Extend flow control valve |
| 2. Clevis pins | 6. Retract proximity switch (LS404) | 10. Cylinder assembly |
| 3. Delrin spacer | 7. Extend proximity switch (LS403) | 11. Manifold shaft |
| 4. Lever | 8. Retract flow control valve | 12. Cylinder adapter spacer |

12. Connect the air tubing to the appropriate cylinder flow control valves. Refer to the pneumatic schematic foldout in this manual.
13. Turn on the feed center air supply.
14. Lower the lance onto the purge manifold and set the purge air pressure to zero. Refer to "Air Pressure Settings" on page 4-8 for the location of the purge air pressure regulator.
15. Select Gun Purge on the control panel, and adjust the extend flow control valve for a 3 second extend. Turn Gun Purge off and adjust the retract flow control valve for a 3 second retract. Toggle Gun Purge on and off as needed while adjusting the valves.
16. Select Gun Purge and clamp the lance. Position the extend proximity switch (LS403):
 - Slide the switch on the cylinder until it senses the magnet in the cylinder piston and the LED lights.
 - Note the position where the LED turned on, then continue sliding it in the same direction until the LED turns off.
 - Position the switch in the midpoint between LED off positions and tighten the clamp screw to secure it in place.
17. Turn off the Gun Purge and allow the cylinder to retract. Adjust the retract proximity switch at the fixed end of the cylinder in the same way as the extend switch.
18. Raise the lance and re-install the hopper/box table.
19. Adjust the purge air pressure to 5.5 bar (80 psi).

Lift Cylinder Replacement

The replacement lift cylinder listed in the Parts section of this manual does not include the trunnion flange and fasteners, clevis and clevis pin, or proximity switches. Re-use your existing components, or order new ones as needed.

Lift Cylinder Removal

1. Lower the lance assembly onto the purge manifold. The lance carriage will be positioned against the stop bolt.
2. See Figure 8-7. Unclip the clevis pin (3) from the clevis (1) and pull the pin out of the clevis and carriage plate (2). Do not lose the pin, as you will need it to install the new cylinder.



Figure 8-7 Lift Cylinder Clevis Pin

1. Clevises

2. Clevis plate

3. Clevis pin

3. Raise the cylinder to the full up position.
4. Turn off the feed center air supply and power by pressing the E-Stop button on the control panel. This relieves the air pressure and mechanically locks the cylinder in place.
5. See Figure 8-8. Disconnect the air tubing from the Up and Down flow control valves and the cylinder lock at the top and bottom of the cylinder.
6. Measure and note the position of the proximity switches. Label the switches and remove them and their brackets from the cylinder.
7. Remove the four M8 socket-head screws from the bottom of the trunnion support block.
8. Remove the bearing caps, then pull the bearings off the cylinder trunnions. Lift the cylinder up and out of the enclosure. Save the bearing caps and bearings for re-use.
9. Remove the clevis and lock nut from the cylinder. Save these parts for re-use.
10. Remove the trunnion flange from the cylinder. Save the flange and four screws for re-use.




Figure 8-8 Lift Cylinder Replacement

Lift Cylinder Installation

1. Remove the lift cylinder packaging and inspect it for damage.
 2. See Figure 8-8. Install the trunnion flange on the new cylinder.
 3. Thread the locknut on the new cylinder rod, then thread the clevis all the way onto the new cylinder rod and lock it in place with the locknut.
 4. Unsnap the clevis pin clip from the clevis and remove the pin.
 5. Remove the four M8 x 75 screws from the bottom of each side of the bearing block and lift off the bearing caps.
 6. Remove the bearings from the bearing caps. Install the bearings on the cylinder trunnions, with the bearing flanges toward the cylinder.
 7. Install the cylinder through the square opening in the roof of the feed center, then carefully guide the bearings into the trunnion support block.
 8. Install the bearing caps on top of the bearings, noting that the bearing caps have position letters stamped on each cap which match letters stamped on the block. Reinstall with the matching letters aligned. Secure the caps to the support block with the four M8 x 75 screws.
 9. Connect air tubing to the cylinder:
 - 6-mm tubing from Down regulator to upper flow control valve.
 - 6-mm tubing from Up regulator to lower flow control valve.
 - 6-mm tubing from solenoid #3 SOL326 to the cylinder lock.
 10. Rotate the E-Stop button on the feed center control panel clockwise to release it and turn on feed center power and air.
 11. Lower the cylinder clevis down the the lance carriage, which should be resting on the stop bolt at the bottom of the V-track rail.
 12. Connect the clevis to the lance carriage with the clevis pin. Snap the pin clip around the clevis.
 13. Install the proximity switches on the cylinder at the same positions as on the old cylinder:
 - LS306: Hopper position
 - LS307: Box position
 - LS308: Purge position
 14. Adjust the position of the purge proximity sensor (LS308).
 - a. Slide the switch up or down until it senses the magnet in the cylinder piston and the LED lights.
 - b. Note the position where the LED turned on, then continue sliding it in the same direction until the LED turns off.
 - c. Slide the switch back up and position it in the midpoint between the off positions and secure it in place.
- NOTE:** Refer to *Lift Cylinder Proximity Switch Adjustment* on page 3-11 of this manual to set the positions of the Box switch (LS307) and the Hopper switch (LS306).
15. Raise and lower the lance assembly and adjust the cylinder flow control valves for 6 seconds full travel in each direction.

Cylinder Cushion Stop Adjustment

Make sure the top cylinder cushion stop is adjusted to bring the piston to a gentle stop when fully retracted.

The adjustment screw is recessed into the end cap next to the flow control valve. Rotating it clockwise increases the dampening effect; counterclockwise decreases the effect.

The bottom cushion stop can be adjusted in the same manner.

Lance Assembly/Purge Manifold Alignment

Anytime the purge manifold, lance, lance arm, or lift assembly is moved, the purge manifold and lances must be re-aligned with each other to ensure proper operation and lance-to-purge manifold sealing.

1. Remove the hopper/box table.
2. See Figure 8-9. Loosen the 8-mm through bolts securing the lance plates to the lance arms.
3. Loosen the ground screw on the lance arm.
4. Loosen the four screws securing the lance arm to the lift carriage plate, just enough to move the lance arm. The lance arms must not sag.




Figure 8-9 Lance Adjustment Steps 2-4

Lance Assembly/Purge Manifold Alignment (contd)

5. Set the purge air pressure to zero.
6. Move the lance down to the stop bolt (Purge Position). Verify that the stop bolt is adjusted to stop the carriage just before the lance makes contact with the purge manifold quad-ring seals. Manual alignment of the lances to the purge manifolds may be necessary as all the fasteners are loose.





Figure 8-10 Stop Bolt Adjustment

7. Turn the Purge Control switch to the Internal Gun Purge position. The lance will be clamped into place.
8. Make sure the alignment between the lance latch blocks and the purge manifolds, front to back, is correct.

The manifolds and lances should be parallel, and the gap between the lances and the manifold seal retainer plate should be even all the way around.




Figure 8-11 Lance Adjustment, Step 8

9. When each of the lance plates and manifold latches are adjusted correctly, the fasteners loosened in steps 2–4 can be tightened. Tighten the through bolts first, then the four screws securing the lance arms to the lift carriage, then the ground screw.
10. Turn Off the Purge Control switch.
11. Adjust the purge air to 5.5 bar (80 psi).
12. Select Internal Gun Purge with the Purge Control switch. The lances will be clamped and the purge air will turn on.
13. Verify that the lances and purge manifolds align properly, and that little or no air escapes from between them while the guns are being purged.

If air leaks from the seals, loosen the latch pawl screws and move the pawls down one notch for a tighter clamp force. Refer to page 8-14 for the pawl adjustment procedure.

Feed Hopper Fluidizing Plate Replacement

75-lb Feed Hopper Fluidizing Plate Replacement

1. Empty the hopper and vacuum as much powder as possible out of the hopper.
2. See Figure 8-12. Remove the screws (5), flat washers (6), and nuts (7) securing the body (1) to the plenum (4). Lift the body off the plenum.
3. Remove and discard the old fluidizing plate (2) and U-gasket (3).
4. Vacuum the inside of the plenum and clean the body and plenum flanges.
5. Install the U-gasket around the outside edge of the new fluidizing plate.

NOTE: Make sure that the smooth side of the new fluidizing plate is facing up.

6. Re-assemble the body, fluidizing plate, and plenum with the screws, washers, and nuts.



CAUTION: Do not overtighten the nylon screws. Overtightening the screws will result in stripped threads and possible air or powder leaks.




Figure 8-12 75-lb Feed Hooper Fluidizing Plate Replacement

- | | | |
|---------------------|------------------------------|------------------------|
| 1. Body | 4. Plenum | 7. Nylon hex nuts (M8) |
| 2. Fluidizing Plate | 5. Nylon screws (M8 x 40 mm) | |
| 3. U-gasket | 6. Nylon flat washers | |

50-lb Feed Hopper Fluidizing Plate Replacement

1. Empty the hopper and vacuum as much powder as possible out of the hopper.
 2. See Figure 8-13. Remove the screws (5) securing the body (1) to the plenum (3). Lift the body off the plenum.
 3. Remove and discard the old fluidizing plate (2).
 4. Vacuum the inside of the plenum and clean the body and plenum flanges.
 5. Check the O-ring gaskets (4) on the body and plenum flanges and make sure they are securely installed in the flange grooves.
- NOTE:** Make sure the smooth side of the new fluidizing plate is facing up.
6. Re-assemble the body, fluidizing plate, and plenum with the nylon screws.



CAUTION: Do not overtighten the nylon screws. Overtightening the screws will result in stripped threads and possible air or powder leaks.




Figure 8-13 50-lb Feed Hooper Fluidizing Plate Replacement

- | | | |
|---------------------|-------------------|-----------------|
| 1. Body | 3. Plenum | 5. Nylon screws |
| 2. Fluidizing Plate | 4. O-ring gaskets | |

Vibratory Table Motor Weight Adjustment

Refer to Table 8-1. If you replace the vibratory table motor, or retrofit a motor to the table, you will need to adjust the new motor weights to the specified setting. Use the applicable instruction to adjust the weights.

Table 8-1 Table Vibrator Motor Weight Settings and Instructions

Nordson Part Number	Description	Manufacturer	Weight Setting
1602109	VIBRATOR, 230/460V, 3PH/60Hz	Oli-Wamgroup/MVE 60/3	66%
1602896	VIBRATOR, 330/575V, 3PH/60Hz	Oli-Wamgroup/MVE 60/3	66%
1602893	VIBRATOR, 220/380V, 3PH/60Hz	Oli-Wolong/MVE 60/3	66%
1602109	VIBRATOR, 200/400V, 3PH/50Hz, ATEX	Oli-Wamgroup/MVE 60/3	75%
1602896	VIBRATOR, 220/380V, 3PH/50Hz	Oli-Wolong/MVE 60/3	75%
1602893	VIBRATOR, 240/415V, 3PH/50Hz	Oli-Wolong/MVE 60/3	75%

60Hz Motor Weight Adjustment

See Figure 8-14 for steps 1 - 4 when replacing or retrofitting a 60Hz vibratory table motor for the Encore Powder Feed Center.

FC 66% = 2 blades turned

60Hz = 156.5 lb. FC X 66% = 103.29 lb. FC

1. Remove the caps from both ends of the motor.
2. Place wrenches on the nuts located on both ends of the motor shaft.
3. Unscrew one nut and remove the weight blades from that end of the shaft. The opposite nut will remain tight.

NOTE: 60Hz motors come with one weight blade already rotated at each end.

4. Place an adjustable wrench on the shaft flat. Make sure that the wrench does not grip the threaded area of the shaft. Use another wrench to unscrew the remaining nut. Remove the weight blades from the end of the shaft.




Figure 8-14 Vibrator Weight Adjustment, 60Hz, Steps 1-4

60Hz Motor Weight Adjustment (con't)

See Figure 8-15 for steps 5 - 8 when replacing or retrofitting a 60Hz vibratory table motor for the Encore Powder Feed Center.

5. Install the weight blades that were removed. Turn (2) weight blades on each shaft end to the opposite position as shown.
6. Make sure that the weight blades are in the same configuration at both ends of the motor. **Two** weight blades must be rotated at each end. Tighten both shaft nuts securely to 74-78 ft-lbs.
7. Install the end caps with the flat area on the cap aligned with the flat area on the mounting flange.
8. Tighten the screws to 4 ft-lbs.




Figure 8-15 Vibrator Weight Adjustment, 60 Hz, Steps 5-8

50Hz Motor Weight Adjustment

See Figure 8-16 for steps 1 - 4 when replacing or retrofitting a 50Hz vibratory table motor for the Encore Powder Feed Center.

FC 75% = 1 blade turned

50Hz = 145.5 lb. FC X 75% = 109.125 lb. FC

1. Remove the caps from both ends of the motor.
2. Place wrenches on the nuts located on both ends of the motor shaft.
3. Unscrew one nut and remove the weight blades from that end of the shaft. The opposite nut will remain tight.

NOTE: 50Hz motors come with all of the weight blades rotated in the same direction.

4. Place an adjustable wrench on the shaft flat. Make sure that the wrench does not grip the threaded area of the shaft. Use another wrench to unscrew the remaining nut. Remove the weight blades from the end of the shaft.




Figure 8-16 Vibrator Weight Adjustment, 50Hz, Steps 1-4

50Hz Motor Weight Adjustment (con't)

See Figure 8-17 for steps 5 - 8 when replacing or retrofitting a 50Hz vibratory table motor for the Encore Powder Feed Center.

5. Install the weight blades that were removed. Turn (1) weight blade on each shaft end to the opposite position as shown.
6. Make sure that the weight blades are in the same configuration at both ends of the motor. ONE weight blade must be rotated at each end. Tighten both shaft nuts securely to 74-78 ft-lbs.
7. Install the end caps with the flat area on the cap aligned with the flat area on the mounting flange.
8. Tighten the screws to 4 ft-lbs.




Figure 8-17 Vibrator Weight Adjustment, 50Hz, Steps 5-8

Section 9

Parts

Introduction

To order parts, call the Nordson Industrial Coating Systems Customer Support Center at (800) 433-9319 or contact your local Nordson representative.

Using the Illustrated Parts List

Numbers in the Item column correspond to numbers that identify parts in illustrations following each parts list. The code NS (not shown) indicates that a listed part is not illustrated. A dash (—) is used when the part number applies to all parts in the illustration.

The number in the Part column is the Nordson Corporation part number. A series of dashes in this column (-----) means the part cannot be ordered separately.

The Description column gives the part name, as well as its dimensions and other characteristics when appropriate. Indentions show the relationships between assemblies, subassemblies, and parts.

- If you order the assembly, items 1 and 2 will be included.
- If you order item 1, item 2 will be included.
- If you order item 2, you will receive item 2 only.

The number in the Quantity column is the quantity required per unit, assembly, or subassembly. The code AR (As Required) is used if the part number is a bulk item ordered in quantities or if the quantity per assembly depends on the product version or model.

Letters in the Note column refer to notes at the end of each parts list. Notes contain important information about usage and ordering. Special attention should be given to notes.

Item	Part	Part	Part	Description	Quantity	Note
—	-----	—	—		—	
1	-----					
2						
Continued...						
NOTE: A. B. NS: Not Shown AR: As Required						

Powder Feed Center Parts

See Figure 9-1.

Item	Part	Description	Quantity	Note
—	-----	Encore Powder Feed Center Assembly	1	
1	1602304	• REGULATOR, air, 0.02 - 0.2 MPA, with gage	2	
2	1602947	• KIT, blowoff gun, Encore PFC	1	
3	1086213	• UNION, bulk, KQ2E16-00, 16 mm	3	
4	1091201	• TUBE, polyurethane, 16 mm OD	9	
5	1066079	• GROMMET, $\frac{3}{8}$ " lip style	3	
6	249461	• SOCKET, F, 8, 10 tube, pneumatic	6	
7	1099946	• PLUG, M, 8, 10 tube, pneumatic	6	




Figure 9-1 Powder Feed Center Parts

Lift Assembly Parts

See Figure 9-2.

Item	Part	Description	Quantity	Note
—	-----	Lift Module	1	
1	1602289	• GUIDE, V linear, feed center	1	
2	1602290	• PLATE, 3, lift carriage, with wheels	1	
3	-----	• TRUNNION SUPPORT BLOCK	1	
4	-----	• PLATE, lift stop	1	
5	1602292	• BEARING, IGUS	2	
6	345439	• SCREW, socket, M16 x 2.0 x 50, zinc	1	
7	984697	• NUT, hex, jam, M16 x 2.0, steel, zinc	1	
8	1602342	• SCREW, socket, M8 x 1.25 x 75, zinc	4	
9	982160	• SCREW, socket, M8 x 1.25 x 25, zinc	4	
10	1602802	• SCREW, socket, M10 x 1.50 x 20, steel, zinc	6	
11	982926	• SCREW, socket, M8 x 12, steel, zinc	2	
–	-----	Lift Cylinder Module	1	
12	1602294	• CYLINDER, locking, 63 x 600 mm, Festo	1	
13	-----	• CLEVIS, Festo rod, M16	1	
14	1603063	• VALVE, flow control, .38 Rc x 6 T, meter out	2	
15	1103505	• SWITCH, cylinder proximity	3	
16	972837	• ELBOW, male, 6 mm tube x 1/8 BSPT	1	
17	-----	• TRUNNION FLANGE, Festo	1	
18	982160	• SCREW, socket, M8 x 1.25 x 25, zinc	4	




Figure 9-2 Lift Assembly Parts

Lance Assembly Parts

Basic Lance Parts

See Figure 9-3. For a complete lance assembly, order either a fluidizing or non-fluidizing latch block module listed on the following pages.

Item	Part	Description	Quantity	Note
—	1099893	LANCE ASSEMBLY, global PFC	1	
1	1099891	• ROD, pump retaining	1	
2	-----	• NUT, hex, acorn, M8	4	
3	-----	• WASHER, lock, split, M8, steel, zinc	4	
4	-----	• WASHER, flat, regular, M8, steel, zinc	8	
5	-----	• SCREW, hex, cap, M8 x 1.24, 50, F.T	4	
6	-----	• WASHER, lock, external, M5, steel, zinc plate	2	
7	-----	• SCREW, hex, serrated, M5 x 12, steel, zinc	1	
8	-----	• SCREW, socket, M10 x 25 mm	4	
9	-----	• WASHER, lock, split, M8, steel, zinc	4	
10	1095926	PUMP ASSEMBLY, corona, Encore Gen II, pkg	AR	A

NOTE: A. Refer to pump manual for repair parts. Pumps must be ordered separately
AR: As Required




Figure 9-3 Basic Lance Assembly Parts Lance Assembly Parts

Fluidizing Latch Block Kits

See Figure 9-4. Use these kits to fluidize the powder around the lance assembly. These kits are typically used with non-fluidized powder sources such as boxes.

Item	Part	Description	Quantity	Note
1	1102803	KIT, fluidizing manifold, PFC	1	
1A	-----	• CONNECTOR, male, 6 mm tube x 1/4 BSPT	1	
1B	-----	• NUT, adapter, lance air tube	1	
1C	941113	• O-RING, silicone, 0.424 in. ID x 0.103 in. wide	2	
1D	-----	• NUT, air passage blanking	1	
1E	-----	• SLEEVE, locating, global PFC lance	2	
2	1102804	KIT, fluidizing tube, PFC	1	
2A	940142	• O-RING, silicone, 0.489 in. ID x 0.07 in. wide	4	
2B	-----	• TUBE, fluidizing, stainless steel	2	




Figure 9-4 Basic Lance Assembly Parts

Lance Port Plug Module

See Figure 9-5. Use this module to plug unused lance ports. The module includes all the parts shown.

Item	Part	Description	Quantity	Note
–	1100097	MODULE, plug, lance assembly port	1	
1	-----	• NUT, hex, acorn, M8	1	
2	-----	• NUT, hex, M8, steel, zinc	1	
3	-----	• WASHER, sealing, lance plug, global PFC	1	
4	-----	• SLEEVE, lance plug, global PFC	1	
5	-----	• ROD, threaded, lance plug, GPFC		
6	-----	• PLUG, lance, global PFC	1	
7	-----	• SCREW, set, cup point, M12 x 1.75, 12mm long, stainless steel	1	




Figure 9-5 Lance Port Plug Module Parts

Level Sensor Module

See Figure 9-6. Use this module for the lance-mounted level sensor used in North America and Asia.

Item	Part	Description	Quantity	Note
–	1100078	MODULE, level sensor, North America and Asia	1	
1	1014553	• SENSOR, level, quick disconnect, M12	1	
2	1023925	• CABLE, 4 pin, M12 connector, 5 meters long	1	
3	-----	• SCREW, socket, M5 x 16, zinc	2	
4	-----	• NUT, lock, M5	2	
5	-----	• BRACKET, level sensor	1	
6	1100076	• SUPPORT, 16 mm shaft, clamping	1	




Figure 9-6 Level Sensor Module Parts

Prodigy/Encore HD Siphon Tube Module

See Figure 9-7. Use this module to provide powder to Prodigy or Encore HD manual guns through 8-mm tubing.

Item	Part	Description	Quantity	Note
–	1100131	MODULE, global PFC	1	
1	1100137	• SIPHON TUBE, global PFC	1	
2	-----	• SCREW, cap, button head socket, M4, 10 mm, steel, zinc plated	2	
3	-----	• HOLDER, tool, spring type	2	
4	-----	• NUT, lock, nylon, M4 steel, zinc	2	
5	-----	• BRACKET, siphon, global PFC	1	




Figure 9-7 Prodigy/Encore HD Siphon Module Parts

Purge Manifold and Pneumatics

Purge Manifold Assembly

See Figure 9-8. Quantities listed as As Required are dependent on the number of purge manifolds.

Item	Part	Description	Quantity	Note
–	1613398	KIT, cylinder, clamping, global PFC	—	
1	-----	• CYLINDER, air, 40 x 160, SMC	1	
2	-----	• SWITCH, cylinder proximity sensor	2	
3	-----	• CLAMP, proximity sensor, 40 mm ID	2	
4	-----	• ADAPTER, PFC, clamp, cylinder to clevis	1	
5	-----	• SET SCREW, socket, M10 x 1, cup	2	
6	-----	• CLEVIS, cylinder, 12mm rod, M12 x 1.25	2	
7	-----	• FITTING, flow control, ¼R	2	
8	-----	MANIFOLD, purge, global PFC	AR	
9	1100024	• QUAD RING, 208 silicone	9	
10	1100023	• GUIDE, lance, global PFC	2	
11	-----	SCREW, flat head, M8 x 16 mm, black	4	
12	1100036	BEARING, 14 mm, plain, flanged	4	
13	1100025	LATCH, complete, 890N, modified	AR	
14	1100028	• PAWL, latch, global PFC	AR	
15	-----	SCREW, button head, socket, M5 x 10, zinc	AR	
16	-----	SCREW, socket, M8 x 40, zinc, full thread	4	
17	-----	WASHER, flat, regular, M8, steel, zinc	4	
18	-----	SCREW, socket, M8 x 16mm, zinc	AR	
19	-----	ELBOW, push in, 0.50 RPT x 16 mm tube	AR	
20	-----	WASHER, lock, internal/external tooth, 5/16 in.	AR	
21	-----	SCREW, pan, slotted, M5 x 20, brass	2	
22	-----	WASHER, lock, external, M5, steel, zinc	4	
23	-----	WASHER, flat, M5, brass	4	
AR: As Required				




Figure 9-8 Purge Manifold Module Parts

Purge Valve Assembly - One Lance Configuration

See Figure 9-9.

Item	Part	Description	Quantity	Note
1	-----	NIPPLE, pipe, std, R.5, close	1	
2	-----	ELBOW, push in, 0.5 RPT x 16 mm tube	1	
3	972770	TUBE FITTING, conn., M, 37 degree, 3/4 T, 1/2 NPT	1	
4	-----	TEE, pipe, 1/2 BSPT, black	1	
5	1100283	VALVE, solenoid, air, 2 x 3, G.5	1	
6	-----	BRACKET, purge valve	1	
7	-----	SCREW, hex, serrated, M5 x 12, steel, zinc	2	
8	-----	PLUG, pipe, socket, flush, R 1/2	1	
9	1606921	CABLE, valve, purge, 5 m	1	
10	1102678	SILENCER, air, 3/8 Rc	1	
11	-----	SCREW, hex,serrated, M6 X 16, steel, zinc	1	
12	-----	NUT, hex, flanged, serrated, M6	1	




Figure 9-9 Purge Valve Assembly - One Lance Configuration

Purge Valve Assembly - Two Lance Configuration

See Figure 9-10.

Item	Part	Description	Quantity	Note
1	-----	NIPPLE, pipe, std, R.5, close	2	
2	-----	ELBOW, push in, 0.5 RPT x 16 mm tube	2	
3	972770	TUBE FITTING, conn., M, 37 degree, 3/4 T, 1/2 NPT	1	
4	-----	TEE, pipe, 1/2 BSPT, black	2	
5	1100283	VALVE, solenoid, air, 2 x 3, G.5	2	
6	-----	BRACKET, purge valve	2	
7	-----	SCREW, hex, serrated, M5 x 12, steel, zinc	4	
8	-----	PLUG, pipe, socket, flush, R 1/2	1	
9	1606921	CABLE, valve, purge, 5 m	2	
10	1102678	SILENCER, air, 3/8 Rc	2	
11	-----	NIPPLE, pipe, std, R1/2 x 3 long	1	
12	-----	SCREW, hex,serrated, M6 X 16, steel, zinc	2	
13	-----	NUT, hex, flanged, serrated, M6	2	




Figure 9-10 Purge Valve Assembly - Two Lance Configuration

Purge Valve Assembly - Three Lance Configuration

See Figure 9-11.

Item	Part	Description	Quantity	Note
1	-----	NIPPLE, pipe, std, R.5, close	3	
2	-----	ELBOW, push in, 0.5 RPT x 16 mm tube	3	
3	972770	TUBE FITTING, conn., M, 37 degree, 3/4 T, 1/2 NPT	1	
4	-----	TEE, pipe, 1/2 BSPT, black	3	
5	1100283	VALVE, solenoid, air, 2 x 3, G.5	3	
6	-----	BRACKET, purge valve	2	
7	-----	SCREW, hex, serrated, M5 x 12, steel, zinc	4	
8	-----	PLUG, pipe, socket, flush, R 1/2	1	
9	1606921	CABLE, valve, purge, 5 m	3	
10	1102678	SILENCER, air, 3/8 Rc	3	
11	-----	NIPPLE, pipe, std, R1/2 x 3 long	2	
12	-----	SCREW, hex,serrated, M6 X 16, steel, zinc	2	
13	-----	NUT, hex, flanged, serrated, M6	2	




Figure 9-11 Purge Valve Assembly - Three Lance Configuration

Purge Valve Module Parts

See Figure 9-12.

Item	Part	Description	Quantity	Note
1	1604501	UNION, bulk, KQ2E16-00 16 mm tube	3	
2	-----	GRIP, cord, 2X, 2.5-3 mm, 3/8 in. NPT, Nylon	AR	
3	-----	GRIP, cord, 2X, 5-6 mm, 1/2 in. NPT, Nylon	AR	
4	-----	ELBOW, plug in, 16 mm T x 16 mm T	3	

AR: As Required




Figure 9-12 Purge Valve Module Parts

Pneumatic Module Parts

See Figure 9-13. Refer to the 11 x 17 foldouts at the end of this manual for the pneumatic diagram.

Item	Part	Description	Quantity	Note
1	1099413	REGULATOR, 0.3–7 bar, .25	3	
2	1605532	CONNECTOR, male, elbow, 6MM T X R1/4	6	
3	1615160	VALVE, 9-station, Encore PFC	1	
4	1099424	VALVE, air, global PFC main interlock	1	
5	1606921	CABLE, valve, purge, 5 m	1	
6	-----	ELBOW, 1 in. BSPT x 3/4 JIC	1	
7	1102676	GAUGE, air, 0–150 psi, rear 1/4 G thread	4	
8	1100285	REGULATOR, air, 1 in., 0.5–12 bar	1	
9	-----	MANIFOLD, Encore PFC, pneumatic	1	
10	148256	PLUG, 10 mm, tubing	2	
11	-----	ELBOW, 3 port, 10 mm tube x 3/8 R	2	
12	-----	VENT, breather, 3/8 BSPT, sintered	3	
13	1101992	NIPPLE, close, 1 in., (4788K416)	2	
14	241040	MUFFLER, air 1/8 NPT	1	
15	1604113	VALVE, airpilot, 2-way	1	
16	-----	ELBOW, 6mm tube x 1/8 RPT	1	




Figure 9-13 Pneumatic Module Parts

Hopper Platform and Vibrator Parts

See Figure 9-14.

Item	Part	Description	Quantity	Note
1	1602109	VIBRATOR, 230/460V, 3 phase, 60 Hz	1	A
1	1602896	VIBRATOR, 330/575V, 3 phase, 60 Hz	1	A
1	1602895	VIBRATOR, 200/400V, 3 phase, 50 Hz, ATEX	1	A
1	1602894	VIBRATOR, 220/380V, 3 phase, 50 Hz	1	A
1	1602893	VIBRATOR, 220/380V, 3 phase, 60 Hz	1	A
1	1602892	VIBRATOR, 240/415V, 3 phase, 50 Hz	1	A
2	-----	SCREW, flat head, socket, M8 x 35, black	2	
3	-----	SCREW, hex, serrated, M8 x 35, steel, zinc	2	
4	1099588	MOUNT, vibration, isolator	4	
5	-----	SCREW, hex, serrated, M8 x 16, steel, zinc	8	
6	-----	NUT, hex, flanged, serrated, M8	8	
7	-----	NUT, hex, machine, M5, brass	1	
8	-----	WASHER, lock, external, M5, steel, zinc	2	
9	-----	JUMPER, ground, 12 in.	1	
10	-----	TAG, ground	1	
11	-----	SCREW, pan head, slotted, M5 x 20, brass	1	
12	-----	SCREW, hex, serrated, M6 x 16, steel, zinc	8	
13	-----	STRAIN RELIEF, cable, 1/2 NPT	1	
14	-----	CABLE, SO, 4C, 16 gauge	AR	
15	-----	POSITIONER, feed center hopper	2	
16	1068715	WASHER, lock, dished, #10	1	

NOTE: A. Check the identification plate on your existing motor before ordering. Before installing, verify the correct weight adjustment to ensure proper operation. Refer to the Repair section for instructions

AR: As Required




Figure 9-14 Hopper Platform and Vibrator Parts

Pneumatic Damper Parts

See Figure 9-15.

Item	Part	Description	Quantity	Note
1	1602175	Cylinder, feed center damper	1	
2	1602786	Rod end, damper cylinder	1	
3	1107595	Valve, flow control, 6 mm tube x 1/8 in. unithread	2	
4	-----	Screw, hex, cap, M8 x 25, zinc	2	
5	-----	Nut, hex, jam, M8, steel, zinc	2	




Figure 9-15 Pneumatic Damper Parts

Sieve and Mounting Parts

Replacement Parts for Non-CE/ATEX Sieve 1

See Figure 9-16 for Sieve 1 latch style. See Figure 9-18 for parts.

Screens

Item	Part	Description	Note
1	1603634	Screen, sieve, vibratory, 15 in., 20 mesh (841 microns)	
1	1604110	Screen, sieve, vibratory, 15 in., 30 mesh (595 microns)	
1	1603635	Screen, sieve, vibratory, 15 in., 40 mesh (400 microns)	
1	1603636	Screen, sieve, vibratory, 15 in., 60 mesh (250 microns)	

Vibrator Motors

Item	Part	Description	Note
2	1603628	Vibrator, sieve, 230/460V, 60 Hz, 3 phase	
2	1603629	Vibrator, sieve, 330/575V, 60 Hz, 3 phase	
2	1603630	Vibrator, sieve, 220/380/415V, 50 Hz, 3 phase	
2	1603631	Vibrator, sieve, 220/380V, 60 Hz, 3 phase	
2	1603632	Vibrator, sieve, 200/346V, 50 Hz, 3 phase	

Miscellaneous Parts

Item	Part	Description	Quantity	Note
3	1603633	Gasket, screen, sieve, 15 in.	1	A
4	1603637	Latch, sieve, toggle	2	
4A	1626399	Spindle, PTFE Pad	AR	
5	1017602	Mount, isolation, sieve	4	
6	1104897	Cap, vinyl, 3/4-13/16, black	AR	
7	1070199	Plug, hopper fill, NHR	1	
8	-----	Clip, ground, sieve screen	0	B

NOTE: A. The screen gasket is made from a conductive material. DO NOT replace it with a non-conductive gasket.

B. Ground clip is required only for systems using Sieve 2.

AR: As Required



Figure 9-16 Latch, Sieve 1

Replacement Parts for Non-CE/ATEX Sieve 2

See Figure 9-17 for Sieve 2 latch style. See Figure 9-18 for parts.

Screens

Item	Part	Description	Quantity
1	1056563	Screen, 20 mesh (864 micron)	1
1	-----	Screen, 30 mesh (595 microns)	1
1	1014561	Screen, 40 mesh (381 micron)	1
1	1014562	Screen, 60 mesh (234 micron)	1

Vibrator Motors

Item	Part	Description	Quantity
2	1060113	Motor, vibrator, 230/460, 3 phase, 60 Hz	1
2	1060114	Motor, vibrator, 220/380, 3 phase, 50 Hz	1

Miscellaneous Parts

Item	Part	Description	Quantity	Note
3	1014563	Gasket, screen, sieve, 15 in.	1	
4	-----	Latch, sieve, toggle	2	
4A	1626399	Spindle, PTFE Pad	AR	
5	1017602	Mount, isolation, sieve	1	
6	1104897	Cap, vinyl, 3/4-13/16, black	AR	
7	1070199	Plug, hopper fill, NHR	1	
8	1104478	Clip, ground, sieve screen	1	A

NOTE: A. Ground clip is required only for systems using Sieve 2.



Figure 9-17 Latch, Sieve 2




Figure 9-18 Sieve Parts (Sieve with Angled Chute Shown)

Pneumatic Damper Parts

See Figure 9-19.

Item	Part	Description	Quantity	Note
1	249461	Socket, female, 8 mm, 10 tube, pneumatic	1	
2	249455	Plug, male, 8mm, 10 tube, pneumatic	1	
3	1100200	Plate, powder hose bulkhead, PFC	AR	
4	1100047	Screw, button head, socket, M6 x 12, zinc	AR	

AR: As Required




Figure 9-19 Powder Hose and Pump Air Bulkhead Fittings

Other Service Parts

Powder Transfer Tubing and Grommets

Part	Description	Note
1063654	Tubing, polyethylene, 16 mm OD, natural	
1066079	Grommet, lip style, 3/8 in.	
1100320	Plug, dome, 35 mm, (1.38 in.), Nylon	
1086213	Union, bulkhead, 16 mm	

Air Tubing and Fittings

Part	Description	Min. Quantity
900742	Tubing, polyurethane, 6 mm OD, blue	50
900618	Tubing, polyurethane, 8 mm OD, blue	50
900619	Tubing, polyurethane, 8 mm OD, black	50
900740	Tubing, polyurethane, 10 mm OD, blue	50
900613	Tubing, polyurethane, 12 mm OD, blue	50
183804	Plug, blanking, 6 mm tube	–
972930	Plug, push in, 8 mm tube, plastic	–
148256	Plug, 10 mm, tubing	–

Miscellaneous Parts

Part	Description	Note
1071873	Hopper, square, 50 lb	A
7404027	Hopper, rectangular, 75 lb	A
NOTE: A. Refer to Options for service parts		

Fittings for Transfer Pump Air

Use these fittings to supply air from the control manifold to the HDLV transfer pump when runs are greater than 25 ft. or when dual reclaim transfer pumps are used. Refer to Installation for diagrams

Part	Description	Note
1106371	Valve, straight fitting, 10 mm, Festo	
7404027	Fitting, Y-branch, 10mm plug-in x 10 mm tube	
1070536	Fitting, straight, 10 mm tube – 8 mm tube	

Section 10

Options

Introduction

This section contains information about options available for the Encore Powder Feed Center. Contact your Nordson representative for more information about the options listed in this section.

75-lb Feed Hopper

See Figure 10-1.

Item	Part	Description	Quantity	Note
–	7404027	Hopper, fluidizing, powder feed center, 75 lbs	1	
1	-----	• Lid, hopper, PFC	1	
2	-----	• Body, hopper, PFC	1	
3	—	• Plenum, hopper	1	
4	—	• Connector, 10 mm tubing x 1/2 in. NPT	1	
–	1086406	• Kit, service, fluidizing hopper, PFC		
5	-----	• • Fluid plate, hopper, PFC	1	
6	7404175	• • Gasket, hopper, PFC	1	
7	-----	• • Nut, hex, M6, nylon	40	
8	-----	• • Washer, flat, M6, nylon	80	
9	-----	• • Screw, hex, M6 x 40, Nylon	40	
NS	1043414	Cart, fluidizing hopper	1	A
NS	1051364	Kit, handle, cart, fluidizing hopper	1	B

NOTE: A. The optional cart allows the fluidizing hopper to be transported easily.
B. Order this kit to install a handle on the hopper cart.

AR: As Required




Figure 10-1 75-lb Feed Hopper Parts

50-lb Feed Hopper

See Figure 10-2.

Item	Part	Description	Quantity	Note
–	1071873	Hopper, 18 x 18 x 17.5 in., 50 lbs	1	
1	-----	• Lid, hopper	1	
2	-----	• Body, hopper	1	
3	1071872	• Plate, fluidizing, 0.50 x 18 x 18 in.	1	
4	-----	• Plenum, hopper	1	
5	-----	• Gasket, Buna-N, 3/16 in. diameter	2	
6	971103	• Connector, 10 mm tubing x 1/2 in. unithread	1	
7	-----	• Screw, hex head, 3-16 UNC x 1.5 in.	32	




Figure 10-2 50-lb Feed Hopper Parts

Vibrasonic Sieve Screen

The Vibrasonic system increases sieve screen life and powder throughput, by applying an ultrasonic frequency to the screen. The ultrasonic frequency breaks down the surface tension in the screen, preventing blinding.

System Components

See Figure 10-3.




Figure 10-3 Vibrasonic System Components

- | | | |
|--------------------------|--------------------------|-----------------|
| 1. Vibrasonic controller | 5. Sieve deck | 9. Sieve pan |
| 2. Control cable | 6. Vibrasonic transducer | 10. Plug |
| 3. Bulkhead connector | 7. Sieve screen | 11. U-gasket |
| 4. Vibrasonic cable | 8. Cap screw | 12. Ground clip |

Installation



WARNING: Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.



WARNING: Turn off and lock out system electrical power before performing the following tasks. Failure to observe this warning may result in personal injury or equipment damage.

NOTE: Inspect all Vibrasonic system components for cleanliness and damage. Contact your Nordson representative if any components are damaged.

Vibrasonic Transducer and Sieve Screen Installation

1. See Figure 10-3. Clean the sieve screen's (7) center hub and the bottom of the transducer (6) with acetone.

NOTE: The transducer must be secured to the flat side of the sieve screen hub.

2. Place the transducer on the center hub of the sieve screen. Hand tighten the cap screw (8) through the bottom of the sieve screen.
3. Hold the base of the transducer with the supplied pin wrench and turn the cap screw with the supplied torque wrench until you hear a click.
4. Install the U-gasket (11) and ground clip (12) on the screen.
5. Set the sieve screen into the vibratory sieve (9). Plug the transducer cable (4) into the transducer, route the cable through the sieve deck (5), then clamp the sieve deck onto the sieve pan.
6. Slide the transducer cable through the slit in the plug (10), then install the plug into the sieve deck.

Controller and Cable Installation

1. See Figure 10-3. Make sure that the voltage selector on the controller (1) is set to your system's electrical supply specification.
2. Mount the controller above the powder feed center electrical panel as shown in Figure 2-9.
3. Connect the control cable (2) to the controller. Route the other end to the feed center roof.
4. Mount the bulkhead connector (3) in the feed center roof, then route the transducer cable (4) to the bulkhead connector and plug it in.

Operation

To turn on the Vibrasonic system, turn the red switch on the controller clockwise 90 degrees. The POWER and VIBRASONICS indicators on the controller will light. The five LEDs on the controller door are used for troubleshooting. During operation, LED 1 will light to indicate normal operation.

Troubleshooting

These procedures cover only the most common problems that you may encounter. If you cannot solve the problem with the information given here, contact your local Nordson representative for help.

Fault Conditions

Refer to Table 10-1 for a description of operating conditions indicated by the LEDs and indicators.

Refer to the Troubleshooting Procedures on the following pages to identify and correct error conditions indicated in Table 10-1.

Table 10-1 LED Functions

Condition	POWER Indicator	VIBRASONICS Indicator	LED 1	LED 2	LED 3	LED 4	LED 5
Normal	On	On	On	Off	Off	Off	Off
Under Voltage	On	On or Off	Off	On	Off	Off	Off
Over Voltage	On	On	Off	Off	On	Off	Off
Open Circuit	On	Flashing	Off	On	Off	On	Off
Short Circuit	On	On	Off	On	Off	Off	On

Electrical Troubleshooting Procedures

Use the following chart to correct faults conditions indicated by the LEDs

Condition	POWER Indicator	VIBRASONICS Indicator
1. Under voltage (output voltage too low)	Supply voltage too low	Increase the supply voltage.
	Sieve screen center hub bonding damaged	Replace the sieve screen.
	Damaged generator	Contact the Vibrasonic system manufacturer.
2. Under voltage (output voltage too low)	Poor contact surfaces between transducer and sieve screen	Remove the transducer from the screen and clean the mating surfaces with acetone. Assemble the transducer to the screen using the Vibrasonic Transducer and Sieve Screen Installation procedure.
	Loose transducer	Tighten the transducer using the supplied torque wrench. Refer to the Vibrasonic Transducer and Sieve Screen Installation procedure.
	Damaged sieve screen mating surface	Replace the sieve screen.
	Damaged transducer mating surface	Replace the transducer.
3. Under voltage (output voltage too low)	Disconnected transducer cable	Check the transducer cable connections.
	Damaged control cable or connector	Replace the control cable.
	Loose or damaged wiring in the controller	Check the controller wiring. Tighten any loose connections.
	Damaged transducer	Replace the transducer.
4. Under voltage (output voltage too low)	Short circuit in control cable	Replace the control cable.
	Short circuit in either control or transducer cable connectors	Thoroughly clean the connectors.
	Short circuit in transducer	Replace the transducer.

VIBRASONICS/POWER Indicator Troubleshooting

Use the following chart to correct fault conditions indicated by the POWER and VIBRASONICS indicators.

Indicator Status	Possible Cause	Corrective Action
POWER: on VIBRASONICS: off	Faulty indicator bulb	Check the indicator light bulb and replace if necessary.
	Loose cable connection	Check all cable connections.
	Poor contact surfaces between transducer and sieve screen	Remove the transducer from the screen and clean the mating surfaces with acetone. Assemble the transducer to the screen using the Vibrasonic Transducer and Sieve Screen Installation procedure.
POWER: off VIBRASONICS: off	Controller power is off	Turn on power to the controller.
	Circuit breaker tripped	Open the controller and reset the miniature circuit breaker.
	Faulty indicator bulbs	Check the indicator light bulbs and replace if necessary.
POWER: off VIBRASONICS: on	Faulty indicator bulb	Check the indicator light bulb and replace if necessary.
POWER: on VIBRASONICS: flashing	Break in continuity or change in polarity in control or transducer cable	Turn off controller power and check the transducer cap screw for the proper torque. Turn on controller power and check indicators. If the condition persists, replace the cables.

Vibrasonic System Parts

See Figure 10-4.

Item	Part	Description	Quantity	Note
—	1103009	System, Vibrasonic, with interface card	1	
1	-----	• Box, control, Vibrasonic	1	
2	-----	• Cable, 4-meter, with support bracket	1	
3	-----	• Cable, transducer	1	
4	-----	• Transducer, Vibrasonic	1	
5	1014565	• Screen, Vibrasonic, 80 mesh (178 micron)	1	A
5	1090890	• Screen, Vibrasonic, 100 mesh (140 micron)		A
6	1014563	• • Gasket	1	
7	-----	• Screw, cap, socket head, M8	1	
8	1104478	Clip, ground, sieve screen	1	
9	1103290	Plug, sieve	1	

NOTE: A. Other mesh sizes are available. Contact your Nordson representative for more information.




Figure 10-4 Vibrasonic System Parts

Section 11

Pneumatic and Electrical Diagrams




Figure 11-1 Encore Feed Center Pneumatic Schematic



ALL DIMENSIONS IN INCHES EXCEPT AS NOTED		D SIZE		NORDSON CORPORATION POWDER SYSTEMS GROUP, AMHERST, OHIO, 44001			
X +/ - .030		X.XXX +/ - .010		DRAWN BY BGZ		DATE 21MAR19	
CHAINED SURFACES 125 AA		CHECKED BY		APPROVED BY		REF DWG. PANEL,FEED CENTER, ENCORE,NAD	
TAK OUTSIDE AND INSIDE DIMENS. .004 TO .032 MAX.		REL NO					
HEAD LENGTH DIMS. ARE L1 L2 L3 L4 L5 L6 L7 L8 L9 L10 L11 L12 L13 L14 L15 L16 L17 L18 L19 L20 L21 L22 L23 L24 L25 L26 L27 L28 L29 L30 L31 L32 L33 L34 L35 L36 L37 L38 L39 L40 L41 L42 L43 L44 L45 L46 L47 L48 L49 L50 L51 L52 L53 L54 L55 L56 L57 L58 L59 L60 L61 L62 L63 L64 L65 L66 L67 L68 L69 L70 L71 L72 L73 L74 L75 L76 L77 L78 L79 L80 L81 L82 L83 L84 L85 L86 L87 L88 L89 L90 L91 L92 L93 L94 L95 L96 L97 L98 L99 L100 L101 L102 L103 L104 L105 L106 L107 L108 L109 L110 L111 L112 L113 L114 L115 L116 L117 L118 L119 L120 L121 L122 L123 L124 L125 L126 L127 L128 L129 L130 L131 L132 L133 L134 L135 L136 L137 L138 L139 L140 L141 L142 L143 L144 L145 L146 L147 L148 L149 L150 L151 L152 L153 L154 L155 L156 L157 L158 L159 L160 L161 L162 L163 L164 L165 L166 L167 L168 L169 L170 L171 L172 L173 L174 L175 L176 L177 L178 L179 L180 L181 L182 L183 L184 L185 L186 L187 L188 L189 L190 L191 L192 L193 L194 L195 L196 L197 L198 L199 L200 L201 L202 L203 L204 L205 L206 L207 L208 L209 L210 L211 L212 L213 L214 L215 L216 L217 L218 L219 L220 L221 L222 L223 L224 L225 L226 L227 L228 L229 L230 L231 L232 L233 L234 L235 L236 L237 L238 L239 L240 L241 L242 L243 L244 L245 L246 L247 L248 L249 L250 L251 L252 L253 L254 L255 L256 L257 L258 L259 L260 L261 L262 L263 L264 L265 L266 L267 L268 L269 L270 L271 L272 L273 L274 L275 L276 L277 L278 L279 L280 L281 L282 L283 L284 L285 L286 L287 L288 L289 L290 L291 L292 L293 L294 L295 L296 L297 L298 L299 L300 L301 L302 L303 L304 L305 L306 L307 L308 L309 L310 L311 L312 L313 L314 L315 L316 L317 L318 L319 L320 L321 L322 L323 L324 L325 L326 L327 L328 L329 L330 L331 L332 L333 L334 L335 L336 L337 L338 L339 L340 L341 L342 L343 L344 L345 L346 L347 L348 L349 L350 L351 L352 L353 L354 L355 L356 L357 L358 L359 L360 L361 L362 L363 L364 L365 L366 L367 L368 L369 L370 L371 L372 L373 L374 L375 L376 L377 L378 L379 L380 L381 L382 L383 L384 L385 L386 L387 L388 L389 L390 L391 L392 L393 L394 L395 L396 L397 L398 L399 L400 L401 L402 L403 L404 L405 L406 L407 L408 L409 L410 L411 L412 L413 L414 L415 L416 L417 L418 L419 L420 L421 L422 L423 L424 L425 L426 L427 L428 L429 L430 L431 L432 L433 L434 L435 L436 L437 L438 L439 L440 L441 L442 L443 L444 L445 L446 L447 L448 L449 L450 L451 L452 L453 L454 L455 L456 L457 L458 L459 L460 L461 L462 L463 L464 L465 L466 L467 L468 L469 L470 L471 L472 L473 L474 L475 L476 L477 L478 L479 L480 L481 L482 L483 L484 L485 L486 L487 L488 L489 L490 L491 L492 L493 L494 L495 L496 L497 L498 L499 L500 L501 L502 L503 L504 L505 L506 L507 L508 L509 L510 L511 L512 L513 L514 L515 L516 L517 L518 L519 L520 L521 L522 L523 L524 L525 L526 L527 L528 L529 L530 L531 L532 L533 L534 L535 L536 L537 L538 L539 L540 L541 L542 L543 L544 L545 L546 L547 L548 L549 L550 L551 L552 L553 L554 L555 L556 L557 L558 L559 L560 L561 L562 L563 L564 L565 L566 L567 L568 L569 L570 L571 L572 L573 L574 L575 L576 L577 L578 L579 L580 L581 L582 L583 L584 L585 L586 L587 L588 L589 L590 L591 L592 L593 L594 L595 L596 L597 L598 L599 L600 L601 L602 L603 L604 L605 L606 L607 L608 L609 L610 L611 L612 L613 L614 L615 L616 L617 L618 L619 L620 L621 L622 L623 L624 L625 L626 L627 L628 L629 L630 L631 L632 L633 L634 L635 L636 L637 L638 L639 L640 L641 L642 L643 L644 L645 L646 L647 L648 L649 L650 L651 L652 L653 L654 L655 L656 L657 L658 L659 L660 L661 L662 L663 L664 L665 L666 L667 L668 L669 L670 L671 L672 L673 L674 L675 L676 L677 L678 L679 L680 L681 L682 L683 L684 L685 L686 L687 L688 L689 L690 L691 L692 L693 L694 L695 L696 L697 L698 L699 L700 L701 L702 L703 L704 L705 L706 L707 L708 L709 L710 L711 L712 L713 L714 L715 L716 L717 L718 L719 L720 L721 L722 L723 L724 L725 L726 L727 L728 L729 L730 L731 L732 L733 L734 L735 L736 L737 L738 L739 L740 L741 L742 L743 L744 L745 L746 L747 L748 L749 L750 L751 L752 L753 L754 L755 L756 L757 L758 L759 L760 L761 L762 L763 L764 L765 L766 L767 L768 L769 L770 L771 L772 L773 L774 L775 L776 L777 L778 L779 L780 L781 L782 L783 L784 L785 L786 L787 L788 L789 L790 L791 L792 L793 L794 L795 L796 L797 L798 L799 L800 L801 L802 L803 L804 L805 L806 L807 L808 L809 L810 L811 L812 L813 L814 L815 L816 L817 L818 L819 L820 L821 L822 L823 L824 L825 L826 L827 L828 L829 L830 L831 L832 L833 L834 L835 L836 L837 L838 L839 L840 L841 L842 L843 L844 L845 L846 L847 L848 L849 L850 L851 L852 L853 L854 L855 L856 L857 L858 L859 L860 L861 L862 L863 L864 L865 L866 L867 L868 L869 L870 L871 L872 L873 L874 L875 L876 L877 L878 L879 L880 L881 L882 L883 L884 L885 L886 L887 L888 L889 L890 L891 L892 L893 L894 L895 L896 L897 L898 L899 L900 L901 L902 L903 L904 L905 L906 L907 L908 L909 L910 L911 L912 L913 L914 L915 L916 L917 L918 L919 L920 L921 L922 L923 L924 L925 L926 L927 L928 L929 L930 L931 L932 L933 L934 L935 L936 L937 L938 L939 L940 L941 L942 L943 L944 L945 L946 L947 L948 L949 L950 L951 L952 L953 L954 L955 L956 L957 L958 L959 L960 L961 L962 L963 L964 L965 L966 L967 L968 L969 L970 L971 L972 L973 L974 L975 L976 L977 L978 L979 L980 L981 L982 L983 L984 L985 L986 L987 L988 L989 L990 L991 L992 L993 L994 L995 L996 L997 L998 L999 L1000 L1001 L1002 L1003 L1004 L1005 L1006 L1007 L1008 L1009 L1010 L1011 L1012 L1013 L1014 L1015 L1016 L1017 L1018 L1019 L1020 L1021 L1022 L1023 L1024 L1025 L1026 L1027 L1028 L1029 L1030 L1031 L1032 L1033 L1034 L1035 L1036 L1037 L1038 L1039 L1040 L1041 L1042 L1043 L1044 L1045 L1046 L1047 L1048 L1049 L1050 L1051 L1052 L1053 L1054 L1055 L1056 L1057 L1058 L1059 L1060 L1061 L1062 L1063 L1064 L1065 L1066 L1067 L1068 L1069 L1070 L1071 L1072 L1073 L1074 L1075 L1076 L1077 L1078 L1079 L1080 L1081 L1082 L1083 L1084 L1085 L1086 L1087 L1088 L1089 L1090 L1091 L1092 L1093 L1094 L1095 L1096 L1097 L1098 L1099 L1100 L1101 L1102 L1103 L1104 L1105 L1106 L1107 L1108 L1109 L1110 L1111 L1112 L1113 L1114 L1115 L1116 L1117 L1118 L1119 L1120 L1121 L1122 L1123 L1124 L1125 L1126 L1127 L1128 L1129 L1130 L1131 L1132 L1133 L1134 L1135 L1136 L1137 L1138 L1139 L1140 L1141 L1142 L1143 L1144 L1145 L1146 L1147 L1148 L1149 L1150 L1151 L1152 L1153 L1154 L1155 L1156 L1157 L1158 L1159 L1160 L1161 L1162 L1163 L1164 L1165 L1166 L1167 L1168 L1169 L1170 L1171 L1172 L1173 L1174 L1175 L1176 L1177 L1178 L1179 L1180 L1181 L1182 L1183 L1184 L1185 L1186 L1187 L1188 L1189 L1190 L1191 L1192 L1193 L1194 L1195 L1196 L1197 L1198 L1199 L1200 L1201 L1202 L1203 L1204 L1205 L1206 L1207 L1208 L1209 L1210 L1211 L1212 L1213 L1214 L1215 L1216 L1217 L1218 L1219 L1220 L1221 L1222 L1223 L1224 L1225 L1226 L1227 L1228 L1229 L1230 L1231 L1232 L1233 L1234 L1235 L1236 L1237 L1238 L1239 L1240 L1241 L1242 L1243 L1244 L1245 L1246 L1247 L1248 L1249 L1250 L1251 L1252 L1253 L1254 L1255 L1256 L1257 L1258 L1259 L1260 L1261 L1262 L1263 L1264 L1265 L1266 L1267 L1268 L1269 L1270 L1271 L1272 L1273 L1274 L1275 L1276 L1277 L1278 L1279 L1280 L1281 L1282 L1283 L1284 L1285 L1286 L1287 L1288 L1289 L1290 L1291 L1292 L1293 L1294 L1295 L1296 L1297 L1298 L1299 L1300 L1301 L1302 L1303 L1304 L1305 L1306 L1307 L1308 L1309 L1310 L1311 L1312 L1313 L1314 L1315 L1316 L1317 L1318 L1319 L1320 L1321 L1322 L1323 L1324 L1325 L1326 L1327 L1328 L1329 L1330 L1331 L1332 L1333 L1334 L1335 L1336 L1337 L1338 L1339 L1340 L1341 L1342 L1343 L1344 L1345 L1346 L1347 L1348 L1349 L1350 L1351 L1352 L1353 L1354 L1355 L1356 L1357 L1358 L1359 L1360 L1361 L1362 L1363 L1364 L1365 L1366 L1367 L1368 L1369 L1370 L1371 L1372 L1373 L1374 L1375 L1376 L1377 L1378 L1379 L1380 L1381 L1382 L1383 L1384 L1385 L1386 L1387 L1388 L1389 L1390 L1391 L1392 L1393 L1394 L1395 L1396 L1397 L1398 L1399 L1400 L1401 L1402 L1403 L1404 L1405 L1406 L1407 L1408 L1409 L1410 L1411 L1412 L1413 L1414 L1415 L1416 L1417 L1418 L1419 L1420 L1421 L1422 L1423 L1424 L1425 L1426 L1427 L1428 L1429 L1430 L1431 L1432 L1433 L1434 L1435 L1436 L1437 L1438 L1439 L1440 L1441 L1442 L1443 L1444 L1445 L1446 L1447 L1448 L1449 L1450 L1451 L1452 L1453 L1454 L1455 L1456 L1457 L1458 L1459 L1460 L1461 L1462 L1463 L1464 L1465 L1466 L1467 L1468 L1469 L1470 L1471 L1472 L1473 L1474 L1475 L1476 L1477 L1478 L1479 L1480 L1481 L1482 L1483 L1484 L1485 L1486 L1487 L1488 L1489 L1490 L1491 L1492 L1493 L1494 L1495 L1496 L1497 L1498 L1499 L1500 L1501 L1502 L1503 L1504 L1505 L1506 L1507 L1508 L1509 L1510 L1511 L1512 L1513 L1514 L1515 L1516 L1517 L1518 L1519 L1520 L1521 L1522 L1523 L1524 L1525 L1526 L1527 L1528 L1529 L1530 L1531 L1532 L1533 L1534 L1535 L1536 L1537 L1538 L1539 L1540 L1541 L1542 L1543 L1544 L1545 L1546 L1547 L1548 L1549 L1550 L1551 L1552 L1553 L1554 L1555 L1556 L1557 L1558 L1559 L1560 L1561 L1562 L1563 L1564 L1565 L1566 L1567 L1568 L1569 L1570 L1571 L1572 L1573 L1574 L1575 L1576 L1577 L1578 L1579 L1580 L1581 L1582 L1583 L1584 L1585 L1586 L1587 L1588 L1589 L1590 L1591 L1592 L1593 L1594 L1595 L1596 L1597 L1598 L1599 L1600 L1601 L1602 L1603 L1604 L1605 L1606 L1607 L1608 L1609 L1610 L1611 L1612 L1613 L1614 L1615 L1616 L1617 L1618 L1619 L1620 L1621 L1622 L1623 L1624 L1625 L1626 L1627 L1628 L1629 L1630 L1631 L1632 L1633 L1634 L1635 L1636 L1637 L1638 L1639 L1640 L1641 L1642 L1643 L1644 L1645 L1646 L1647 L1648 L1649 L1650 L1651 L1652 L1653 L1654 L1655 L1656 L1657 L1658 L1659 L1660 L1661 L1662 L1663 L1664 L1665 L1666 L1667 L1668 L1669 L1670 L1671 L1672 L1673 L1674 L1675 L1676 L1677 L1678 L1679 L1680 L1681 L1682 L1683 L1684 L1685 L1686 L1687 L1688 L1689 L1690 L1691 L1692 L1693 L1694 L1695 L1696 L1697 L1698 L1699 L1700 L1701 L1702 L1703 L1704 L1705 L1706 L1707 L1708 L1709 L1710 L1711 L1712 L1713 L1714 L1715 L1716 L1717 L1718 L1719 L1720 L1721 L1722 L1723 L1724 L1725 L1726 L1727 L1728 L1729 L1730 L1731 L1732 L1733 L1734 L1735 L1736 L1737 L1738 L1739 L1740 L1741 L1742 L1743 L1744 L1745 L1746 L1747 L1748 L1749 L1750 L1751 L1752 L1753 L1754 L1755 L1756 L1757 L1758 L1759 L1760 L1761 L1762 L1763 L1764 L1765 L1766 L1767 L1768 L1769 L1770 L1771 L1772 L1773 L1774 L1775 L1776 L1777 L1778 L1779 L1780 L1781 L1782 L1783 L1784 L1785 L1786 L1787 L1788 L1789 L1790 L1791 L1792 L1793 L1794 L1795 L1796 L1797 L1798 L1799 L1800 L1801 L1802 L1803 L1804 L1805 L1806 L1807 L1808 L1809 L1810 L1811 L1812 L1813 L1814 L1815 L1816 L1817 L1818 L1819 L1820 L1821 L1822 L1823 L1824 L1825 L1826 L1827 L1828 L1829 L1830 L1831 L1832 L1833 L1834 L1835 L1836 L1837 L1838 L1839 L1840 L1841 L1842 L1843 L1844 L1845 L1846 L1847 L1848 L1849 L1850 L1851 L1852 L1853 L1854 L1855 L1856 L1857 L1858 L1859 L1860 L1861 L1862 L1863 L1864 L1865 L1866 L1867 L1868 L1869 L1870 L1871 L1872 L1873 L1874 L1875 L1876 L1877 L1878 L1879 L1880 L1881 L1882 L1883 L1884 L1885 L1886 L1887							

LEGEND

△ - REMOTELY LOCATED DEVICE

⊙ - SYSTEM PANEL TERMINAL (SP)

○ - FEED CENTER CONTROL PANEL (FCP)



COLOR CHANGE ENABLE
TO SYSTEM PANEL


GUN INTERNAL CLEAN COMPLETE
TO SYSTEM PANEL


GUN MOVERS AT GUN PURGE POSITION
FROM SYSTEM PANEL

415

SPRAY BOOTH FAN RUN
FROM SYSTEM PANEL

224





01

X

X

X

X

ALL DIMENSIONS IN INCHES EXCEPT AS NOTED

D SIZE

NORDSON CORPORATION
POWDER SYSTEMS GROUP, AMHERST, OHIO, 44001

XXXXXX

X.XX +/- .030 X.XXX +/- .010

DRAWN BY BGZ

DATE 21MAR19

NEXT ASSEMBLY

MACHINED SURFACES $\sqrt{25}$ AA

CHECKED BY

APPROVED BY

FIRST PRODUCT USED ON XXXXXXXXXXXX

BREAK OUTSIDE AND INSIDE CORNERS .004 TO .032 MAX.

REL NO

INTERPRET DRAWINGS PER ANSI Y14.5M - 1994 STD.

THREAD LENGTH DIMS. ARE FULL THREAD

CONTROL NUMBER

10018963

REV. 09

PERFECT FORM AT MMC REQUIRED FOR INTERRELATED FEATURES

THIRD ANGLE PROJECTION




SCALE: 1:4

PRODUCT DEVELOPMENT DEPARTMENT
CAD GENERATED DRAWING

PAGE 5 / 6

NOTICE THIS DRAWING IS NORDSON PROPERTY, CONTAINS PROPRIETARY INFORMATION AND MUST BE RETURNED UPON REQUEST. DO NOT CIRCULATE, REPRODUCE OR DIVULGE TO OTHER PARTIES WITHOUT WRITTEN CONSENT OF NORDSON.

D



NOTES:

1. CUT TO CLOSEST CUT LINE TO LENGTH DIMENSION SHOWN
2. SOLDER 4 FT. OF #16GA STRANDED WIRE TO SOLDER PADS AS SHOWN
3. POT SOLDERED CONNECTIONS WITH ROOM TEMP. CURING ELECTRICAL INSULATING POTTING COMPOUND

WINDOW & LIGHT ASSEMBLY:
1. USE SDFT FOAM RUBBER GASKET MATERIAL (1/16" - 1/8 " THICK) BETWEEN LEXAN AND ENCLOSURE (ITEM 65).
2. USE A NYLON FLAT WASHER OR SEALING WASHER BETWEEN HEAD OF MOUNTING SCREW AND ENCLOSURE.
3. USE ZINC BUTTON HEAD SCREWS, 16 REQUIRED, WITH NUT, SEAL WASHER AND STAR WASHER..

A

01	X	X	X		X	X
ALL DIMENSIONS IN INCHES EXCEPT AS NOTED			D SIZE	NORDSON CORPORATION POWDER SYSTEMS GROUP, AMHERST, OHIO, 44001		
XXXXXX	X.XX	+/- .030	X.XXX	+/- .010	DRAWN BY BGZ	DATE 21MAR19
NOTICE ASSEMBLY	MACHINED SURFACES		125		CHECKED BY	APPROVED BY
FIRST PRODUCT USED ON XXXXXXX	BRK OUTSIDE AND INSIDE CORNERS .004 TO .032 MAX.		REL NO	REF DWG, PANEL,FEED CENTER, ENCORE,NAD		
INTERPRET DRAWINGS PER ANSI Y14.5 - 1974 STD.	THREAD LENGTH DIMS. ARE FULL THREAD		CONTROL NUMBER			10018963
PERFECT FORM AT MMC REQUIRED FOR INTERRELATED FEATURES	THIRD ANGLE PROJECTION 	SCALE: 1:1	PRODUCT DEVELOPMENT CAD GENERATED DRAWING	DEPARTMENT	PAGE 6 / 6	REV. 09