




Operating and maintenance manual



Machine

RECIPROCATOR

Model

HS _ _

Serial No./Year of manufacture

--



IMPORTER

CUSTOMER

.....
.....
.....
.....
.....
.....

All copy rights of this manual are reserved to **Nordson®**.

The text and the numbering system can not be used in any other form without written permission from **Nordson®**.


NB: descriptions and illustrations in this publication are simplified.

For eventual technical reasons **Nordson®** reserves the right to modify their product data or features without any prior notice.

TITLE OF THE DOCUMENT : OPERATING AND MAINTENANCE MANUAL	NO. :
	REVISION : 1.3

CUSTOMER :	JOB ORDER NO.:
SERIAL NO.:	DATE :

[illegible]

			
Prepared	Controlled	Approved	

CONTENTS

CHAPTER 0.0

INTRODUCTION

0.1	Document identification	Page	2
0.2	Object of the document	Page	2
0.3	General conditions	Page	2
0.4	Identification data of the manufacturer	Page	3
0.5	Nordson International	Page	4
0.6	How to read and use the "operating and maintenance manual"	Page	6
0.6.1	Symbols used in the manual	Page	7
0.7	Machine updates	Page	8
0.8	How to ask for further copies	Page	8
0.9	Responsibilities	Page	9

CHAPTER 1.0

TECHNICAL ASSISTANCE

CHAPTER 2.0

GENERAL SAFETY INSTRUCTIONS

2.1	Dangerous areas and placing of safety devices	Page	4
2.2	Placing of warning labels	Page	5
2.3	General prohibitions	Page	6
2.4	General obligations	Page	6
2.5	Dangers	Page	6
2.6	Advice about lighting	Page	6

CHAPTER 3.0

DESCRIPTION OF THE MACHINE

3.1	Terminology used	Page	3
-----	------------------	------	---

CHAPTER 4.0

TECHNICAL DATA

4.1	Weights and overall dimensions	Page	2
-----	--------------------------------	------	---

CHAPTER 5.0

IDENTIFICATION OF THE MACHINE

CHAPTER 6.0

FORESEEN AND UNFORESEEN USE OF THE MACHINE

6.1	Risidual risks	Page	2
-----	----------------	------	---

CHAPTER 7.0

MOVING AND TRANSPORT

7.1	Staff qualification	Page	3
7.2	Equipment and means to use	Page	3
7.3	Advice about lifting	Page	4
7.3.1	Lifting with ropes	Page	4
7.3.2	Lifting with machines	Page	5
7.4	Storage conditions	Page	5
7.5	Checking the machine	Page	5

CHAPTER 8.0

MACHINE INSTALLATION

8.1	Environmental conditions	Page	3
8.2	Need of free spaces	Page	3

CHAPTER 9.0

SETTING UP THE MACHINE

9.1	Connection of the reciprocator to the control module	Page	2
9.2.1	Assembly dispenser supports	Page	3
9.2.2	Machine balancing	Page	5
9.2.3	Checking of the maximum speed	Page	8

CHAPTER 10.0

BEFORE START UP

10.1	Staff qualification	Page	2
10.2	Foreseen control positions	Page	2
10.3	Control boards	Page	3
10.4	Stop-commands and their position	Page	4

CHAPTER 11.0

USE OF THE MACHINE

CHAPTER 12.0

MAINTENANCE

12.1	General safety advice	Page	2
12.2	Technical competences	Page	2
12.3	Periodical maintenance table	Page	3
12.4	Summery table of suggested spare parts	Page	4
12.5	Replacing gear-motor	Page	5
12.6	Pulley replacement	Page	12
12.7	Replacement of position sensor	Page	22
12.8	Adjustment of supporting-gun sliding blocks	Page	25
12.9	Replacement of supporting-gun sliding blocks	Page	29
12.10	Adjustment of counterweight	Page	34

12.11	Replacement of counterweight sliding blocks	Page	36
12.12	Replacement of snub pulley	Page	40
12.13	Maximum stroke adjustment of gun supporting arm	Page	49
12.14	Belt replacement	Page	51
12.15	Toothed belt tension adjustment	Page	65

CHAPTER 13.0

ALARMS

CHAPTER 14.0

SPARE PARTS

14.1	General advice	Page	2
14.2	How to order spare parts	Page	3

CHAPTER 15.0

DRAINING OF HARMFUL SUBSTANCES AND DISMANTLING THE MACHINE

CHAPTER 16.0

ATTACHED

- ☐ CE plate
- ☐ Declaration of conformity
- ☐ Wiring diagrams
- ☐ Recommended oils

CHAPTER 17.0

PERSONALIZATION/ SPECIAL EXECUTIONS

17.1	Additional handle for manual movement	Page	2
------	---------------------------------------	------	---

	INTRODUCTION	REV. 1.3
---	---------------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

0.0 INTRODUCTION	Page 1 to 9
-------------------------	--------------------

0.1	Document identification	Page	2
0.2	Object of the document	Page	2
0.3	General conditions	Page	2
0.4	Identification data of the manufacturer	Page	2
0.5	Nordson International	Page	3
0.6	How to read and use the "operating and maintenance manual"	Page	5
0.6.1	Symbols used in the manual	Page	6
0.7	Machine updates	Page	7
0.8	How to ask for further copies	Page	7
0.9	Responsibilities	Page	8

CHAPTER 0.0 INTRODUCTION

0.1 Document identification

The operating and maintenance manual is a document issued by **Nordson®** against a specific job order and it is an integral part of the machine.

Such a document is marked with a serial number that corresponds to that of the machine, in order to permit tracing and identification.

All copy rights and distribution's rights of this manual and the relevant enclosed documents are reserved to Nordson®.

0.2 Object of the document

This manual sets out:

- To provide technicians, workers and maintenance people with instructions, information and advice on how to work in the best safety conditions.
- To put the worker in a position to use the machine correctly and safely and to maintain it in a good and efficient condition.
- To be able to prove, through the provided information, the compliance of the machine with the directives in force regarding industrial safety standards.

0.3 General conditions

During the drawing up of this document the following directives have been considered:

- UNI EN ISO 12100-1:2009, Safety of machinery - Basic concepts; general principles for design:
 - Part 1 - Basic terminology, methodology (UNI EN ISO 12100-1:2009)
 - Part 2 - Technical principles and specification (UNI EN ISO 12100-2:2009)
- UNI EN ISO 13849-1:2008, Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design
- UNI EN ISO 14121-1:2007, Safety of machinery - Principles or risk assessment - Part 1: Principles
- UNI EN ISO 13857:2008, Safety of machinery - Safety distances to prevent danger zones being reached by the upper and lower limbs
- UNI EN 349:1994 + A1:2008, Safety of machinery - Minimum gaps to avoid crushing of parts of the human body
- UNI EN ISO 13850:2008, Safety of machinery - Emergency stop equipment - Functional aspects - Principles for design
- CEI EN 60204-1:A1:2009, Safety of machinery - electrical equipment of the machines - Part 1: General rules



ATTENTION : If this machine is an integral part of a plant , it is forbidden to start it unless the whole plant is in compliance with the "**Machine directive**" **2006/42/CE** and those that follow.

0.4 Identification data of the manufacturer

The identification of **Nordson®** as machine manufacturer, is in compliance with the legislation in force through these certificates:

- **Declaration of conformity** (see attached)
- **CE plate**
- **Operation and maintenance manual**

A special identification plate, applied to the machine, permanently carries information regarding **CE** mark. The copies of the identification plates "**CE MARK**", applied on each single machine, and the relevant "**DECLARATION OF CONFORMITY**" are attached.

The machine has been manufactured by:

NORDSON CORPORATION

0.5 Nordson International

Europe

<u>COUNTRY</u>		<u>PHONE</u>	<u>FAX</u>
Austria		43-1-707 5521	43-1-707 5517
Belgium		31-13-511 8700	31-13-511 3995
Czech Republic		4205-4159 2411	4205-4124 4971
Denmark	Hot Melt	45-43-66 0123	45-43-64 1101
	Finishing	45-43-66 1133	45-43-66 1123
Finleand		358-9-530 8080	358-9-530 80850
France		33-1-6412 1400	33-1-6412 1401
Germany	Erkrath	49-211-92050	49-211-254 658
	Lüneburg	49-4131-8940	49-4131-894 149
	Düsseldorf-Nordson UV	49-211-3613 169	49-211-3613 527
Italy		39-02-904 691	39-02-9078 2485
Netherlands		31-13-511 8700	31-13-511 3995
Norway	Hot Melt	47-23 03 6160	47-22 68 3636
	Finishing	47-22-65 6100	47-22-65 8858
Poland		48-22-836 4495	48-22-836 7042
Portugal		351-22-961 9400	351-22-961 9409
Russia		7-812-11 86 263	7-812-11 86 263
Slovak Republic		4205-4159 2411	4205-4124 4971
Spain		34-96-313 2090	34-96-313 2244
Sweden	Hot melt	46-40-680 1700	46-40-932 882
	Finishing	46 (0) 303 66950	46 (0) 303 66959
Switzerland		41-61-411 3838	41-61-411 3818
United Kingdom	Hot Melt	44-1844-26 4500	44-1844-21 5358
	Finishing	44-161-495 4200	44-161-428 6716
	Nordson UV	44-1753-558 000	44-1753-558 100

Distributors in Eastern & Southern Europe

DED, Germany	49-211-92050	49-211-254 658
--------------	--------------	----------------

Outside Europe

For Your nearest **Nordson**® office outside Europe contact the Nordson offices below for detailed information.

CONTACT NORDSON	PHONE	FAX
------------------------	--------------	------------

Africa/Middle East

DED, Germany	49-211-92050	49-211-254 658
---------------------	--------------	----------------

Asia/Australia/ Latin America

Pacific South Division, USA	1-440-988-9411	1-440-985-3710
------------------------------------	----------------	----------------

Japan

Japan		81-3-5762 2700	81-3-5762 2701
--------------	--	----------------	----------------


North America

Canada		1-905-475 6730	1-905-475 8821
USA	<i>Hot Melt</i>	1-770-497 3400	1-770-497 3500
	<i>Finishing</i>	1-440-988 9411	1-440-985 1417
	<i>Nordson UV</i>	1-440-985 4592	1-440-985 4593


0.6 How to read and use the "operating and maintenance manual"

This manual is an integral part of the machine, therefore it must be preserved and appropriately used for the whole operating life of the machine, also in case of transfer to outside parties.

The manual is subdivided into chapters each identified by a summarizing first page. Each page reports its progressive number depending on the chapter and to the number of the chapter itself.



The graphic illustrations, reported in the manual, are identified by a progressive number depending on the chapter.



0.6.1 Symbols used in the manual

To make the reading and the understanding of this manual easier and immediate the following symbols have been used:



"Conductor": qualified and authorized person that has been instructed to start the machine with the necessary protections in place via the use of the commands on the push-button panel.



Mechanical maintenance person: a technician, qualified and authorized to install, repair and carry out special maintenance that is exclusively mechanical.



Electrical maintenance person: a technician, qualified and authorized to install, repair and carry out special maintenance exclusively electrical.



Manufacturer's technician with mechanical competences: for complex and/or special operations.



Manufacturer's technician with electrical or electronic competences: for complex and/or special operations.

0.9 **Responsibilities**

This manual reflects the technical state of the machine at the moment of sale and it is open to changes, depending on the firm opinion of the manufacturer.

In case of manual changes the manufacturer is not obliged to update those manuals that accompany machines already sold.

The manufacturer is released from any responsibility in any case of improper or incorrect use such as, for example:

- the use of the machine by not trained staff;
- use without following the regulations in force;
- incorrect installation;
- mains supply defects;
- serious lack of maintenance;
- not authorized modifications to the machine;
- the use of unsuited spare parts;
- inobservance of the "operating and maintenance manual";

It must be remembered that any total or partial reproduction of this manual is forbidden unless authorised by **Nordson®**.



	TECHNICAL ASSISTANCE	REV. 1.3
--	----------------------	-------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

1.0	TECHNICAL ASSISTANCE	Page1 to 2
-----	----------------------	------------

CHAPTER 1.0 TECHNICAL ASSISTANCE

For any technical or commercial requirements, please contact:



**GENERAL SAFETY INSTRUCTIONS**REV.
1.3

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

2.0 GENERAL SAFETY INSTRUCTIONS

Page 1 to 6

2.1	Dangerous areas and placing of safety devices	Page	4
2.2	Placing of warning labels	Page	5
2.3	General prohibitions	Page	6
2.4	General obligations	Page	6
2.5	Dangers	Page	6
2.6	Advice about lighting	Page	6

CHAPTER 2.0 GENERAL SAFETY ADVICE

Each interaction between the worker and the machine has been carefully studied and analysed during the planning stages.

The choice in construction, the technical features of the machine and the indications reported in this document are intended to guarantee the greatest safety level to the exposed people and the worker.

According to the "**Machine directive**" 2006/42/CE it is useful to remember the following definitions:

"Dangerous zones": every zone inside and/or in proximity to a machine where the presence of an exposed person is a danger to safety and health.

"Exposed person": any person situated entirely or partially in a dangerous zone.

"Worker": a person instructed to operate, regulate and carry out ordinary maintenance and/or clean the machine.

To better define the limit of operation, the relevant qualifications of the "**worker**" and to make the immediate reading and the understand of the manual easier, the following classifications have been used:



"Conductor":

qualified and authorized person that has been instructed to start the machine with the necessary protections in place via the use of the commands on the push-button panel.



Mechanical maintenance person:

a technician, qualified and authorized to install, repair and carry out special maintenance that is exclusively mechanical.



Electrical maintenance person:

a technician, qualified and authorized to install, repair and carry out special maintenance exclusively electrical.



Manufacturer's technician with mechanical competences:

for complex and/or special operations.



Manufacturer's technician with electrical or electronic competences:

for complex and/or special operations.

The employer should provide the necessary training to the staff regarding the risks of accidents, and safety devices to protect the worker, and must also insist on the observance of rules and company instructions about safety and protection measures.

The worker has to respect the instructions given by the employer or other authorised people and particularly:

- Use correctly the machine, equipment, tools, and safety's devices;
- Use correctly the individual protective devices;
- Notify immediately any dangerous conditions;
- Must not remove or modify safety devices or control signal;
- Follow scrupulously the indications in this manual;

The unauthorised tampering and substitution of one or more parts or groups of the machine, the use of equipment or normal wear material other than that indicated by **Nordson®** can pose a risk of accidents and hence release the manufacturer from civil or penal responsibilities.




ATTENTION : Before starting up the machine and carrying out working operations, electric boards, control panels, and all protections, must be closed and the working area must be free and clean.



ATTENTION : If this machine is an integral part of a plant, it is forbidden to start it unless the whole plant is in compliance with the "**Machine directive**" 2006/42/CE and those that follow.

2.1 Dangerous areas and placing of safety devices


- Due to the structural typology of the machine that is integrated in painting plants, it is necessary to determine and fence an area **A** where the operator must not enter when the plant is in function.
- Emergency stop: the position of the emergency/stop button **01(01)** depends on the type of control module connected to the machine and it has to be integrated to the emergency circuit of the general plant (see the attached wiring diagrams)



2.2 Position of warning labels

The warning labels that are clearly visible and attached to the machine are additional and not alternative measures to the already foreseen protections.

Such labels further improve the operator's safety, in that they give correct information regarding requirements and cautions.



2.3 General prohibitions



Do not remove safety devices and protections.



Temporary removal of protections - protections and safety devices of the machine must **NOT** be removed during maintenance; it is necessary to adopt immediately measures to reduce risks, under the supervision of authorised people.



It is forbidden for any person, except the conductor, to access to the operating area of the machine.



Do not clear or lubricate while the machine is running.



It is forbidden to use water to put out fires.

2.4 General obligations



Switch off at the mains supply before unplugging electrical devices.



Check the effectiveness of protections and precautionary measures.



Notify immediately faults and lack of protections and precautionary measures and any dangerous situation.

2.5 Dangers



High voltage.

2.6 Advice about lighting

The machine is not provided with an autonomous lighting system, because a normal working environment condition, that is at least 300 lux, is sufficient.

The customer should supply a similar lighting value, to carry out the normal working operations.

For maintenance work a portable lamp is recommended.



	DESCRIPTION OF THE MACHINE	REV. 1.3
--	----------------------------	-------------

TITLE OF THE DOCUMENT: Operating and maintenance manual RECIPROCATOR HS

3.0	DESCRIPTION OF THE MACHINE	Page 1 to 3
-----	----------------------------	-------------

3.1	Terminology used	Page 3
-----	------------------	--------

CHAPTER 3.0 DESCRIPTION OF THE MACHINE

The ever-increasing need to produce automatically and to optimise the production cycles of spray-coating systems has led in these years to the development of reciprocators, that, replacing the operator during the most repetitive phases of working processes, eliminate errors caused by carelessness and inexperience.

The new generation of reciprocators by **Nordson®** has been studied in order to increase the requirements of productions and, beginning from the simplest model, technical advanced solutions are used, that eliminate manual works carried out from the edge of machine, previously essential. In fact all adjustments are achieved directly from the control board via simple and immediate commands.

The **Reciprocators mod. HS** are the most recent solution in automated systems; they have been studied to support heavy loads (up to 80 Kg.); they allow a great versatility in use, because they can be used individually as well as in integrated automation systems and automation systems with computerized control.

Description

The reciprocator HS is a self-supporting structure **01(01)**, fixed on a base **01(02)** which assures total stability.


In order to help the positioning, the base is equipped with rotating wheels **01(03)**, while in order to achieve a correct levelling of the machine, also on uneven floors, adjustment blocks are provided **01(04)**.

A special guide **01(05)** which is fixed to the inner part of the structure, allows a trolley to slide via special blocks **01(06)**.

A second guide **01(07)** is placed near the counterweight **01(08)** in order to guide it in its movements; in this way noises and vibrations are reduced to the minimum.

The movement occurs via a pulleys system **01(09)** and a toothed belt **01(10)** and the stroke width is controlled by an encoder **01(11)**.

The movement is guaranteed by a strong gear **01(12)** driven by an electric motor **01(13)** suitably protected by a safety guard **01(14)**.



3.1 Terminology used

- **TROLLEY:** used to move the arm of the spray-gun.
- **ARM:** part of the machine for fitting the spray gun.
- **GUN:** apparatus not supplied by **Nordson®** suitable for the spraying of epoxidic powders or paints.

	TECHNICAL DATA	REV. 1.3
---	----------------	-------------


TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

4.0	TECHNICAL DATA	Page1 to 2
-----	----------------	------------

4.1	Weights and overall dimensions	Page 2
-----	--------------------------------	--------

CHAPTER 4.0 TECHNICAL DATA

4.1 Weights and overall dimensions



ATTENTION : It is forbidden to use the machine in the presence of explosive atmosphere.

STANDARD VERSIONS	HS 17	HS 22	HS 27	HS 32
TOTAL HEIGHT "H"	2500 mm	3000 mm	3500 mm	4000 mm
USEFUL STROKE	1700 mm	2200 mm	2700 mm	3200 mm
DISTANCE FROM THE GROUND	560 mm	560 mm	560 mm	560 mm
SPEED MIN.	10 m/1'	10 m/1'	10 m/1'	10 m/1'
SPEED MAX.	50m/1'	50 m/1'	50 m/1'	50 m/1'
CAPACITY	80 Kg	80 Kg	80 Kg	80 Kg
TOTAL WEIGHT	280 Kg	300 Kg	320 Kg	340 Kg
NOISE	Inferior to 70 dB			
RATED POWER	0,75 kW			
POWER SUPPLY	230 V AC +/- 10% 3F 50 Hz (others on demand)			



	IDENTIFICATION OF THE MACHINE	REV. 1.3
--	-------------------------------	-------------

TITLE OF THE DOCUMENT: Operating and maintenance manual RECIPROCATOR HS

5.0 IDENTIFICATION OF THE MACHINE	Page1 to 2
-----------------------------------	------------

CHAPTER 5.0 IDENTIFICATION OF THE MACHINE


5.0.1 - This manual contains the operating and maintenance instructions for the machine manufactured by **Nordson®**.

The figure **01** shows the location of the identification plate of the machine, that specifies the following information:

- **01(01)** Name of the manufacturer
- **01(02)** Model
- **01(03)** Serial No. and year of manufacture
- **01(04)** Power supply
- **01(05)** Certification mark
- **01(06)** Protection level
- **01(07)** Speed
- **01(08)** Pressure (only for pneumatic releases)



ATTENTION : the serial no. **01(03)** on the plate must be mentioned whenever contacting the Manufacturer for information or spare parts.



5.0.2 - Copies of the plates "**CE MARK**", applied to each machine, and the relevant "**DECLARATION OF CONFORMITY**" are attached.

5.0.3 - If the plate **CE MARKING** is accidentally damaged , removed from the machine or simply the manufacturer mark is removed, the customer must inform **Nordson®**.

	FORESEEN AND UNFORESEEN USE OF THE MACHINE	<i>REV.</i> 1.3
---	---	---------------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

6.0 FORESEEN AND UNFORESEEN USE OF THE MACHINE	Page1 to 2
---	------------

6.1 Residual risks

Pag. 2

CHAPTER 6.0 FORESEEN AND UNFORESEEN USE OF THE MACHINE

The use of the **Reciprocator HS** is foreseen exclusively in automatic systems of spray-coating with thermosetting powders or paints.
It has been planned for automatic guns that perform vertical and horizontal movements.



ATTENTION : If this machine is an integral part of a plant , it is forbidden to start it unless the whole plant is in compliance with the "**Machine directive**" 2006/42/CE and those that follow.

The use of the machine must be carried out exclusively by staff that knows its work and have acknowledged all that is described on this manual.



It is absolutely forbidden to use the machine for any use other than that for what it is intended unless a specific request has been made to **Nordson®**.

The incorrect use of the machine could cause risks both to the operator and to the machine itself.

6.1 Residual risks

The normal automatic modality of the machine does not foresee risks, on condition that the whole plant, where the machine is integrated, is in compliance with the "**Machine directive**" 2006/42/CE.

The only residual risk is the possibility to reach the movable sliding vertical parts with the upper limbs.

This risk can occur only during the maintenance operations where the operator is close contact with the machine.

In any case the risk has been limited by using special protections and safety plates that inform and make the reaching of the dangerous zone difficult.

	MOVING AND TRANSPORT	REV. 1.3
---	-----------------------------	--------------------


TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

7.0	MOVING AND TRANSPORT	Page1 to 5
------------	-----------------------------	------------

7.1	Staff qualification	Page	3
7.2	Equipment and means to use	Page	3
7.3	Advice about lifting	Page	4
7.3.1	Lifting with ropes	Page	4
7.3.2	Lifting with machines	Page	5
7.4	Storage conditions	Page	5
7.5	Checking the machine	Page	5

CHAPTER 7.0 MOVING AND TRANSPORT

The machine is normally sent completely wrapped up with Pluriball, but depending on distance and type of contractual agreements it may be also blocked to a pallets or in a crate.



01

7.1 Staff qualification



During the movement and unloading from the means of transport qualified staff for the use of fork lift trucks, cranes or hoists should be used.

7.2 Equipment and means to use



ATTENTION: Before carrying out any moving operations of the machine, make sure there is nobody in the proximity.

Use chains and ropes and make sure that their characteristics are compatible with the weight and the overall dimension of the machine to move and in accordance with the regulations in force.

ADVICE

- Slings must be in accordance with the regulations ISO 4878 - ISO 9351.
- Only use slings, if the label, indicating all manufacturer's data, is attached and the capacity is clearly shown.
- Check slings before each lifting.
- Do not used in case of damage, cuts or wear.
- Follow the load factors indicated for each standard configuration.
- Use suitable protections to lift loads with sharp corners.
- Do not twist or knot the belt.
- Follow the instructions for use indicated by the supplier.
- Hook the other ends of the slings on to the hook of the lifting machineries.


7.3 Advice about lifting

Depending on transport conditions, the reciprocator by **Nordson®** can be moved by lifting with ropes or fork lift trucks.

7.3.1 Lifting with ropes




Place the special lifting eyebolts **02(01)** in the special hooking points as indicated in figure **02** using two ropes, with maximum corner α equal to 30° and rope characteristics adapted to the lifting of loads indicated.



7.3.2 Lifting with machines



If the reciprocator by **Nordson®** is moved horizontally, it is necessary to lay it down on the forks of the forklift truck paying attention to position the spray coupler facing down as in figure 03.



7.4 Storage conditions

If the machine has already been installed and a storage period, during which the machine will not be used, is necessary, all precautions must be taken to avoid contact with dust dirt, humidity and all moving mechanical parts that are prone to rust must be covered with a layer of grease. If the machine has to be moved, wrap it up with Pluriball and follow the previous procedures in order to move it.

7.5 Checking the machine

When unpacking the machine, check immediately that during transport none of the parts have been damaged.

Any damage to the machine, loss of additional or supplied parts must be communicated immediately to **Nordson®**.



	MACHINE INSTALLATION	REV. 1.3
---	-----------------------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

8.0	MACHINE INSTALLATION	Page1 to 3
------------	-----------------------------	------------


8.1	Environmental conditions	Page	3
8.2	Need of free spaces	Page	3

CHAPTER 8.0 MACHINE INSTALLATION

There is no particular advice or precautions to take during the installation of the machine that can be placed on a normal floor.

To place the machine in a paint plant, it is sufficient to let it slide on the wheels **01(01)**, of the base, up to the required position.

Turn the special gradual dials **01(02)** to stop the machine and level it with the help of levelling indicators **01(04)**; when it reaches the correct position, block the safety lock nuts **01(03)**.



8.1 Environmental conditions

The machine can work with the following environmental and climatic conditions:

- Environmental luminosity **min.300 Lux.**
- Environmental temperature **+5°/+40° C**
- Relative humidity maximum **50%** at **40° C**
- Relative humidity maximum **90%** at **20° C**

D ATTENTION : It is forbidden to use the machine in explosive atmospheres.

D ATTENTION : In case of use in explosive atmospheres, it is possible to supply the version according to the ATEX directive (to advise during the order).

8.2 Need of free spaces

D ATTENTION : When the reciprocator is positioned, it is necessary to define the area, where the moving parts (gun supporting arm) have their range, according to the EEC laws regarding the security on working stations

02



02

	SETTING UP THE MACHINE	REV. 1.3
---	-------------------------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

9.0	SETTING UP THE MACHINE	Page 1 to 9
------------	-------------------------------	-------------


9.1	Connection of the reciprocator to the control module	Page	2
9.2.1	Assembly dispenser supports	Page	3
9.2.2	Machine balancing	Page	5
9.2.3	Checking of the maximum speed	Page	8

CHAPTER 9.0 SETTING UP THE MACHINE

9.1 Connection of the reciprocator to the control module



Connect the machine with the control module, by using the cables already connected to the junction box located on the side of the motor gear **01**



ATTENTION: The reciprocator HS is projected to be connected to control modules series HQ; for any other kind of connections, contact the **Nordson®** technical office in advance.

N.B.: for the electrical connections, see the wiring diagram attached.


9.2.1 Assembly of dispenser supports




An attachment (two in some versions) is located on the reciprocator for fitting the gun supporting-arm.

To assemble do as follows:

- Assemble the plate **02(01)** on the special support using a setscrew wrench No. 6.



- Position the two stopper plates **03(02)** fixing them to the plate **03(01)** with the special knob screws **03(03)**, then insert the gun and tighten the knob screws, at the same time setting the arm at the required distance.






ATTENTION: The reciprocator HS has a maximum capacity of 80 kg, this value reduces depending on the position; to determine the correct position see chapter 9.2.2 "Machine balancing".




ATTENTION: The arms must be earthed.

Examples of assembly/use of gun supporting arm are now shown.


■ **Example n°1**



■ **Example n°2**




■ **Example n°3**



9.2.2 Machine balancing



The reciprocator HS by **Nordson®** can support a maximum capacity of 80 kg, this value reduces depending on the position of the gun supports as indicated in the graph in fig 07.




Therefore before starting with the machine balancing, it is necessary to carry out a preventive valuation on the grounds of the kind of dispenser and the weight that the machine has to support, considering that the reciprocator **Nordson®** can support a maximum unbalance of 20%.

The machine is supplied, if agreed in the order, already balanced.


In case of no specification the standard configuration is composed by 8 counterweights (with a total weight of 46,4 kg), and eventually other plates with a unit weight of 5,8 kg. are supplied.

To carry out the machine balancing, do as follows:


- Turn off the power supply to the machine.
- Remove the rear door 08(01) using setscrew wrench No. 3.




- Remove the motor safety guard **09(02)** lifting it as indicated in figure **09**.



- Lift the trolley by hand, till the plates of the counterweight are in line with the rear door, an then block it, by inserting a screwdriver into the inner cool fan as indicated in fig. **10**.




- Unscrew the nuts **11(01)** that fix the counterweight modules, using an adjustable wrench CH19.



- Add or remove the required modules till, once the screwdriver has been removed, the gun supporting arm keeps still. **12**



ATTENTION : The reciprocator by **Nordson®** can support a maximum unbalance of 20% of the total weight.




- Once the machine has been balanced repeat the reverse operations, in order to put it in working conditions.

9.2.3 Checking of the maximum speed




If not different defined in the order, the machine is supplied with stops and limit switches positioned at maximum stroke. In case of necessary changes, do as follows:

- Turn off the power supply to the machine.
- Remove the front safety guard **13(01)** using a setscrew wrench No. 5, taking care to remove it first at its base and then lifting it.



- Unloosen the fixing screws of the "end of stroke group" using an adjustable wrench No. 13, then position it at the required height and tighten the screws unloosened previously. **14**



- Repeat the aforesaid operations for the "upper end of stroke group".

- Once the maximum stroke has been mechanically modified, it is necessary to adjust the stroke parameters of the control module (to carry out this operation, refer to the operating manual of the control module).

	BEFORE START UP	REV. 1.3
---	------------------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

10.0	BEFORE START UP	Page 1 to 3
-------------	------------------------	-------------

10.1	Staff qualification	Page	2
10.2	Foreseen control positions	Page	2
10.3	Control boards	Page	2
10.4	Stop-commands and their position	Page	3

CHAPTER 10.0 BEFORE START UP

When starting the machine no particular preparatory procedures are necessary because the machine is tested and adjusted in all its functions by **Nordson®**'s.

10.1 Staff qualification

The operator of the machine, before carrying out any kind of productive cycle, must know all the information, shown in this technical manual about the machine.

10.2 Foreseen control positions

The machine has been projected to be commanded and controlled in all its functions by one operator only.

The foreseen working position is in front of the control panel, integrated in the control system of the plant, from where the operator can verify the correct working of the plant.

10.3 Control boards

The **Reciprocator HS** by **Nordson®** is projected to be connected to control modules series HQ.


For the descriptions of modules refer to the operating manual supplied.

10.4 Stop-commands and their placing

In case of danger, failure or any emergencies it is necessary to press the **EMERGENCY STOP** push button **01(01)** common to the whole plant.



To reset press the **EMERGENCY** push button, with rotating it.





	USE OF THE MACHINE	REV. 1.3
---	--------------------	-------------

TITLE OF THE DOCUMENT: Operating and maintenance manual RECIPROCATOR HS

11.0 USE OF THE MACHINE	Page 1 to 2
-------------------------	-------------

CHAPTER 11.0 USE OF THE MACHINE



For a correct use and programming, see the operating manual of the control module.

	MAINTENANCE	REV. 1.3
---	--------------------	--------------------

TITLE OF THE DOCUMENT: Operating and maintenance manual RECIPROCATOR HS

12.0 MAINTENANCE

Page 1 to 67

12.1	General safety advice	Page	2
12.2	Technical competences	Page	2
12.3	Periodical maintenance table	Page	3
12.4	Summery table of suggested spare parts	Page	4
12.5	Replacing gear-motor	Page	5
12.6	Pulley replacement	Page	12
12.7	Replacement of position sensor	Page	22
12.8	Adjustment of supporting-gun sliding blocks	Page	25
12.9	Replacement of supporting-gun sliding blocks	Page	29
12.10	Adjustment of counterweight	Page	34
12.11	Replacement of counterweight sliding blocks	Page	36
12.12	Replacement of snub pulley	Page	40
12.13	Maximum stroke adjustment of gun supporting arm	Page	49
12.14	Belt replacement	Page	51
12.15	Toothed belt tension adjustment	Page	65

CHAPTER 12.0 MAINTENANCE

In order to have a safe, efficient and reliable machine, careful and constant maintenance is essential.

12.1 General safety advice

It is compulsory, before any maintenance to turn off the power and use any protective devices necessary during all intervention phases.

12.2 Technical competences

There are three kinds of maintenance interventions:



INTERVENTIONS THAT REQUIRE SPECIFIC TECHNICAL COMPETENCES

Can be carried out by not specific staff and usually regard cleaning duties.



INTERVENTIONS THAT REQUIRE SPECIFIC TECHNICAL COMPETENCES

Can only be carried out by staff qualified by customer and regard ordinary maintenances. Mechanical or electric competences may be required.






INTERVENTIONS THAT REQUIRE PARTICULAR TECHNICAL COMPETENCES

Can only be carried out by **Nordson®** qualified mechanical or electrical technicians.

At the beginning of each paragraph, referring to the various maintenance subjects, the relative symbol referring to the necessary qualification of the operator is indicated.

12.3 Periodical maintenance table

PERIODICAL MAINTENANCE TABLE									
NOTE									
BIENNIAL									
ANNUAL									
SEMIANNUAL									
TRIMESTRIAL									
MONTHLY									
SEMWEELY									
WEEKLY									
DAILY									
Check belt tension									The 1st time after one week
Check trolley adjustment									
Guide cleaning									

12.4 Summery table of suggested spare parts

The following components are subject to wear and so a suitable stock should be kept for spare parts.


DESCRIPTION	PART NUMBER
<u>120.1001.17 - Toothed belt HEN 17</u>	736421
<u>310.8207 - End of stroke sensor</u>	736339
<u>500.0004 - Kit sliding blocks</u>	736177
<u>500.0005 - Protective strip</u>	-
<u>310.8061.03 - Encoder</u>	736404
<u>120.0002 - Encoder joint</u>	736358
<u>400.0004 - Gear motor</u>	-
<u>500.0015 - Kit counterweight blocks</u>	-

12.5 Replacing gear-motor




To replace the gear-motor do as follows:


- Turn off the power supply to the machine.
- Remove the gun supporting-arm.
- Remove the safety guard of the motor, lifting it as in figure 01.




- Remove the upper safety guard using a setscrew wrench No. 5 taking care to remove it first at the base and then lifting it. 02




- Open the junction box and disconnect the encoder. **03**



- Remove the rear cover **04(01)** using a setscrew wrench No. 3.




- Lift the trolley by hand till the plates of the counterweight are in line with the rear door, then block it with a staff. **05**




- Using a setscrew wrench No. 8 slacken the belt by unscrewing the screws of the counterweight. **06**




ATTENTION: do not remove the screws completely so as to avoid that the counterweight and the trolley fall.




- Unloosen the hose clamp of the joint near the pulley using a screwdriver. **07**




- Unscrew the fixing screws of the motor-gear using a ratchet spanner No.19 then remove the motor-gear. **08**




- Unscrew the fixing screws of the pulley using a setscrew wrench No. 5. **09**




- Insert the screws, removed previously, into the special dismantle holes and screw them in to remove the pulley. **10**



- Remove the ring-block from the driving shaft. **11**



- Using a box wrench No.19 remove the pivot of the driving shaft joint. **12**



- Replace the motor-gear.

- Repeat the reverse operations to reassemble the new motor gear.
- For the correct belt tension see chapter 12.15.



ATTENTION: Once the belt has been tensioned, apply Loctite to the adjusting screws.



ATTENTION: After the connection of the motor, check its correct direction of rotation.


- Once the mechanical operations have been finished, proceed with the setting of the control module (to carry out this operation, refer to the operating manual of the control module).

12.6 Pulley replacement




To replace the driving pulley do as follows:

- Turn off the power supply to the machine.
- Remove the gun supporting-arm.
- Remove the safety guard of the motor, lifting it as in figure 13.




13

- Remove the front safety guard using a setscrew wrench No. 5 taking care to remove it first at its base and then lifting it. 14




14

- Remove the rear window **15(01)** using a setscrew wrench No. 3.




- Lift the trolley by hand till the plates of the counterweight are in line with the rear door, then block it with a staff. **16**




- Using a setscrew wrench No. 8 slacken the belt unscrewing the screws of the counterweight. **17**




ATTENTION: Do not remove the screws completely so as to avoid that the counterweight and the trolley fall.




- Unloosen the hose clamp of the joint near the pulley using a screwdriver **18** then remove the position sensor **18(01)**.




- Block the electric motor by inserting a screwdriver into the inner cooling fan. **19**




- Unscrew the screws of the ring-block that fix the pulley to the driving shaft, using a setscrew wrench No. 5. **20**




- Insert the screws, removed previously, into the special dismantle holes and screw them in to remove the pulley. **21**



- Remove the screws from the threaded holes of the ring block. **22**




- Using a box wrench No.19 remove the pivot of the driving shaft joint. **23**




N.B. - The pivot is fixed with Loctite. It is therefore necessary to use a greater force to unblock it.


- To avoid friction clean the ring block with a cloth. **24**




- Retighten, without closing, the screws in the first position. **25**




- Place the pulley on the driving shaft, then tighten the clamping screws of the ring block, cross ways. The screws should be tightened to 1,7 Kg. **26**




- Add Loctite on the thread of joint pivot and tighten it on the driving shaft with a box wrench Nr.19. **27**




- Reassemble the position sensor **28(01)** inserting the joint on the pivot, then fix the support with the relative screws.




- Remove the screwdriver from the motor fan. **29**



- Tension the toothed belt, see chapter 12.15.
- Carry out the parameters configuration on the programming panel, see the relative technical manual.
- Close the front safety guard and the rear window. **30**



- Reassemble the safety guard and the gun-supporting arm. **31**




12.7 Replacement of position sensor




To replace the position sensor do as follows:

- Turn off the power supply to the machine.
- Remove the gun-supporting arm.
- Remove the safety guard of the motor, lifting it as in figure 32.




32

- Remove the front safety guard using a setscrew wrench No. 5 taking care to remove it first at its base and then lifting it. 33




33


- Remove the rear window **34(01)** using the setscrew wrench No. 3.




- Unloosen the hose clamp of the joint near the pulley using a screwdriver and disconnect the sensor. **35**



- Using a setscrew wrench No. 5 unscrew the support screws of the sensor support and extract it. **36**



- Unscrew the fixing screws of the sensor using a setscrew wrench No. 4 and replace it. **37**




- Repeat the reverse operations to reassemble the new sensor.

12.8 Adjustment of supporting-gun sliding blocks




To adjust the supporting-gun sliding blocks do as follows:

- Turn off the power supply to the machine.
- Remove the safety guard of the motor, lifting it as in figure 38.




38

- Block the electric motor by inserting a screwdriver into the inner cooling fan. 39




39


- Remove the front safety guard using a setscrew wrench No. 5 taking care to remove it first at its base and then lifting it. **40**




- Check, using a sliding gauge, the parallelism between the sliding blocks. **41**



- Tension the eccentric pivots using a fixed wrench No. 24, till the spring washer preloads. **42**




- Adjust, using a wrench No. 30, the eccentric pivot located in the cylindrical hole till the block and the bar are in contact; adjust, at the same way, the pivot located in the slotted hole of the plate. **43**




- Repeat the two aforesaid operations in order to have a better adjustment, making sure that the accessible wheels, when block is still, can easily slide on the bar by hand.

44




- When finished, block the eccentric pivots. **45**



ATTENTION: Avoid excessive loads on the wheels so as to damage the surface.


- Reassemble the front safety guard.
- Remove the screwdriver from the fan of the motor, then reassemble the safety guard.

12.9 Replacement of supporting-gun sliding blocks




To replace the supporting-gun sliding blocks do as follows:


- Turn off the power supply to the machine.
- After having removed the gun supporting-arm, remove the front safety guard, unscrewing the two screws that fix it at the lower part and lifting it at its base. **46**




- Position the trolley to a position useful to operate, then block the counterweight stroke with a staff (or others) to avoid its fall. **47**




- Unscrew, with a spanner No. 30, the four nuts of the sliding blocks pivots. **48**



- Rotate the eccentric pivots till the blocks loosen. **49**




- Remove the pivots from the trolley, removing one sliding block at a time. **50**




ATTENTION: If the counterweight is not blocked by an iron staff, it will slide up to the lower end of stroke and consequently the trolley will be lift up to the upper end of stroke.


- Assemble the new sliding block with pivot, screwing it to the rear plate through two nuts on the relative washers, without blocking them. **51**



- Position the other block into the guide seat, then join the block with the trolley plate through the eccentric pivots. **52**




- Rotate the eccentric pivots **53(01)** so that the wheels are not preloaded, then screw the nuts, with the relative elastic washers, on the pivots.



- Proceed with the blocks adjustment (see chapter 12.8).

- Reassemble the gun supporting-arm, tighten the four knob screws. **54**




12.10 Adjustment of counterweight




To adjust the counterweight do as follows:


- Turn off the power supply to the machine.
- Remove the rear door **53(01)** using a setscrew wrench No. 3.




- Position and block the gun supporting-arm so as to position the support of counterweights up to the rear door, then unscrew the four nuts that fix the counterweights. **54**



- Add or remove the counterweight modules in order to balance the trolley, when the gun supporting-arm is assembled. **57**



- Block the modules on the threaded pivots tightening the four nuts. **58**




- Reassemble the rear door and unblock the gun supporting-arm.

12.11 Replacement of counterweight sliding blocks




To replace the counterweights do as follows:

- Turn off the power supply to the machine.
- Remove the rear door **59(01)** using a setscrew wrench No. 3.




- Position and block the gun supporting-arm so as the support of the counterweight is in line with the window of the rear door. **60**




- Slacken the belt unscrewing the two tie rod screws that join the upper and the lower counterweight, using a socket setscrew wrench No 8. **61**




ATTENTION: Do not remove the tie rod screws completely so as to avoid that the counterweight and the trolley fall.




- Tilt sideways the counterweight group so as to remove the sliding block from the guides. **62**




- Replace the sliding blocks by unscrewing the two screws with a setscrew wrench No.5 that fix them to the upper counterweight. **63**




- Tilt sideways the counterweight group in order to insert the sliding blocks into the guides. **64**



- Adjust the belt tension (see the relative paragraph) with a socket setscrew wrench No. 8 **65**



- Close the rear door and remove the backstop to the gun supporting-arm. **66**




12.12 Replacement of snub pulley




ATTENTION: To perform this maintenance two person are necessary.

To replace the snub pulley do as follows:


- Turn off the power supply to the machine.
- Remove the rear door **67(01)** using a setscrew wrench No. 3.




- Remove the front safety guard using a setscrew wrench No. 5, taking care to remove it first at its base and then lifting it. **68**




- Position the trolley in line with the rear window. **69**




- Remove the motor safety guard, by lifting it as in figure **70**.




- Block the electric motor by inserting a screwdriver into the inner cooling fan. **71**




- Unscrew the four knob-screws **72(01)** and remove the gun supporting-arm **72(02)**.




- Unscrew the four nuts **73(01)** that fix the counterweights **73(02)** with a wrench No.19




- Remove the additional weights to the upper counterweight. **74**




- Using a socket setscrew wrench No. 8 unscrew the tie rods **75(01)** a little, in order to slacken the toothed belt of the counterweight.




- Using a socket setscrew wrench No. 5 remove the two screws **76(01)** in order to extract the belt **76(02)** from the upper counterweight, taking care to hold and put the counterweights to the ground, while the second operator must let the trolley supporting-arm slide to the lower end of stroke.



- Remove the toothed belt from the snub pulley group **77(03)**.




- With a wrench No. 13 remove the screw **78(01)** then with a setscrew wrench No. 5 remove the screws **78(02)** in order to extract the snub pulley **78(03)**.




- Assemble the new snub pulley group and after having checked the adjustment with the drive pulley tighten the screws **78(01)** and **78(02)** again.


- Insert the toothed belt into the snub pulley group. **79**




- Fix the toothed belt to the basic module of the upper counterweight, screwing, with a setscrew wrench No. 5, the two screws **80(01)** of the toothed plate **80(02)**.





- Reassemble the additional modules of the upper counterweight. **81**




- Using a socket setscrew wrench No. 8 operate on the two screws **82(01)** to tension the toothed belt (see par. 12.15).



- Close the front safety guard **83** and the rear window **84(01)**.



- Reassemble the gun supporting-arm. **85**




12.13 Maximum stroke adjustment of gun supporting arm




If not different defined in the order, the machine is supplied with stops and limit switches positioned at maximum stroke. In case of necessary changes, do as follows:


- Turn off the power supply to the machine.
- Remove the gun supporting-arm **86(01)** unscrewing the four knob-screws **86(02)**.




- Remove the front safety guard using a setscrew wrench No. 5 taking care to remove it first at its base and then lifting it. **87**



- Unscrew the nuts that fix the "end of stroke group" using an adjustable wrench No. 13 **88** then slide it up to the required position.



- Reassemble the safety guard and fix it with the screws to the base. **89**




12.14 Belt replacement




ATTENTION: To perform this maintenance two persons are necessary.

To replace the belt, do as follows:


- Turn off the power supply to the machine.
- Remove the rear door **90(01)** unscrewing the four screws with a setscrews wrench No. 3.




- Remove the front safety guard using a setscrew wrench No. 5 taking care to remove it first at its base and then lifting it. **91**




- Position the trolley in line with the upper window. **92**




- Remove the motor safety guard lifting it as indicated in figure **93**.




- Block the electric motor by inserting a screwdriver into the inner cooler fan. **94**




- Remove the gun supporting-arm **95(02)** by unscrewing the four knob-screws **95(01)**.




- Unscrew the four nuts **96(02)** that fix the counterweights **96(01)** with a wrench No.19




- Remove all additional weights of the upper and lower counterweight. **97**




- Mark the belt (up and down) in order to locate the assembly position. **98**



- Mark the toothed plate that fix the belt to the trolley. **99**




- Using a socket setscrew wrench No. 5 extract the four screws **100(01)** to remove the belt **100(02)** from the trolley, taking care to hold it and put in to the lower end of stroke.




- Slacken the belt by unscrewing the two tie rod screws that fix the upper and the lower counterweight. Using a socket setscrew wrench No. 8. **101**




ATTENTION: Do not remove the tie rod screws completely, so as to avoid that the counterweight and the gun supporting-arm to fall.




- Tilt sideways the counterweight group so as to remove the sliding block from the guides. **102**




- Using a setscrew wrench No. 8 unscrew completely the tie rods, taking care to hold the lower part of the counterweight. **103**




- Remove the toothed belt from the counterweights unscrewing the four screws that fix it to them through the toothed plates **104(01)**.




- Remove the toothed belt from the snub pulley group **105(03)** and from the machine.




- Lay down the toothed belt to replace on the ground near the old one, then report the marks from the old belt to the new one. **106**




- Pos. **106(A)** - Assembly position of upper counterweight
 Pos. **106(B)** - Assembly position of lower counterweight
 Pos. **106(C)** - Fixing position of the trolley
- Assemble the new belt **107(01)** between the two pulleys positioning the two extremities in line with the rear window then fix them, with the toothed plates **107(02)**, to the two base counterweights.




- Fix the belt to the trolley, and position the toothed plate following the marks, then block it with the special screws. **108(01)**




- Using a socket setscrew wrench No. 8 screw, without tightening, the tie rods **109(01)** in order to join the upper **109(02)** and the lower **109(03)** counterweight.



- Tilt sideways the counterweight group so as to remove the sliding block from the guides. **110**




- Assemble the additional counterweights and block them on the threaded pivots **111(01)** with the nuts **111(02)**.




- Tension correctly the belt following the instructions described in paragraph 12.15.


- Close the front cover and fix it with the two base screws. **112**




- Close the rear door by tightening the for fixing screws with a setscrew wrench No. 3. **113**




- Remove the screwdriver from the electric motor. **114**



- Reassemble the motor safety guard. **115**



- Reassemble the gun supporting-arm. **116**




12.15 Toothed belt tension adjustment




To adjust the belt tension do as follows:



- Turn off the power supply to the machine.
- Remove the rear door unscrewing the four screws with a setscrew wrench No. 3.
117(01)




- Position the trolley supporting-arm high and consequently the counterweight low.
118




- With a socket setscrew wrench No. 8 operate on the two tie rods **119(01)** so as to reach the values indicated on the table **120**.



- Check the parallelism between the upper and the lower counterweight adjusting eventually the tension of the tie rods. **121**



- Reassemble the rear door **122**.






	ALARMS	REV. 1.3
---	--------	-------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

13. ALARMS	Page 1 to 2
----------------	-------------

CHAPTER 13.0 ALARMS

ANOMALY	CAUSE	REMEDY
NOISE AND VIBRATIONS DURING THE STROKE	<ul style="list-style-type: none"> ■ Incorrect adjustment of trolley ■ Worn-out wheels of trolley ■ Dirty guide 	<ul style="list-style-type: none"> ■ Adjust trolley ■ Replace wheels ■ Clean guide
STRONG STROKES DURING MOVEMENT	<ul style="list-style-type: none"> ■ Belt tension insufficient 	<ul style="list-style-type: none"> ■ Adjust belt tension
NOISE DURING REVERSAL	<ul style="list-style-type: none"> ■ Play of reductor gear 	<ul style="list-style-type: none"> ■ Replace gear-motor
LOSS OF STROKE REFERENCES	<ul style="list-style-type: none"> ■ Breaking of sensor joint ■ Breaking of position sensor 	<ul style="list-style-type: none"> ■ Replace the sensor joint ■ Replace the position sensor
ELECTRIC ANOMALIES		<ul style="list-style-type: none"> ■ See manual of control

	SPARE PARTS	REV. 1.3
---	--------------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

14.0 SPARE PARTS	Page 1 to 3
-------------------------	-------------

14.1	General advice	Page	2
14.2	How to order spare parts	Page	3

CHAPTER 14.0 SPARE PARTS

14.1 General advice

- In order to optimise and address correctly the demand of spare parts and/or technical assistance, it is necessary to refer to **Nordson®**.
- If the customer uses, above all during the period of contractual guarantee of the machine, not original **Nordson®** spare parts, the guarantees about functional performances and above all accident prevention safeties are no more valid. Therefore **Nordson®** declines each possible responsibilities direct, indirect or consequential, about accidents occurred to staff, or about possible restrictions of productive performances of the machine.
- The safety, reliability and interchangeability of **Nordson®** spare parts is guaranteed by the using of the same technological/productive and qualitative processes used to the achievement of the machine.
- Before removing any components of the machine and replacing them with spare parts, it is necessary to look it up in the "**OPERATING AND MAINTENANCE MANUAL**" attached.
This is necessary to identificate all information to adopt to guarantee safety during the interventions (safety and accident prevention measures).




14.2 How to order spare parts

To order spare parts see the data on the CE plate.
The order will have to contain the following elements:

- Model/Type of machine
- Serial No.
- Table No.
- Position No. of spare part
- Description of spare part
- Code of spare part
- Quantity


Example:

- Reciprocator HS 17
- Serial No. 99999
- Table 1.0
- Position 07
- Encoder 2500I/G 5VDC shaft 10 MM L.D.
- 736404
- No. 1 piece





**MOTOR-GEAR GROUP****CODE****TAB. 1.A**

Pos.	Part Number	Mu	Q.ty	
1	-		1	400.0004 - Motor-gear V.S.F. 0.75KW i=12.1
2	-		1	220.1060 - Driving pulley
3	-		1	330.0500 - Ring block d25/D50
4	-		1	220.1059 - Connection pin
5	736358		1	120.0002 - Absolute sensor/encoder joint
6	-		1	220.1062 - Encoder support
7	736404		1	310.8061.03 - Encoder 2500I/G 5VDC shaft 10 MM L.D.
8	-		4	230.1054 - Cheese headed hexagonal screw M5x16 UNI 5931 8.8 Zn B




**CODE****TAB. 2.A**

Pos.	Part Number	Q.ty	
1	-	1	220.1014 - Trolley plate
2	-	1	335.0009 - Eccentric sliding block with 3 wheels
3	-	1	335.0008 - Concentric sliding block with 3 wheels




**COUNTERWEIGHT GROUP****CODE****TAB. 3 .A**

Pos.	Part Number	Q.ty	
1	-	1	220.1019 - Upper counterweight HS
2	-	2	220.1016 - Belt clamping plate T10-50
3	-	1	220.1019 - Lower counterweight HS
4	-	8	230.2150 - Flat socket head screw M8x16 UNI 5933 8.8 Zn B
5	-	1	220.1020 - Right guide for counterweight HS
6	-	1	230.1103 - Cheese headed hexagonal screw M6x20 UNI 5931 8.8 Zn B
7	-	1	220.1020 - Left guide for counterweight HS
8	-	1	230.1109 - Cheese headed hexagonal screw M6x50 UNI 5931 8.8 Zn B
9	-	2	220.1067 - Cheese headed hexagonal screw M10x150x75 8.8 UNI 5931
10	736425	2	220.0543 - Additional counterweight HS Pb



**SNUB PULLEY GROUP****CODE****TAB. 4 .A**

Pos.	Part Number	Q.ty	
1	-	1	220.1090 - Guide fixing plate
2	-	2	220.1091 - Pulley support plate
3	-	4	230.2151 - Flat socket head screw M8x20 UNI 5933 8.8 Zn B
4	-	1	220.1063 - Shaft
5	-	1	220.1061 - Snub pulley
6	-	2	330.0006 - Stiff radial ball bearing d25/D52/15
7	-	1	220.4203 - Spacer D32xd25x26
8	-	1	230.0709 - Seeger ring int. 52
9	-	2	220.4204 - Spacer D32xd25x9.5
10	-	2	230.5010 - Flat washer d8xD32 Zn B
11	-	2	230.5405 - Toothed washer D. 8 UNI 8842/A Zn B
12	-	2	230.1652 - Hexagonal screw M8x20 UNI 5739 8.8 Zn B



**END OF STROKE GROUP****CODE****TAB. 5 .A**

Pos.	Part Number	Q.ty	
1	-	1	220.1015 - Mechanical lock
2	-	2	330.3005 - Buffer 25x20 anti-vibration
3	-	1	250.0322 - Sensor support right
4	-	1	250.0323 - Sensor support left
5	736339	1	310.8207 - Inductive sensor NC ø12 PNP

	DRAINING OF HARMFUL SUBSTANCES AND DISMANTLING THE MACHINE	REV. 1.3
---	---	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

15.0 DRAINING OF HARMFUL SUBSTANCES AND DISMANTLING THE MACHINE

Page 1 to 2


CHAPTER 15.0 DRAINING OF HARMFUL SUBSTANCES AND DISMANTLING THE MACHINE

The user must remember that the harmful substances used, see lubricating oil, grease etc., must be drained in accordance with the local laws in force.

The dismantling of the machine and the removal of its components must be carried out according with the local laws or directives.

The machine is prevalently composed by:

- Ferrous materials (structure and mechanical parts)
- Materials derived from copper (electric wires and electric motor winding)
- Aluminium materials (mechanical parts)
- Lead materials (counterweights)



	ATTACHED	REV. 1.3
---	-----------------	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

16.0 ATTACHED	Page 1 to
----------------------	-----------

- ☐ CE plate
- ☐ Declaration of conformity
- ☐ Wiring diagrams
- ☐ Recommended oils

CE PLATE



TYPE

SERIAL N°/YEAR

/

POWER SUPPLY

V50Hz KW

IP

SPEED

m / 1'


PRESSURE

bar

DECLARATION OF CONFORMITY

WIRING DIAGRAMS

TERMINAL BOARD OF THE MACHINE



RECOMMENDED OILS

R...	K... (HK...)	F...	S... (HS...)	W... (HW...)	R32 R302	6) °C -50 0 +50 +100 Standard -10 +40	DIN (ISO)	ISO, NLGI	Mobil®	Shell	Lubrizol	ARAL	bp	TERMO	Castrol Tribol Optimol	FUCHS	TOTAL
							CLP (CC)	VG 220	Mobilgear 600 XP 220	Shell Omala 220	Kiuberol GEM 1-220 N	Aral Degol BG 220	BP Energol GR-XP 220	Meropa 220	Tribol 1100/220	Renolin CLP 220	Carter EP 220
							CLP PG	VG 220	Mobil Glygoyle 30	Shell Tivela S 220	Kiuberol GH 6-220	Aral Degol GS 220	BP Energol SG-XP 220	Synlube CLP 220	Tribol 800/220	Alphasyn PG 220 Optiflex A 220	Carter SY 220
						4) -25	CLP HC	VG 220	Mobil SHC 624	Shell Omala HD 220	Kiuberol GEM 4-220 N	Aral Degol PAS 220		Pinnacle EP 220	Tribol 1510/220	Alphasyn T 220 Optiflex Synthetic X 220	
						4) -40	CLP HC	VG 150	Mobil SHC 629	Shell Omala HD 150	Kiuberol GEM 4-150 N			Pinnacle EP 150		Alphasyn T 150 Optiflex Synthetic X 150	Carter SH 150
							CLP (CC)	VG 150	Mobilgear 600 XP 100	Shell Omala 100	Kiuberol GEM 1-150 N	Aral Degol BG 100	BP Energol GR-XP 100	Meropa 150	Tribol 1100/100	Renolin CLP 150	Carter EP 100
							HLP (HM)	VG 68-46 VG 32	Mobil D.T.E. 13M	Shell Tellus T 32	Kiuberol GEM 1-88 N	Aral Degol BG 46		Rando EP Ashless 46	Tribol 1100/68	Hyacin AWS 32 Optigear 32	Equivalis ZS 46
						4) -40	CLP HC	VG 68	Mobil SHC 626								
							CLP HC	VG 32	Mobil SHC 624		Kiuber-Summit HySyn FG-32					Alphasyn T32 Optilab HY 32	Dacris SH 32
						4) -40	HLP (HM)	VG 15	Mobil D.T.E. 11M	Shell Tellus T 15	Isocifex NT 30 ROT		BP Energol HLP-HM 15	Rando HDZ 15		Hyacin AWS 22	Equivalis ZS 15
							CLP (CC)	VG 680	Mobilgear 600 XP 680	Shell Omala 680	Kiuberol GEM 1-680 N	Aral Degol BG 680	BP Energol GR-XP 680	Meropa 680	Tribol 1100/680	Renolin SEW 680	Carter EP 680
							CLP PG	VG 680 1)		Shell Tivela S 680	Kiuberol GH 6-680		BP Energol SG-XP 680	Synlube CLP 680	Tribol 800/680	Optiflex A 680	
						4) -30	CLP HC	VG 460	Mobil SHC 634	Shell Omala HD 460	Kiuberol GEM 4-460 N			Pinnacle EP 460		Optigear Synthetic X 460	
						4) -40	CLP HC	VG 150	Mobil SHC 629	Shell Omala HD 150	Kiuberol GEM 4-150 N			Pinnacle EP 150		Optigear Synthetic X 150	Carter SH 150
							CLP (CC)	VG 150	Mobilgear 600 XP 100	Shell Omala 100	Kiuberol GEM 1-150 N	Aral Degol BG 100	BP Energol GR-XP 100	Meropa 150	Tribol 1100/100	Renolin CLP 150	Carter EP 100
							CLP PG	VG 220 1)	Mobil Glygoyle 30	Shell Tivela S 220	Kiuberol GH 6-220	Aral Degol GS 220	BP Energol SG-XP 220	Synlube CLP 220	Tribol 800/220	Alphasyn PG 220 Optiflex A 220	Carter SY 220
							CLP HC	VG 68	Mobil SHC 626		Kiuber-Summit HySyn FG-32			Cetus PAO 46		Alphasyn T32	Dacris SH 32
						4) -40	CLP HC	VG 32	Mobil SHC 624								
							HCE	VG 460		Shell Classica Fluid GL 460	Kiuberol 4UHT-460 N	Aral Eural Gear 460				Optilab GT 460	
							E	VG 460			Kiuberol CA2-460	Aral Degol BAB 460			Tribol Bio Top 1418/460		
							SEW PG	VG 460 2)			Kiuber SEW HT-460-5						
							API GL5	SAE 75W90 (-VG 100)	Delvac Synth Gearoil LS 75 W90								
						4) -40	CLP PG	VG 460 3)			Kiuberol UH1 6-460						
							DIN 51 818	00	Glygoyle Grease 00	Shell Tivela GL 00	Kiuberol GE 46-1200			Multifak 6833 EP 00		Spherol EPL 0	Marson SY 00
							5)	000 - 0	Mobilux EP 004	Shell Avania GL 00		Aralub MFL 00	BP Energol LS-EP 00	Multifak EP 000		CLS Grease Longtime PD 00	Multus EP 00




	PERSONALISATION/SPECIAL EXECUTIONS	REV. 1.3
--	---	--------------------

TITLE OF THE DOCUMENT : Operating and maintenance manual RECIPROCATOR HS

17.0 PERSONALISATION/SPECIAL EXECUTIONS	Page 1 to 2
--	-------------

17.1	Additional handle for manual movement	Page 2
------	---------------------------------------	--------

CHAPTER 17.1 ADDITIONAL HANDLE FOR MANUAL MOVEMENT



Pos.	Part Number	Mu	Q.ty	Description
1	7033030	Nr.	1	500.0073 - Handle for manual moving

