

# **DC Gunmover Controller**

**Wall Mount Panel**

Manual P/N 768 617 C  
– English –

**Keep for Future Reference**



NORDSON (UK) LTD. • STOCKPORT



#### Order number

P/N = Order number for Nordson products

#### Notice

This is a Nordson Corporation publication which is protected by copyright. Original copyright date 1998. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Nordson Corporation. The information contained in this publication is subject to change without notice.

#### Trademarks

AccuJet, AquaGuard, Asymtek, Automove, Autotech, Blue Box, CF, Can Works, Century, Clean Coat, CleanSleeve, CleanSpray, COLORMAX, Compumelt, Control Coat, Cross-Cut, Cyclo-Kinetic, Dispensejet, DispenseMate, Durafiber, Durasystem, Easy Coat, Easymove Plus, Econo-Coat, EPREG, ETI, Excel 2000, Flex-O-Coat, Flexi-Spray, Flow Sentry, Fluidmove, Fluidshooter, FoamMelt, FoamMix, Helix, Horizon, Hose Mole, Hot Shot, Hot Stitch, Isocoil, Isocore, Iso-Flo, KB30, Little Squirt, Magnastatic, MEG, Meltex, MicroSet, Millenium, Mini Squirt, Moist-Cure, MultiScan, Nordson, OmniScan, Opticoat, Package of Values, PluraFoam, Porous Coat, PowderGrid, Powderware, Pro-Flo, ProLink, PRX, RBX, Rhino, S. design stylized, SC5, SCF, Select Coat, Select Cure, Slaughterback, Smart-Coat, Spray Squirt, Spraymelt, Super Squirt, Sure-Bond, Sure Coat, System Sentry, Tela-Therm, Trends, Tribomatic, UniScan, UpTime, Versa-Coat, Versa-Screen, Versa-Spray, Watermark, When you expect more are registered trademarks – ® – of Nordson Corporation.

ATS, Auto-Flo, AutoScan, BetterBook, Chameleon, CanNeck, Check Mate, CPX, Control Weave, Controlled Fiberization, EasyClean, Ebraid, Eclipse, Equi=Bead, Fillmaster, FlexiCoat, Gluie, Ink-Dot, JR, Maxima, MicroFin, Minimeter, Mountaingate, Multifil, OptiMix, Pattern View, PluraMix, Primarc, Prism, Pro-Meter, Pro-Stream, Process Sentry, PurTech, Pulse Spray, Saturn, Seal Sentry, Select Charge, Select Series, Sensomatic, Shaftshield, Spectral, Spectrum, Sure Brand, Sure Coat, Swirl Coat, Vista, Walcom, 2 Rings (Design) are trademarks – ® – of Nordson Corporation.

Designations and trademarks stated in this document may be brands that, when used by third parties for their own purposes, could lead to violation of the owners' rights.

# Declaration of Conformity

## 98/37/EC

## 73/23/EEC

We,

**Nordson (U.K.) Limited**

of

**Ashurst Drive, Cheadle Heath, Stockport, Cheshire, SK3 0RY,  
United Kingdom**

declare that under our sole responsibility for supply/manufacture of the product(s)

**Product Name** DC Gunmover Controller

**Model Number(s)** 765154

**Product Options** All


to which this declaration relates, is in conformity with the following standards and other normative documents

**Safety** BS EN 60204-1:1993  
"Safety of Machinery – Electrical equipment of machines"

EN 60335:Part 1:1988  
"Safety of household and similar electrical appliances"

BS EN 292:1991  
"Safety of machinery – Basic concepts, general principles for design"

following the provisions of 98/37/EC and 73/23/EEC Directives

A handwritten signature in black ink, appearing to read 'J. Ainsworth', with a long horizontal line extending from the end of the signature.

Jim Ainsworth  
General Manager

Nordson (U.K.) Ltd., 14th March 2001

NB ref EN45014 (BS7514)



# Table of Contents

---

## ***Congratulations on the Purchase of Your Nordson Product***

---

|   |     |
|---|-----|
| Your Safety is Important to Nordson ..... | O-1 |
| Manufacturer of Equipment .....           | O-1 |

---

## ***Nordson International***

---

|  |     |
|--|-----|
| Europe .....   | O-3 |
| Distributors in Eastern & Southern Europe .....        | O-3 |
| Outside Europe / Hors d'Europe / Fuera de Europa ..... | O-4 |
| Africa / Middle East .....                             | O-4 |
| Asia / Australia / Latin America .....                 | O-4 |
| Japan .....  | O-4 |
| North America .....                                    | O-4 |

---

## ***Section 1 Safety***

---

|   |     |
|---|-----|
| 1. Introduction .....                         | 1-1 |
| 2. Qualified Personnel .....                  | 1-1 |
| 3. Intended Use .....                         | 1-1 |
| 4. Regulations and Approvals .....            | 1-1 |
| 5. Personal Safety .....                      | 1-2 |
| 6. Fire Safety .....                          | 1-3 |
| 7. Action in the Event of a Malfunction ..... | 1-4 |
| 8. Disposal .....                             | 1-4 |

---

## ***Section 2 Description***

---

|   |     |
|---|-----|
| 1. Intended Use .....                         | 2-1 |
| 2. Features .....                             | 2-2 |
| 3. Operational Controls and Indications ..... | 2-2 |

---

**Section 3**  
**Installation**

---

|                              |     |
|------------------------------|-----|
| 1. Transport .....           | 3-1 |
| 2. Unpacking .....           | 3-1 |
| 3. Removing .....            | 3-1 |
| 4. Storage .....             | 3-1 |
| 5. Disposal .....            | 3-1 |
| 6. Setting Up the Unit ..... | 3-2 |
| 7. Electrical .....          | 3-2 |
| 8. Configuration .....       | 3-3 |

---

**Section 4**  
**Operation**

---

|                          |     |
|--------------------------|-----|
| 1. Daily Operation ..... | 4-1 |
|--------------------------|-----|

---

**Section 5**  
**Maintenance**

---

|  |     |
|--|-----|
| 1. Daily Maintenance .....               | 5-1 |
| 2. Circuit Board Replacement .....       | 5-1 |
| 3. Replacement of Other Components ..... | 5-2 |
| 4. Electrical Safety .....               | 5-2 |

---

**Section 6**  
**Troubleshooting**

---

|  |     |
|--|-----|
| 1. Important Hints for Troubleshooting ..... | 6-1 |
|--|-----|

---

**Section 7**  
**Parts**

---

|  |     |
|--|-----|
| 1. Introduction .....                  | 7-1 |
| Using the Illustrated Parts List ..... | 7-1 |
| 2. Wall Mount DC Controller .....      | 7-2 |

---

**Section 8**  
**Specifications**

---

|                               |     |
|-------------------------------|-----|
| 1. Electrical .....           | 8-1 |
| 2. Mechanical .....           | 8-1 |
| 3. Noise .....                | 8-1 |
| 4. Electrical Schematic ..... | 8-2 |

# Congratulations on the Purchase of Your Nordson Product

Nordson equipment is engineered and manufactured in accordance with strict specifications, using high quality components and state-of-the-art technologies that assure reliable, long-term performance. Your product was thoroughly tested for proper operation prior to shipment.

Before unpacking and installing your new equipment, please read this manual. It is your guide to safe installation, productive operation and effective maintenance. We recommend that you keep the manual available for future reference.

---

## ***Your Safety is Important to Nordson***

---

Carefully read the *Safety* section. Your product is designed for safe operation when used according to the published instructions. Potential hazards exist when operating instructions are not followed.

---

## ***Manufacturer of Equipment***

---

Nordson (U.K.) Ltd.  
Ashurst Drive  
Cheadle Heath  
Stockport  
England  
SK3 0RY

Telephone: 0044 (0) 161-495-4200  
Fax: 0044 (0) 161-428-6716

For a list of local Nordson organisations, see *Nordson International*.





# Nordson International

## Europe

| Country                |                                | Phone            | Fax              |
|------------------------|--------------------------------|------------------|------------------|
| <b>Austria</b>         |                                | 43-1-707 5521    | 43-1-707 5517    |
| <b>Belgium</b>         |                                | 31-13-511 8700   | 31-13-511 3995   |
| <b>Czech Republic</b>  |                                | 4205-4159 2411   | 4205-4124 4971   |
| <b>Denmark</b>         | <i>Hot Melt</i>                | 45-43-66 0123    | 45-43-64 1101    |
|                        | <i>Finishing</i>               | 45-43-66 1133    | 45-43-66 1123    |
| <b>Finland</b>         |                                | 358-9-530 8080   | 358-9-530 80850  |
| <b>France</b>          |                                | 33-1-6412 1400   | 33-1-6412 1401   |
| <b>Germany</b>         | <i>Erkrath</i>                 | 49-211-92050     | 49-211-254 658   |
|                        | <i>Lüneburg</i>                | 49-4131-8940     | 49-4131-894 149  |
|                        | <i>Düsseldorf - Nordson UV</i> | 49-211-3613 169  | 49-211-3613 527  |
| <b>Italy</b>           |                                | 39-02-904 691    | 39-02-9078 2485  |
| <b>Netherlands</b>     |                                | 31-13-511 8700   | 31-13-511 3995   |
| <b>Norway</b>          | <i>Hot Melt</i>                | 47-23 03 6160    | 47-22 68 3636    |
|                        | <i>Finishing</i>               | 47-22-65 6100    | 47-22-65 8858    |
| <b>Poland</b>          |                                | 48-22-836 4495   | 48-22-836 7042   |
| <b>Portugal</b>        |                                | 351-22-961 9400  | 351-22-961 9409  |
| <b>Russia</b>          |                                | 7-812-11 86 263  | 7-812-11 86 263  |
| <b>Slovak Republic</b> |                                | 4205-4159 2411   | 4205-4124 4971   |
| <b>Spain</b>           |                                | 34-96-313 2090   | 34-96-313 2244   |
| <b>Sweden</b>          | <i>Hot Melt</i>                | 46-40-680 1700   | 46-40-932 882    |
|                        | <i>Finishing</i>               | 46 (0) 303 66950 | 46 (0) 303 66959 |
| <b>Switzerland</b>     |                                | 41-61-411 3838   | 41-61-411 3818   |
| <b>United Kingdom</b>  | <i>Hot Melt</i>                | 44-1844-26 4500  | 44-1844-21 5358  |
|                        | <i>Finishing</i>               | 44-161-495 4200  | 44-161-428 6716  |
|                        | <i>Nordson UV</i>              | 44-1753-558 000  | 44-1753-558 100  |

## Distributors in Eastern & Southern Europe

|                     |              |                |
|---------------------|--------------|----------------|
| <b>DED, Germany</b> | 49-211-92050 | 49-211-254 658 |
|---------------------|--------------|----------------|

**Outside Europe /  
Hors d'Europe /  
Fuera de Europa**

- For your nearest Nordson office outside Europe, contact the Nordson offices below for detailed information.
- Pour toutes informations sur représentations de Nordson dans votre pays, veuillez contacter l'un de bureaux ci-dessous.
- Para obtener la dirección de la oficina correspondiente, por favor diríjase a unas de las oficinas principales que siguen abajo.

| Contact Nordson | Phone | Fax |
|-----------------|-------|-----|
|-----------------|-------|-----|

**Africa / Middle East**

|              |              |                |
|--------------|--------------|----------------|
| DED, Germany | 49-211-92050 | 49-211-254 658 |
|--------------|--------------|----------------|

**Asia / Australia / Latin America**

|                                |                |                |
|--------------------------------|----------------|----------------|
| Pacific South Division,<br>USA | 1-440-988-9411 | 1-440-985-3710 |
|--------------------------------|----------------|----------------|

**Japan**

|       |                |                |
|-------|----------------|----------------|
| Japan | 81-3-5762 2700 | 81-3-5762 2701 |
|-------|----------------|----------------|

**North America**

|        |            |                |                |
|--------|------------|----------------|----------------|
| Canada |            | 1-905-475 6730 | 1-905-475 8821 |
| USA    | Hot Melt   | 1-770-497 3400 | 1-770-497 3500 |
|        | Finishing  | 1-440-988 9411 | 1-440-985 1417 |
|        | Nordson UV | 1-440-985 4592 | 1-440-985 4593 |

## *Section 1*

---

# ***Safety***

---



# Section 1

## Safety

---

### **1. Introduction**

---

Read and follow these safety instructions. Task and equipment specific warnings, cautions, and instructions are included in equipment documentation where appropriate.

Make sure all equipment documentation, including these instructions, is accessible to all persons operating or servicing equipment.

---

### **2. Qualified Personnel**

---

Equipment owners are responsible for making sure that Nordson equipment is installed, operated, and serviced by qualified personnel. Qualified personnel are those employees or contractors who are trained to safely perform their assigned tasks. They are familiar with all relevant safety rules and regulations and are physically capable of performing their assigned tasks.

---

### **3. Intended Use**

---

Use of Nordson equipment in ways other than those described in the documentation supplied with the equipment may result in injury to persons or damage to property.

Some examples of unintended use of equipment include

- using incompatible materials
- making unauthorized modifications
- removing or bypassing safety guards or interlocks
- using incompatible or damaged parts
- using unapproved auxiliary equipment
- operating equipment in excess of maximum ratings

---

### **4. Regulations and Approvals**

---

Make sure all equipment is rated and approved for the environment in which it is used. Any approvals obtained for Nordson equipment will be voided if instructions for installation, operation, and service are not followed.

---

## **5. Personal Safety**

---

To prevent injury follow these instructions.

- Do not operate or service equipment unless you are qualified.
- Do not operate equipment unless safety guards, doors, or covers are intact and automatic interlocks are operating properly. Do not bypass or disarm any safety devices.
- Keep clear of moving equipment. Before adjusting or servicing any moving equipment, shut off the power supply and wait until the equipment comes to a complete stop. Lock out power and secure the equipment to prevent unexpected movement.
- Relieve (bleed off) hydraulic and pneumatic pressure before adjusting or servicing pressurized systems or components. Disconnect, lock out, and tag switches before servicing electrical equipment.
- While operating manual electrostatic spray guns, make sure you are grounded. Wear electrically conductive gloves or a grounding strap connected to the gun handle or other true earth ground. Do not wear or carry metallic objects such as jewelry or tools.
- If you receive even a slight electrical shock, shut down all electrical or electrostatic equipment immediately. Do not restart the equipment until the problem has been identified and corrected.
- Obtain and read Material Safety Data Sheets (MSDS) for all materials used. Follow the manufacturer's instructions for safe handling and use of materials, and use recommended personal protection devices.
- To prevent injury, be aware of less-obvious dangers in the workplace that often cannot be completely eliminated, such as hot surfaces, sharp edges, energized electrical circuits, and moving parts that cannot be enclosed or otherwise guarded for practical reasons.

---

## 6. Fire Safety

---

To avoid a fire or explosion, follow these instructions.

- Ground all conductive equipment in the spray area. Check equipment and workpiece grounding devices regularly. Resistance to ground must not exceed one mega-ohm.
- Shut down all equipment immediately if you notice static sparking or arcing. Do not restart the equipment until the cause has been identified and corrected.
- Do not smoke, weld, grind, or use open flames where flammable materials are being used or stored.
- Provide adequate ventilation to prevent dangerous concentrations of volatile materials or vapors. Refer to local codes or your material MSDS for guidance.
- Do not disconnect live electrical circuits while working with flammable materials. Shut off power at a disconnect switch first to prevent sparking.
- Know where emergency stop buttons, shutoff valves, and fire extinguishers are located. If a fire starts in a spray booth, immediately shut off the spray system and exhaust fans.
- Shut off electrostatic power and ground the charging system before adjusting, cleaning, or repairing electrostatic equipment.
- Clean, maintain, test, and repair equipment according to the instructions in your equipment documentation.
- Use only replacement parts that are designed for use with original equipment. Contact your Nordson representative for parts information and advice.

---

**7.    *Action in the Event of a  
Malfunction***

---

If a system or any equipment in a system malfunctions, shut off the system immediately and perform the following steps:

- Disconnect and lock out electrical power. Close pneumatic shutoff valves and relieve pressures.
- Identify the reason for the malfunction and correct it before restarting the equipment.

---

**8.    *Disposal***

---

Dispose of equipment and materials used in operation and servicing according to local codes.



## Section 2

---

# ***Description***

---



## Section 2

### Description

#### 1. *Intended Use*

The Nordson DC Gunmover Controller is intended for use in the control of Nordson Reciprocator Columns. The columns cover a range of standard heights:

- 1.0 metres stroke length – 765 022
- 1.5 metres stroke length – 765 023
- 2.0 metres stroke length – 765 024
- 2.5 metres stroke length – 765 025

The Controller is designed for use in powder coating installations.




Fig. 2-1

---

## 2. Features

---

The Controller features are listed below:

- Independent control over speed of travel in each direction.
- Independent operator control of top and bottom turnaround position of the working stroke.
- Internal control over the maximum stroke length. Maximum capacity of 30kg load, working, equivalent to more than 10 Nordson powder spray guns and mounting hardware.
- Maximum speed of travel of 120 feet per minute.

---

## 3. Operational Controls and Indications

---

The front panel controls are as follows:

- **Main Isolator**  
Disconnects power to the internal control circuits, the switch is interlocked with the door ensuring that power is not on when the door is open.
- **Start**  
A momentary push action switch that disengages the motor brake, and enables the electronics to control the motor. There is a delay after pressing the switch before the reciprocator carriage moves.
- **Stop**  
A momentary action switch that engages the motor brake and disables the motor control electronics.
- **Top Limit**  
Adjusts the point at which the carriage changes from up stroke to down stroke for the working stroke. The maximum working stroke for each machine is set internally. The minimum working stroke is approx. 450mm, i.e. the top limit must be 450mm higher than the bottom limit.
- **Bottom Limit**  
Adjusts the point at which the carriage changes from down stroke to up stroke for the working stroke. The maximum working stroke for each machine is set internally. The minimum working stroke is approx. 450mm, i.e. the bottom limit must be 450mm lower than the top limit.
- **Up Speed**  
Adjusts the speed of travel in the up direction.
- **Down Speed**  
Adjusts the speed of travel in the down direction.

## *Section 3*

---

# ***Installation***

---



## Section 3

# Installation



**WARNING:** Allow only qualified personnel to perform the following tasks. Observe and follow the safety instructions in this document and all other related documentation.

---

### 1. Transport

---

Transport the unit so as to avoid damage. Do not throw the unit. Use suitable packaging materials and sturdy cartons. See *Specifications* section for dimensions and weights.

Protect the unit from exposure to humidity, dust and vibrations.

---

### 2. Unpacking

---

Carefully unpack the unit to avoid damaging it. Check for damage caused during transport.

Save packing materials for possible later use. Otherwise recycle or dispose of properly according to local regulations.

---

### 3. Removing

---

Switch off the mains supply, then disconnect all electrical connections from the unit.

---

### 4. Storage

---

Pack the unit in suitable packing materials and sturdy cartons. Protect from humidity, dust and large temperature fluctuations (condensation).

---

### 5. Disposal

---

Dispose of properly according to local regulations.

---

## **6.   *Setting Up the Unit***

---



**WARNING:** Allow only qualified personnel to perform the installation. Observe safety instructions.

Choose a location for the Controller where there is free circulation of air, a clearance of 150 mm on all sides should be allowed.

The Controller requires at least 600 mm to the front of the cabinet to allow the door to open.

1. Fix the Controller to its support using the four fixing holes in the corners of the unit. The Controller should be mounted vertically.
2. Connect the ten-way connector on the underside of the Controller to the reciprocator column using the cable provided.

---

## **7.   *Electrical***

---



**WARNING:** Allow only qualified personnel to perform electrical connections. Observe the safety instructions.

1. The Controller requires a single phase 240 VAC supply which can supply a minimum of 10 A. We suggest a cable of 1.5 mm<sup>2</sup>, 3 cores be used and that this supply be protected by a 10-Amp fuse or a 10-Amp type 2 circuit breaker.
2. Connect the cable cores to the connector supplied as follows:  
Live – L1– Brown connects to terminal 1  
Neutral – L2 – Blue connects to terminal 2  
Earth – E – Green/Yellow connects to terminal E.



---

## 8. Configuration

---



**WARNING:** Allow only qualified personnel to perform electrical work. Observe the safety instructions. This section requires operation of the panel with the control panel door open and the supply energised, exercise extreme caution.

**NOTE:** Read this complete section thoroughly before commencing.

1. Withdraw the reciprocator from the booth.
2. Set the speed controls on the front panel to zero.
3. On the control panel set the top limit to zero (fully anti-clockwise), set the bottom limit to nine (fully clockwise).
4. Apply power to the control panel, this will require the use of a suitable tool to turn the isolator into the energised position.
5. Start the control panel by depressing the Start push-button.
6. Turn one of the speed controls slightly clockwise until the reciprocator carriage starts to move up or down the column slowly. If the carriage fails to move, turn the control to zero and operate the other speed control until the carriage starts to move.
7. The carriage will be moving towards the top or bottom of the reciprocator.
8. If the limits have been set for the column the carriage will stop at or before reaching the maximum stroke length.
9. When the desired limit is reached turn both speed controls to zero.
10. Open the control panel door and adjust the appropriate top or bottom preset potentiometer on the Reciprocator Limit P.C.A. A clockwise rotation of RV2 will raise the top limit. A clockwise rotation of RV1 will lower the bottom limit.
11. Turn the other speed control clockwise a small amount and repeat the above procedure from paragraph 7 until both the top and bottom limit are set.
12. Increase the speed gradually trimming the limits accordingly until maximum speed is reached.
13. Switch off the controller and place the reciprocator into the gunslots. Start the reciprocator with the speeds set low, check for correct stroke, increase speed and check that no contact is made with the booth.



## *Section 4*

---

# ***Operation***

---



## Section 4 Operation



**WARNING:** Allow only qualified personnel to perform the following tasks. Observe and follow the safety instructions in this document and all other related documentation.



**WARNING:** Ensure that the vicinity of the reciprocator is clear of personnel before starting. Failure to do so may result in personal injury.

---

### 1. Daily Operation

---

1. Ensure the emergency stop button is not activated. If the emergency stop button has been pressed investigate reasons before turning on the equipment.
2. Turn on the panel isolator.
3. Check the speed controls are set at zero.
4. Press the Start push-button.
5. Adjust the speed and stroke controls as required.
6. At the end of use turn the speed controls to zero, then press the Stop push-button.
7. Turn off the panel using the isolator.



**CAUTION:** Do not use the emergency stop button to turn off the reciprocator except in an emergency. The action may cause other items of equipment associated with the process to be stopped as well.

Placing the working limits too close together will cause the machine to stop, if this happens raise/lower the limits and restart the machine.



# ***Maintenance***

---





## Section 5 Maintenance



**WARNING:** Allow only qualified personnel to perform the following tasks. Observe and follow the safety instructions in this document and all other related documentation.



**WARNING:** Breathing in certain airborne dusts (including finishing powders) may be hazardous to health. Ask the powder manufacturer for a Material Safety Data Sheet (MSDS) for information. Use appropriate respiratory protection.

---

### 1. Daily Maintenance

---

- Check for the correct operation of all controls. Do not operate the equipment with faulty controls.
- Clean any powder and dust from the cabinet.
- Check all cables for damage, replace any damaged cables.

---

### 2. Circuit Board Replacement

---

The Reciprocator Limit P.C.A. can be removed by using the following procedure.

1. Turn off the power to the controller using the door isolator.
2. Open the cabinet door, and remove the plug in connectors from the Reciprocator Limit P.C.A.
3. Remove the Reciprocator Limit P.C.A. by gently moving the two tabs at either end which clip it to the mounting rail.
4. Fit a new circuit board by reversing the above procedure, ensure that the board is secure on the mounting rail.
5. Refit the connectors to the circuit board.
6. Before operation follow chapter *Configuration* in section *Installation*.

---

**3.    *Replacement of Other Components***

---

Nordson do not recommend customer replacement of any other parts in the Controller.

Customers should either return the unit to their nearest Nordson representative or arrange for a Nordson appointed service engineer to visit to repair the unit.

---

**4.    *Electrical Safety***

---

The Controller should be periodically tested in accordance with the Electricity at work Regulations (1989).

# ***Troubleshooting***

---



# Section 6

## Troubleshooting



**WARNING:** Allow only qualified personnel to perform the following tasks. Observe and follow the safety instructions in this document and all other related documentation.

### 1. Important Hints for Troubleshooting

The following tables provide general information for the troubleshooting of basic problems. Sometimes more detailed information, circuit diagrams or measuring devices are also needed for troubleshooting.

It must be noted that a fault can occur for several reasons. It is advisable to check all possible causes for a given fault. Obvious causes of malfunction such as broken wires, missing fasteners etc., should be noted during visual inspections and corrected immediately.

The Unit does not contain any user serviceable parts, any parts that fail must be replaced by approved parts available from Nordson.

| Problem  | Possible Cause        | Corrective Action   |
|--|-----------------------|---|
| No motion when start pressed (no clunk from contactor) | No supply voltage     | Check supply<br>Check Isolator Closed<br>Check Emergency Stop button not pushed<br>Check no remote Emergency Stop button has been pressed |
|  | Limits crossed        | Check LED indicator LR on P.C.A. if lit then raise/lower the top/bottom limits until LED is not lit                                       |
|  | Motor overtemperature | Check that Drive Operational LED is lit on drive if not lit consult Nordson   |

| Problem   | Possible Cause  | Corrective Action   |
|---|---|---|
| No motion when start button pressed<br>contactor closes when button pressed | Carriage or gearbox jammed<br>Chain broken or off sprockets<br>Speed set to zero<br>Reciprocator Limit PCA failed   | Check for free operation<br>Check chain<br>Adjust speed control<br>Replace PCA  |
| Gun Bounce  | Gun bars too long<br>Reversal too fierce  | Shorten or brace gun bars<br>Consult Nordson  |
| No movement or drives in only one direction                                 | Column potentiometer faulty or incorrectly set<br>Potentiometer gearbox or coupling loose<br>Failure of limit circuits, Reciprocator Limit LEDs TL and BL do not illuminate | Check re-set or replace as necessary<br>Check gearbox and coupling<br>Check operation of circuits manually using door mounted limit controls.<br>Replace Reciprocator Limit PCA |
| Erratic Motion  | Loose Carriage<br>Loose drive sprocket<br>Slack chain<br>Worn gearbox<br>Drive incorrectly set  | Check, replace or adjust carriage wheels<br>Check, replace or adjust sprocket<br>Adjust chain tension<br>Check, replace gearbox<br>Refer to Nordson                             |

**NOTE:** Other controls and adjustments within the controller must not be adjusted by the customer. The configuration of the drive has been set at the factory for optimum operation and adjustments may only be made by 'qualified personnel' under the supervision of Nordson. Controllers with settings not in line with factory settings may be subjected to operating conditions outside those tested by Nordson and therefore may not be the subject of warranty claims.

## *Section 7*

---

# ***Parts***

---





## Section 7

### Parts

#### 1. Introduction

To order parts, call the Nordson Customer Service Center or your local Nordson representative. Use the parts list, and the accompanying illustration, to describe and locate parts correctly.

#### **Using the Illustrated Parts List**

Numbers in the Item column correspond to numbers that identify parts in illustrations following each parts list. The code NS (not shown) indicates that a listed part is not illustrated. A dash (—) is used when the part number applies to all parts in the illustration.

The number in the Part column is the Nordson Corporation part number. A series of dashes in this column (-----) means the part cannot be ordered separately.

The Description column gives the part name, as well as its dimensions and other characteristics when appropriate. Indentions show the relationships between assemblies, subassemblies, and parts.

| Item | Part     | Description   | Quantity | Note |
|------|----------|---------------|----------|------|
| —    | 000 0000 | Assembly      | 1        | A    |
| 1    | 000 000  | • Subassembly | 2        |      |
| 2    | 000 000  | • • Part      | 1        |      |

- If you order the assembly, items 1 and 2 will be included.
- If you order item 1, item 2 will be included.
- If you order item 2, you will receive item 2 only.

The number in the Quantity column is the quantity required per unit, assembly, or subassembly. The code AR (As Required) is used if the part number is a bulk item ordered in quantities or if the quantity per assembly depends on the product version or model.

Letters in the Note column refer to notes at the end of each parts list. Notes contain important information about usage and ordering. Special attention should be given to notes.

**2. Wall Mount DC Controller**

| Item  | Part     | Description  | Quantity | Note |
|---|----------|--|----------|------|
| –   | 765 154  | Controller, Reciprocator, D.C., Wall mount         | 1        |      |
| 1   | 765 139  | • Legend Plate                                     | 1        |      |
| 2   | 765 131X | • Drive, D.C. Pre 1994 (BBC)                       | 1        | A    |
|   | 765 130  | • Drive, D.C. 1994 – 1999 (Eurotherm SSD 540)      | 1        |      |
|   | 765 157  | • Drive, D.C. Post 1999 (Eurotherm 514C)           | 1        |      |
| 2a  | 765 158  | • Filter, Unit post 1999                           | 1        | B    |
| 3   | 769 026  | • Connector, Insert, 10 Way, Female                | 1        |      |
| 4   | 769 025  | • Connector, Housing, 10 Way, Rear Entry           | 1        |      |
| 5   | 769 211  | • P.C.A., Reciprocator Limit, Pre 1994             | 1        |      |
|   | 769 213  | • P.C.A., Reciprocator Limit, 1994 – 1999 (Orange) | 1        |      |
|   | 769 218  | • P.C.A., Reciprocator Limit, Post 1999 (Green)    | 1        | C    |
| 6   | 769 922  | • Plate Identification                             | 1        |      |
| 7   | 769 020  | • Connector, Housing, 4 Way, Rear Entry            | 1        |      |
| 8   | 769 022  | • Connector, Insert, 4 Way, Male                   | 1        |      |
| 9   | 765 141  | • Potentiometer, 1 Watt, 10K                       | 4        |      |
| 10  | 765 138  | • Knob   | 4        |      |
| 11  | 769 021  | • Connector, Insert, 4 Way, Female                 | 1        |      |
| 12  | 769 019  | • Connector, Hood, 4 Way, Top Entry                | 1        |      |
| 13  | 769 401  | • Nut, M3, Nyloc                                   | 4        |      |
| 14  | 765 140  | • Nut, Potentiometer                               | 4        |      |
| 15  | 765 056  | • Cable, Reciprocator, 10 Way, 6 MTR               | 1        |      |
| <p>NOTE A: This Drive is supplied as a service exchange</p> <p>B: Must be fitted with 765 157 DC Drive Unit.</p> <p>C: The new Electronic PCA can be fitted to Controllers 1994 – 1999 , but a small wiring modification is required.</p> <p>AR: As Required</p> <p>NS: Not Shown</p> |          |  |          |      |

# ***Specifications***

---



## Section 8 Specifications

---

### 1. *Electrical*

---

|                             |     |
|-----------------------------|-----|
| Voltage (Volts)             | 240 |
| Frequency (Hz)              | 50  |
| Power (kW)                  | 2.0 |
| Average Running Current (A) | 7.4 |

---

### 2. *Mechanical*

---

|                             |     |
|-----------------------------|-----|
| Height (mm)                 | 540 |
| Width (mm)                  | 400 |
| Depth (mm)                  | 320 |
| Weight (kg)                 | 24  |
| Ambient Temperature Max (C) | 32  |

---

### 3. *Noise*

---

Less than 70 dB(A). Measured at a distance of 1 m from the surface of the unit and at a height of 1.6 m.

