

## Sure Coat® Powder Spray Gun Electrode Kit



**WARNING:** Allow only qualified personnel to perform the following tasks. Follow the safety instructions in this document and all other related documentation.

### 1. Removing Old Electrode



**WARNING:** Turn off the electrostatic voltage and ground the gun electrode before performing the following tasks. Failure to observe this warning could result in a shock.

- 1. See Figure 1. Disconnect the powder feed hose from the pump.
- 2. Point the gun into the booth.
- 3. Blow the powder out of the hose and gun with OSHA-approved low-pressure compressed air.
- 4. Disconnect the powder feed hose from the adapter.




Fig. 1 Purging the Gun

- 5. See Figure 2. Remove the hose adapter (8) from the powder inlet body (3).
- 6. Loosen the set screw (4) in the underside of the powder inlet body.
- 7. Remove the nozzle parts (5, 6, 7) from the powder inlet body.
- 8. Slide the powder inlet body off of the electrode assembly (2) and gun body (1).
- 9. Unscrew the old electrode assembly from the gun body.

# 1. Removing Old Electrode (contd)




Fig. 2 Removing the Electrode Assembly

1. Gun body

2. Electrode assembly

3. Powder inlet body

4. Set screw

5. Deflector

6. Pattern adjuster

7. Nozzle adapter

8. Hose adapter

#### 2. Installing New Electrode



**WARNING:** Do not leave powder or contaminants in the gun body or on the end of the electrode assembly. Failure to remove powder build-up or contaminants may result in internal damage, sparking, and/or injury to personnel.

- 1. Remove the shipping container and protective caps from the new electrode assembly.
- 2. See Figure 2. Thread the new electrode assembly (2) onto the gun body (1) until snug.
- 3. Reassemble the gun and reconnect the powder feed hose.

### 3. Parts

See Figure 3. Use the following parts list to order replacement components for your Sure Coat manual powder spray gun electrode assembly.

Item	Part	Part	Description	Quantity	Note
_	288 567		Electrode, handgun, standard, packaged	1	
_		288 573	Electrode, handgun, short, packaged	1	
1	941 081	941 081	<ul> <li>O-ring, silicone, 0.250 x 0.438 x 0.094 in.</li> </ul>	1	
2	288 557	288 557	Support, electrode, handgun	1	
3	940 163	940 163	<ul> <li>O-ring, silicone, 0.625 x 0.750 x 0.063 in.</li> </ul>	1	
4	288 555	288 572	Sleeve, wear	1	
5			Cable, core	AR	
6	288 560	288 560	Electrode, spring, contact	1	
7	288 554	288 554	Holder, cable, electrode	1	
AR: As Required					




Fig. 3 Sure Coat Electrode Kits

Original copyright date 1997. Sure Coat, Nordson, and the Nordson logo are registered trademarks of Nordson Corporation.