


Ejector Gun Controller Menus for Service Personnel

NOTE: This document is a supplement to the *Ejector Gun Controller* manual and contains confidential information made available only for Nordson field service personnel. Do not provide this information to customers.

1. Main Menu Options

See Figure 1, which shows the Ejector gun controller menu tree.




2530002A

Fig. 1 Menu Tree

2. SYSTEM, GUN, AND RESET TOTALS Menu

The **SYSTEM, GUN, AND RESET TOTALS** menu is not available to customers. It is only available to Nordson service personnel through a blind link from the **MAIN MENU**.

Figure 2 shows the **SYSTEM, GUN, AND RESET TOTALS** menu.



2530001A

Fig. 2 System, Gun, and Reset Totals Menu

SYSTEM, GUN, AND RESET TOTALS Menu Navigation

Access the **SYSTEM** and **GUN** submenus to view the counts for gun cycles, system cycles, and system hours. Access the **RESET** submenu when you change a gun and need to reset the gun counts.

NOTE: To perform functions in the **RESET** submenu, you must enter the access code. The access code is 100.

[Refer to Table 1.](#)

Table 1 **SYSTEM, GUN, AND RESET TOTALS** Menu Navigation

When:	You Will See This Message:	Then:
You enter the SYSTEM, GUN, AND RESET TOTALS menu	TOTALS 1. System 2. Gun 3. Reset	Use the numeric keys on the keypad to enter the desired menu.
You enter the SYSTEM menu	1. TOTAL CYCLES 2. TOTAL HOURS	Use the numeric keys on the keypad to enter the desired menu.
You select TOTAL CYCLES from the SYSTEM menu	TOTAL CYCLES X,XXX,XXX,XXX	View the total numbers of times the dispense signal has been received from the robot. This value is not resettable.
You select TOTAL HOURS from the SYSTEM menu	TOTAL HOURS XXX,XXX,XXX	View the total number of hours the system has operated in dispense mode. This value only changes when the system is dispensing and is not resettable.
You enter the GUN menu	GUN #1 CYCLES XXX,XXX,XXX GUN #2 CYCLES XXX,XXX,XXX GUN #3 CYCLES XXX,XXX,XXX GUN #4 CYCLES XXX,XXX,XXX	View the number of cycles Gun #1 has dispensed. This value is not resettable from this menu. View the number of cycles Gun #2 has dispensed. This value is not resettable from this menu. View the number of cycles Gun #3 has dispensed. This value is not resettable from this menu. View the number of cycles Gun #4 has dispensed. This value is not resettable from this menu.
You enter the RESET menu	LIMITED ACCESS CODE	Enter the access code (100) .
Your access code is accepted	Valid Code Access Permitted Then, you will see this menu: RESET GUN CYCLES 1 2 3 4	Use the numeric keys on the keypad to enter the desired menu.
You select 1 from the RESET GUN CYCLES menu	GUN #1 CYCLES F1 – RESET	Press F1 to reset the gun cycle count.
You select 2 from the RESET GUN CYCLES menu	GUN #2 CYCLES F1 – RESET	Press F1 to reset the gun cycle count.
You select 3 from the RESET GUN CYCLES menu	GUN #3 CYCLES F1 – RESET	Press F1 to reset the gun cycle count.
You select 4 from the RESET GUN CYCLES menu	GUN #4 CYCLES F1 – RESET	Press F1 to reset the gun cycle count.

Original copyright date 2001. Nordson and the Nordson logo are registered trademarks of Nordson Corporation.

