
Kinetix[®] Air-Assisted Airless Automatic **Electrostatic Spray Gun**




Refer to the Kinetix Airspray Fluid Tip and Air Cap Selection Chart and the Kinetix KVLP Fluid Tip and Air Cap Selection Chart included with this manual for available part numbers and descriptions.

> Kinetix, Nordson, and the Nordson logo are registered trademarks of Nordson Corporation. MagnaLube is a registered trademark of General Magnaplate Corporation. Perlast is a registered trademark of Precision Polymer Engineering Limited Company.



Service Notes



- 2 Tighten finger tight.
- 3 Apply threadlocking adhesive to threads.
- 4 Generously apply MagnaLube® G (PTFE-filled lubricant).
- 5 Make sure the pins on puller link engage in the grooves in the retainer bushing.
- 6 Tighten to 0.9–1.13 N•m (8–10 in.-lb).
- 7 Activate the spray gun to pull the ball tip back before removing or installing a fluid tip.
- 8 Apply pipe sealant adhesive if fittings do not already have manufacturer's thread sealant applied.
- 9 Tighten finger tight.
- 10 . . . Apply a dielectric grease to O-rings.
- **11** . . . Apply a thin coat of dielectric grease to threads.
- **12** . . . Apply a liberal coat of dielectric grease.
- **13** . . . Apply a thin coat of dielectric grease to the outside.
- 14 . . . Insert hose end into the extension until the O-ring is seated. Screw in the retaining nut then tighten 1/4 turn past hand tight.
- 15 . . . A removable threadlocking adhesive can be applied to the threads of the ball tip if there are problems with the ball tip backing out.