


Low-Flow Conversion Kits

For other parts and information, refer to the *Low-Flow Powder Pump Conversion Kits* instruction sheet, part 108460, located at <http://emanuals.nordson.com/finishing/>




Conversion Kit, part 114217

This kit converts the pump to low-flow and includes a new pickup tube for use with the standard adapter.



Conversion Kit, part 118743

This kit converts the pump to low-flow and includes a new adapter and pickup tube for use on HRS-1 and HRS-2 50-lb feed hoppers.



**Nordson Corporation**  
**Powder Customer Service**  
300 Nordson Drive • Amherst, OH 44001 • (800) 433-9319  
Email: [finishing\\_csc@nordson.com](mailto:finishing_csc@nordson.com)  
[www.nordson.com](http://www.nordson.com)

**Nordson Canada, Limited**  
1211 Denison Street • Markham, Ontario L3R 4B3  
(800) 463-3200  
[www.nordson.ca](http://www.nordson.ca)

**Nordson Deutschland GmbH**  
Heinrich-Hertz-Strasse 42 • 40699 Erkrath, Germany  
Phone: 49-211-9205-0  
Email: [powder.systems@de.nordson.com](mailto:powder.systems@de.nordson.com)  
[www.nordson-finishing-eu.com](http://www.nordson-finishing-eu.com)