

# Caster Kit for Encore LT Mobile Systems

## Installation

The caster kit adds to casters to the front of the Encore LT Mobile System dolly. The casters increase the maneuvering ability of the dolly so it can be transported easier.

Remove the feed hopper or the power box and vibrator table from the dolly.

1. Unpack the caster kit and check the contents against the part list on the following page.
2. Install the caster stems (1) through the bushings (2), then push the stems up through the two front tab holes in the dolly platform.
3. Install the washers (3) over the stems with the flat side facing the retainer tabs.
4. Thread the lock nuts (4) onto the caster shafts, then tighten the nuts securely.




Figure 1 Caster Kit Installation

## Parts

To order parts, call the Nordson Industrial Coating Systems Customer Support Center at (800) 433-9319 or contact your local Nordson representative.

Item	Part	Description	Quantity	Note
–	1601339	KIT, caster, dolly, Encore LT	1	
1	1601335	• CASTER, 2.5 in, 325 lb, 1/2-13 x 1.5 stem	2	
2	-----	• BUSHING, caster kit, dolly, Encore LT	2	
3	-----	• WASHER, caster kit, dolly, Encore LT	2	
4	-----	• NUT, lock, 1/2-13, nylon insert, zinc plated	2	

Issued 5/12

Original copyright date 2012. Nordson and the Nordson logo are registered trademarks of Nordson Corporation.

All other trademarks are the property of their respective owners.